


Lavadora Kenmore 110.24932200





Lavadora Kenmore 110.24932200


Guía	N.P.	Descripción
1	3951609	Washer drain hose
1A	661577	Washer external drain hose
1B	3357090	Washer external drain hose
2	3366913	Washer drain hose clamp
3	3357027	Washer drain hose clamp
4	9740848	Dishwasher screw
5	3351614	Washer screw, #10-24 x 3/8-in
6	3976395	Washer drain hose support clip
7	3390631	Washer screw, #10-16 x 3/8-in
8	3952821	Washer power cord strain
9	90767	Washer screw
10	8318255	Washer control panel strap
11	3356472	Rear panel
12	3366912	Hose clamp
14	62747	Pad panel
15	8317940	Washer pump drain hose
17	3976286	Shield
19	8318201	Washer clip
20	3360977	Washer tub fill nozzle
21	371503	Appliance hose clamp
22	303294	Protector
23	16123	Washing machine washer
24	661605	Washer start capacitor
25	370451	Appliance hose clamp
26	3979347	Washer water inlet valve
28	3348424	Shield
29	3950829	Extension shield
30	8539874	Shield



Lavadora Kenmore 110.24932200

Guía	N.P.	Descripción
31	89503	Washer fill hose
31A	89503	Washer fill hose
32	8528351	Washer wire harness retainer
33	8055003	Retainer
34	285655	Washer hose clamp
35	3363366	Hose clamp
36	3951449	Washer tub-to-pump hose
38	8317926	Washer tub fill nozzle hose

Lavadora Kenmore 110.24932200





Lavadora Kenmore 110.24932200


1C	LIT8528411	Energy guide
1D	LIT8537224	Parts list
1E	LIT4314044	Repair manual
2	3949958	Washer top panel (white)
2A	3954464	Top
3	62750	Washer cabinet spacer
4	3349654	Washer sound dampening pad
5	63424	Washer cabinet
5A	3954357	Washer cabinet
6	62780	Washer cabinet clip
7	3357011	Range screw
8	3356311	Washer lid switch
11	3949238	Washer lid switch
13	3351355	Washer screw
14	21097	Washer lid hinge
15	54583	Washer lid hinge, rear
16	54584	Washer lid hinge
17	21258	Washer lid hinge bearing
18	19119	Washer lid hinge bumper
19	8526145	Lid (white)
19A	8526147	Lid
20	357141	Washer lid switch actuator kit
21	354255	Washer lid bumper
22	9724509	Washer lid bumper
23	3390631	Washer screw, #10-16 x 3/8-in
26	90016	Washer wire harness retainer
28	357213	Washer lid hinge
30	3362952	Washer bleach dispenser

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Lavadora Kenmore 110.24932200





Lavadora Kenmore 110.24932200



Guía	N.P.	Descripción
1	90767	Washer screw
2	3366845	Washer water-le
3	3950344	Temperature switch
4	3948608	Bracket
5	3955719	Wire harness
6	388326	Washer screw
7	3949280	End cap (white)
7A	3949284	End cap
8	3951013	Washer control panel end cap
8A	3977760	Trim
9	3402576	Washer control knob
9A	3402575	Dryer timer knob (white)
10	3949274	Laundry appliance control panel
10A	3949278	End cap (off-whit
11	3949180	Washer cycle selector switch
12	3949432	Washer timer dial
12A	3949431	Washer timer dial (bisque)
13	3948416	Washer timer knob
13A	3948415	Washer control knob
14	3953144	Washer cycle selector switch
15	3951009	Washer control panel end cap
15A	3977759	Trim
16	3400073	Washer screw
17	8283343	Clip
19	3955337	Washer timer
21	3948063	Washer power
23	8539879	Microcomputer
24	3400064	Washer screw



Lavadora Kenmore 110.24932200

Guía	N.P.	Descripción
26	8537233	Control panel
26A	8537234	Control panel
27	688805	Laundry appliance control knob

Lavadora Kenmore 110.24932200





Lavadora Kenmore 110.24932200


Guía	N.P.	Descripción
1	8528278	Washer fabric softener
2	358237	Washer agitator bolt
3	8537433	Washer agitator cam repair kit
4	8055141	Washer agitator cam bearing
5	3366877	Washer agitator dog set
6	3946996	Washer agitator auger
7	3947517	Washer agitator
8	8528150	Washer tub ring assembly
9	3359585	Washer tub ring seal
10	8526016	Washer spin basket
11	21366	Washer spanner
12	8519788	Washer basket balance ring
13	63849	Washer outer tub
14	8533540	Washer agitator spring retainer
15	389140	Washer drive block
16	383727	Washer tub gasket
17	3347780	Washer water-level pressure
18	8522271	Washer filter plug kit
19	3946997	Spring
23	3355921	Washing machine washer
24	3354845	Washer agitator clip
25	8538246	Washer agitator assembly
26	3949550	Washing machin

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas


Lavadora Kenmore 110.24932200





Lavadora Kenmore 110.24932200

Guía	N.P.	Descripción
1	3400076	Washer power
2	64067	Washer suspension spring
3	63907	Washer suspension spring
4	280184	Washer spinner support
5	64065	Washer suspension spring
6	63466	Washer leveling link assembly
7	62597	Washer leveling leg spring
8	62837	Washer leveling leg pin
9	62596	Washer leveling leg
13	3347047	Washer center post bearing
14	357409	Washer agitator shaft seal
15	8318050	Washer counterweight spring
16	62568	Washer suspension plate
17	3946509	Washer suspension plate
18	3633660	Washer base pad set
19	3946512	Washer base
21	3359452	Washer leveling leg lock nut
22	389102	Leveling foot
23	356934	Washer top agitator shaft seal
24	285203	Washer bearing and seal kit
25	63134	Washer sound
26	63806	Washer suspension spring





Lavadora Kenmore 110.24932200

Guía	N.P.	Descripción
1	388952	Washer basket drive assembly
2	63292	Washing machine washer
3	62697	Washer brake retainer clip
4	63283	Washer retainer spring
5	3951311	Washer clutch
6	3951308	Washer clutch band
7	62646	Washer clutch
8	3946792	Washer clutch spring
9	3360630	Washer gear case
10	3357334	Washer screw
11	62611	Washer motor mounting brack
12	62691	Washer drive motor grommet
13	285753	Washer motor coupling
14	3946532	Shield
16	3400516	Washer screw
17	3349637	Washer motor retainer
18	3362089	Shield tub
19	8529935	Washer drive motor
20	8529896	Washer motor
21	62700	Washer drain pump retainer
22	3363394	Washer drain pump
25	3387485	Washer screw
26	3355454	Washer clutch anti-rattle clip