


Lavadora Kenmore Elite 11026924503





Lavadora Kenmore Elite 11026924503


Guía	N.P.	Descripción
1	388952	Washer basket drive assembly
2	62658	Washer drive tube thrust ring
3	356427	Washer basket drive tube seal
4	64027	Washer basket drive tube
5	64035	Washer retainer clip
6	64232	Washer brake assembly
7	62703	Washer spin bearing
8	3353956	Washer brake spring sleeve
9	387806	Spring
10	3355360	Washer brake spring sleeve
11	661516	Cam
12	63022	Sleeve
13	64194	Washer brake cam driver
14	90368	Washer brake cam retainer clip

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Lavadora Kenmore Elite 11026924503





Lavadora Kenmore Elite 11026924503

Guía	N.P.	Descripción
1	8559373	Washer drain hose
2	8541667	Washer clip
3	8577378	Washer drain hose u-bend
4	9740848	Dishwasher screw
5	3351614	Washer screw, #10-24 x 3/8-in
6	3347868	Washer cable tie
7	62863	Washer screw, #10-16 x 3/8-in
8	8055003	Retainer
9	90767	Washer screw
10	8568314	Washer control panel strap
11	8318015	Panel
12	8541669	Connector
13	8541658	Connector
14	62747	Pad panel
15	8519200	Washer rear panel support
16	8539874	Shield
17	8318046	Washer clip
18	8541668	Washer wire harness retainer
19	661661	Washer power cord
20	8559349	Washer power cord strain relief
21	301958	Appliance hose clamp
22	8317974	Washer tub fill nozzle hose
23	370450	Appliance hose clamp
24	387606	Washer tub fill nozzle
25	3979347	Washer water inlet valve
26	8572718	Washer start capacitor



Lavadora Kenmore Elite 11026924503


Guía	N.P.	Descripción
27	8571377	Washer fill hose
27A	8571378	Washer fill hose
28	3976300	Washing machine washer
29	8317496	Washer hose clamp
30	3363366	Hose clamp
31	3951449	Washer tub-to-pump hose

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Lavadora Kenmore Elite 11026924503





Lavadora Kenmore Elite 11026924503


Guía	N.P.	Descripción
1	8543478	Washer fabric softener dispenser cup
2	358237	Washer agitator bolt
3	8537434	Washer agitator cam repair kit
4	8055141	Washer agitator cam bearing
5	8318246	Washer tub ring
6	3354845	Washer agitator clip
7	8538247	Washer agitator
8	3954507	Washer tub ring
9	3359585	Washer tub ring seal
10	8526016	Washer spin basket
11	21366	Washer spanner nut
12	8054468	Washer agitator auger
13	8283125	Washer outer tub
14	8543666	Washing machine washer
15	389140	Washer drive block
16	383727	Washer tub gasket
17	3347780	Washer water-level pressure switch
19	8533540	Washer agitator s
20	8054350	Washer agitator
21	3366877	Washer agitator dog set
22	8055140	Washer agitator spring retainer
23	3348855	Washer o-ring
24	3948705	Washer bleach dispenser hose
25	3354733	Washer agitator cap
26	3949550	Washing machine washer
27	8055228	Washing machine washer
28	8519788	Washer basket balance ring

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Lavadora Kenmore Elite 11026924503






Lavadora Kenmore Elite 11026924503



Guía	N.P.	Descripción
1	3400076	Washer power cord
2	64067	Washer suspension spring bracket
3	63907	Washer suspension spring
4	8575214	Washer spinner support
5	64065	Washer suspension spring bracket
6	63466	Washer leveling link assembly
7	62597	Washer leveling leg spring
8	62837	Washer leveling leg pin
9	62596	Washer leveling leg
10	8546455	Washer center pos
11	357409	Washer agitator shaft seal
12	8318050	Washer counterwe
13	62568	Washer suspension plate friction pad
14	3946509	Washer suspension plate
15	3363660	Washer base pad set
16	39946512	Washer base
17	3359452	Washer leveling leg lock nut
18	389102	Leveling foot
19	356934	Washer top agitator shaft seal
20	285203	Washer bearing and seal kit
21	63134	Washer sound dam
22	63806	Washer suspension spring retainer

Lavadora Kenmore Elite 11026924503



GC-215-C

Guía	N.P.	Descripción
1	3360629	Washer gear case
2	285202	Cover-gc
3	3349985	Washer gear case cover seal
4	285195	Appliance silicone
5	63320	Pinion
6	356427	Washer basket drive tube seal
7	389387	Washer agitator drive shaft
8	90369	Retaining ring
9	62677	Spring retainer
10	62676	Spring
11	63273	Washer agitator drive shaft
12	62619	Washer gear case flat washer
13	62580	Washer agitator dr
14	62581	Washer agitator drive shaft
15	285509	Washer agitator drive shaft
16	62618	Washer
17	285205	Washer agitator cam bearing
18	285205	Washer agitator cam bearing
19	389230	Gear case
21	285352	Washer gear case oil seal
22	3351614	Washer screw, #1
23	3362552	Retainer ring
24	285735	Washer
25	3360629	Washer gear case
26	388253	Washer neutral drain assembly
27	3349296	Rack
28	62621	Actuator
29	388815	Washer





Lavadora Kenmore Elite 11026924503


Guía	N.P.	Descripción
1	W10026350	Installation instructions
1A	8566934	Washer owner's manual
1B	8566913	Laundry guide
1C	8571878	Wiring diagram
1D	8567127	Energy guide
1F	4314044	Washer owner's manual
2	8543479	Top (white)
2A	8543480	Top
3	62750	Washer cabinet spacer
4	3349654	Washer sound dampening pad
5	63424	Washer cabinet (white)
5A	3954357	Washer cabinet
6	62780	Washer cabinet clip
7	3357011	Range screw
8	3351614	Washer screw, #10-24 x 3/8-in
9	8318084	Washer lid switch assembly
10	355274	Lid hinge mounting
11	8559336	Hinge
12	54583	Washer lid hinge, rear
13	8319539	Washer lid hinge bearing
14	19119	Washer lid hinge bumper
15	8567440	Lid
15A	8567441	Bisque lid
16	9724509	Washer lid bumper
17	3390631	Washer screw, #10-16 x 3/8-in
18	21097	Washer lid hinge bracket
19	8566266	Washer dispenser as

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas


Lavadora Kenmore Elite 11026924503





Lavadora Kenmore Elite 11026924503

Guía	N.P.	Descripción
1	90767	Washer screw
2	3366847	Washer water-level pressure switch
3	8564136	Washer water temperature switch
4	8559504	Bracket
5	3957364	Washer wire harness
6	8536939	Laundry appliance control knob clip
7	8559502	Washer control panel end cap
7A	8559516	End cap
8	8312709	Laundry appliance end cap clip
9	8559501	Washer control panel end cap, right
9A	8559514	End cap
10	8541468	Washer control knob
10A	8541469	Washer control knob (bisque)
11	3950357	Cycle switch
12	8541465	Washer timer dial
12A	8541466	Dial
13	8541457	Washer control knob
13A	8541458	Washer control knob
14	8566628	Control panel
14A	8566627	Control panel
16	3400073	Washer screw
17	3954573	Washer cycle selector switch
18	8317387	Washer tub ring
19	8541110	Washer timer
20	3400818	Washer screw
21	8317975	Washer clip





Lavadora Kenmore Elite 11026924503

Guía	N.P.	Descripción
1	388952	Washer basket drive assembly
2	63292	Washing machine washer
3	62697	Washer brake retainer clip
4	63283	Washer retainer spring
5	8299642	Washer clutch
6	W10817888	Washer clutch band
7	62646	Washer clutch spring cap
8	8559387	Washer clutch spring
9	3360629	Washer gear case
10	3357334	Washer screw
11	62611	Washer motor mounting bracket
12	62691	Washer drive motor grommet
13	285753	Washer motor coupling
14	3946532	Shield
16	3400516	Washer screw
17	3349637	Washer motor retainer
18	W10838408	Shield tub
19	8541504	Washer drive motor
20	8529896	Washer motor swit
21	8546127	Washer drain pum
22	3363394	Washer drain pump
23	3387485	Washer screw
24	3355454	Washer clutch anti-rattle clip