


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Lavadora Kenmore 11072981810





Lavadora Kenmore 11072981810

Guía	N.P.	Descripción
1	90984	Hex nut, 8-pack
2	352143	Cover
3	91073	Ball
4	87270	Rod
6	98062	Washer screw
8	96101	Nut
9	365998	Wig way ay
10	16135	Tap end scr
11	95462	Washer cam bar glide
12	354838	Washer transmission cam bar
13	95405	Washer drive belt
14	98001	Cap screw
15	94726	Washer brake pad retainer
16	18642	Bar cam
17	84866	Washer plunger kit
19	17261	Spring
21	358586	Washer spinner support
22	90315	Washer
23	90532	Pin
24	92119	Roller
25	359460	Shaft
26	362901	Gear case
27	352434	Pad
28	356934	Washer top agitator shaft seal
29A	126358	Bolt
29B	126211	Carriage bolt
29C	353770	Carriage bolt
30	98048	Hex bolt



Lavadora Kenmore 11072981810


Guía	N.P.	Descripción
31	17235	Gasket
32	8546455	Washer center post bearing
33	W11095997	Washer agitator shaft seal
34	16515	Washer wire harness retainer
35	356444	Washer basket drive spring
36	358585	Washer spinner support
37	355345	Screw
38	360840	Washer transmission pulley
40	85286	Bracket
41	98023	Nut
42	19138	Grommet, motor bracket
43B	93219	Pully 50 cy
44	356217	Shield
45	92217	Washer
46A	357822	Motor
46B	62190	Motor
47	8572717	Washer start capacitor
48	357030	Clamp
49	9420601	Washer screw, #10-16 x 3/8-in
50	359397	Bearing
51	98537	Bolt
55	357395	Shield
56	362738	Motor switch
57	370950	Wire
58A	351500	Brace
58B	351499	Brace
60	90877	Cap screw, 2-pack

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Lavadora Kenmore 11072981810





Lavadora Kenmore 11072981810

Guía	N.P.	Descripción
1	353366	Hose clamp
2	353367	Hose clamp
3	356349	Hose
5	366072	Inlet
9	356584	Washer seal
11	389140	Washer drive block
12	W10814296	Washer tub seal
15	21365	Washer agitator bolt washer
16	358348	Washer agitator cap
17	359071	Agitator
18	21366	Washer spanner nut
19A	353243	Washer water-level pressure switch
19B	353574	Washer water-level pressure switch
20	351830	Washer seal
21	360804	Air dome
22	96386	Washer outer tub grommet
23	9421321	Hose clamp
24	84091	Manifold
25	92229	Nut
26	92232	Washer
27	92235	Washer
38	272858	Hose clamp
41	359163	Washer fabric softener dispenser
43	358690	Agitator auger
44	358692	Washer agitator dog
45	358691	Cam
46	357574	Appliance o-ring
47	357559	Washer agitator cap seal



Lavadora Kenmore 11072981810


Guía	N.P.	Descripción
48	358237	Washer agitator bolt
49	353096	Clamp
50	368772	Washer lint filter
51	357018	Hose
52A	356645	Hose
52	357052	Hose
53	358036	Washer drain pump
55	96867	Screw pump to gear case, 5/16-18

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Lavadora Kenmore 11072981810





Lavadora Kenmore 11072981810


Guía	N.P.	Descripción
1	91273	Discharge hose
2	352833	Strainer
3	16272	Washer drain hose coupling kit
4	96746	Washer suds saver drain outlet hose
5	96743	Washer drain hose
6	95440	Washer drain hose connector
7	190575	Screw
8	356138	Hose clamp
9	357189	Hose
10	370448	Hose clamp
11	356990	Rivet
12	90228	Pin
13	86798	Washer suds saver solenoid
14	90296	Laundry appliance push
15	99830	Valve kit
16	343641	Dishwasher screw
17	370446	Hose clamp
18	357191	Bracket
19	97784	Hose
20	357334	Connector
21	75183	Diaphragm

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Lavadora Kenmore 11072981810





Lavadora Kenmore 11072981810

Guía	N.P.	Descripción
1	681414	Dishwasher screw
2	359374	Panel
3	W10119828	Washer screw
4	21097	Washer lid hinge bracket
5	98460	Washer push nut
6A	373933	Timer
6B	373997	Washer timer
6D	373935	Washer timer
7A	362681	Washer motor
7B	362682	Motor
8A	371378	Lid (white)
8B	371385	Lid (almond)
8C	371386	Lid
8D	371387	Lid
8E	371388	Lid
10	354255	Washer lid bumper
11	91367	Washer lid hinge
12	19119	Washer lid hinge bumper
13	91770	Washer lid hinge
14	9724509	Washer lid bumper
15E	377196	Top
16	370959	Washer lid switch actuator
17	354764	Washer lid switch screw
18	21258	Washer lid hinge bearing
19	W10820036	Laundry appliance door switch kit
20	WP359231	Washer lid switch shield
21	90767	Washer screw
30	369054	Bracket



Lavadora Kenmore 11072981810


Guía	N.P.	Descripción
31	339607	Screw
32B	378327	Panel
34	279255	Washer control knob clip
35	355519	Washer timer knob
36	365559	Dial
38A	352089	Connector (black)
38B	352090	Block (white)
41	94612	Connector
42	94611	Plug
43	596797	Dryer terminal connector
44	94614	Terminal
46	90016	Washer Wire Harness Retainer
47	98997	Clip
48	689559	Washer push nut
53	358709	Harness
56	3184020	Wire
61	357213	Washer lid hinge bumper
64	357695	Ring
65	94696	Plug
66	94697	Cap
69	353244	Washer water-level pressure switch

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Lavadora Kenmore 11072981810





Lavadora Kenmore 11072981810


Guía	N.P.	Descripción
2	356138	Hose clamp
3	353096	Clamp
4	132848	Screw
5	22965	Ground strap
6	364089	Ground wire
7	96743	Washer drain hose
8	285452	Washer fill hose seal and screen
9	76314	Washer fill hose
10	16123	Washing machine washer
11	3351614	Washer screw, #10-24 x 3/8-in
12B	357335	Panel
13	681414	Dishwasher screw
14	96160	Washer water inlet valve screen
17	18776	Dryer top panel clip
27	359364	Washer leveling leg clip
28	359059	Link
29	358594	Washer leveling leg
30	18849	Hinge pad
32A	357871	Washer power cord
32B	83742	Power cord
33	358277	Washer water inlet valve assembly
34	357977	Spring
35	358336	Washer snubber pad
36	98669	Dryer cabinet panel guide
37	681414	Dishwasher screw
38	367594	Washer leveling leg, front
39	WP681414	Dishwasher screw
40	358805	Connector



Lavadora Kenmore 11072981810

Guía	N.P.	Descripción
41	351395	Clip
42	90876	Thread-forming screw, 8-pack
43	98853	Screw
44	365956	Relay

PUMP PARTS



C2
F72981110

Guía	N.P.	Descripción
1	358036	Washer drain pump
2	273556	Thread-forming screw, 8-pack
3	96175	Sleeve
4	96266	Spring
2	355538	Lever
13	96264	Rod
15	96265	Wick oil