


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones Electrodomesticas



LAVADORA 1CWTW4815EW1





LAVADORA 1CWTW4815EW1

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10807862	Installation Instructions
	W10807906	Use and Care Guide
	W10786922	Quick Start Guide
	W10740624	Tech Sheet
2		Top
	W10686433	White
3		Assembly, Lid and Bumper
	W10251302	White
4	9724509	Bumper, Lid
5	9740848	Screw
6	91770	Hinge, Lid

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10119872	Screw
8		Strike, Lid Lock
	W10714899	White
9	W10273971	Screw
10	W10192089	Dispenser, Bleach
11	W10280024	U-Bend, Drain Hose
12	21258	Bearing, Lid Hinge
13	90016	Clip, Harness
14	W10682535	Latch, Lid Lock Assembly
15	3400076	Screw
16	W10250884	Panel, Rear


<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
17		Cabinet
	W10478060	White
18	W10215098	Brace, Cabinet Top - Front
19	W10512626	Brace, Cabinet Top - Rear
20	1157158	Screw
21	356138	Clamp, Hose
22	W10397994	Foot, Leveling
23	W10339879	Tie, Cable
24	W10221546	Hose, Outer Drain Assembly
25	W10676061	Cover, Harness

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

LAVADORA 1CWTW4815EW1



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

LAVADORA 1CWTW4815EW1

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10774525	Panel, Console
2	8536939	Clip, Spring
3		End Cap (Left)
	W10520782	White
4		End Cap (Right)
	W10520780	White
5	8312709	Clip, Console
6	W10885801	Control Unit Assembly, Machine and Motor
7	W10552335	Panel, Console Rear Cover
8	1157158	Screw
9	W10213953	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
10	90767	Screw
11	W10737739	Cord, Power
12	3400076	Screw
13		Knob, Timer
	W10576634	White/Metallic
14		Assembly, Control Knob
	W10576636	White/Metallic
15	W10285512	Switch, Rotary Encoder (4 Position)
16	W10694682	Harness, Upper
17	W10789992	Inlet Assembly, Water
18	W10678671	Harness, Valve


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
19	W10598040	Grommet, Push to Start
20	W10596298	Button, Push to Start
21	W10285511	Switch, Rotary Encoder (2 Position)
22	W10786100	Harness, Jumper
23	W10339680	Cable Tie

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

LAVADORA 1CWTW4815EW1



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

LAVADORA 1CWTW4815EW1

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10795104	Dispenser Assembly, Fabric Softner
2	W10003790	Screw and Washer
3	3949550	Washer
4	63235	Agitator Assembly
5	W10531289	Ring, Tub
6	21366	Nut, Spanner
7	W10554251	Basket Assembly
8	389140	Block, Basket Drive

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
9	W10238320	Tub (Includes Tub Seal)
10	W10006371	Seal, Tub
11	8533928	Screw
12	W10215093	Filter, Drain Pump
13	W10821956	Damper Assembly, Tub Suspension (Set Of 4-Includes Suspension Bushings and Suspension Balls)


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
14	W10678684	Harness, Lower (includes pressure hose)
15	8572540	Hose Pressure Switch
16	W10005430	Clamp, Cable
17	8533943	Screw

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

LAVADORA 1CWTW4815EW1





LAVADORA 1CWTW4815EW1

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10465543	Pump Assembly, Drain
2	W10004910	Screw
3	W10763078	Hose, Inner Drain Assembly
4	8317496	Clamp, Hose
5	W10473144	Gearcase Assembly

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
6	W10249633	Screw
7	W10677715	Motor, Drive
8	W10094780	Screw
9	W10006384	Belt, Drive
10	W10597177	Actuator, Shift
11	9741052	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
12	W10625045	Capacitor, Motor Run
13	W10427633	Shield, Pulley Cover
14	357640	Screw
15	W10721967	Splutch Kit (60Hz)

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350938	Gray Primer
	350930	White

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

WATER SYSTEM PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	285835	Connector Assembly
	285863	4' Drain Hose w/Clamp
	285834	Siphon Break Kit
	3363920	Adapter, Standpipe 2" Diameter to 1" Diameter
	DRNEXT4	Drain Hose Extension Kit

SEALER

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	285195	Sealer, Gasket (.20 Fl. Oz.) (6ml)

COUPLING

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	384496	Coupling, Hose Extension Kit

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	W10355010	Cleaner, Kitchen & Appliance
	W10135699	Affresh Odor Remover
	8212546RP	Inlet Hoses, 4 Ft. (Two Black Hoses W/ Straight Ends and 4 Rubber Washers)
	8212641RP	Inlet Hoses, 5 Ft. (Two Black Hoses W/ Straight Ends and 4 Rubber Washers)
	8212545RP	Inlet Hoses, 5 Ft. (One Red Hose and One Blue Hose W/ Straight Ends and 4 Rubber Washers)
	8212487	Inlet Hoses, 5 Ft. (Two Braided Hoses W/Straight Ends and 4 Rubber Washers)
	8212638RP	Inlet Hoses, 6 Ft (Two Braided Hoses W/ One Straight End and One 90 Degree End and 4 Rubber Washers)
	8212656RP	Inlet Hoses, 10 Ft. (Two Black Hoses W/ Straight Ends and 4 Rubber Washers)
	285448A	Hose Washers (Package of 4)
	285452A	Hose Screen (Package of 2)
	8212526	Washer, Drip Tray Hose, Water Inlet
	W10194210	Cold Water
	W10194211	Hot Water
	W10242307	Washer, Hose
	3976300	Washer, Inlet Hose
	W10810281	Washer, Filter
	3357450	Washer, Hose Adapter
	W10269488	Connector, Hose -"Y"