

**KitchenAid®**

**6 QT. STAND MIXER  
COSTCO - BOWL LIFT**

**MODELS:**

KSM6573CWH2 (White)

KSM6573COB2 (Onyx Black)

KSM6573CER2 (Empire Red)


KSM6573CCU2 (Contour Silver)

4KSM6573CWH2 (White)

4KSM6573COB2 (Onyx Black)

4KSM6573CER2 (Empire Red)


4KSM6573CCU2 (Contour Silver)



<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Motor Housing
	9703311	White
	9705296	Onyx Black
	9705300	Empire Red
	W10327951	Contour Silver
2		Trim Band
	W10410026	Dark Platinum
3		Lower Gearcase
	W10234488	White
	W10410012	Onyx Black
	W10410011	Empire Red
	W10410010	Contour Silver

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
4		Planetary
	W10420628	White
	W10410018	Onyx Black
	W10419426	Empire Red
	W10410016	Contour Silver
5		Bowl Support and Pins
	9707633	White
	9707876	Onyx Black
	9707883	Empire Red
	W10410004	Contour Silver

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
6		Column and Pins
	9703673	White
	9705320	Onyx Black
	9705324	Empire Red
	W10328003	Contour Silver
7		Base and Foot Assembly
	9703690	White
	9705344	Onyx Black
	9705348	Empire Red
	W10328017	Contour Silver




<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Motor Housing (Refer to Color Variation Parts Page)	8	3400617	Screw	16	9703438	Ring, Retaining
			9	3400814	Screw	17	9706090	Washer
2	9703315	Cover, Attachment Hub	10	W10517938	Motor, 120 Volt Assembly	18	W10234643	Gear, Pinion
3		Trim Band (Refer to Color Variation Parts Page)	11	3400200	Screw	19	9707223	Pin, Retaining
4	W10351843	Screw	12	W10409930	Control Assembly	20	8533910	Washer
5	W10305968	Holder, Control	13	W10234531	Pin, Groove	21	9708191	Shaft, Agitator
6		Lower Gearcase (Refer to Color Variation Parts Page)	14		Cord, Power	22	9703680	Clip, Retaining
				W10234520	White	23		Thumb Screw
7	W10234493	Gear, Ring and Plate Assembly		W10338492	Black		W10417014	Chrome
			15		Planetary Assembly (Refer to Color Variation Parts Page)	24	9704677	Pin, Groove

1



Literature Parts



<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	9	9708649	Foot	20	9703426	Cam, Adjusting
	W10410027	Use and Care Guide, U.S.	10	9703307	Ring, Retaining	21	3400863	Screw
3	W10177650	Bowl, 6 Qt.	11	9706787	Rod, Bowl Lift	22	9706788	Handle, Bowl Lift
4	240185	Pin, Retaining Bowl	12	9237	Spring, Lift Rod	23	3400200	Screw
5	9703474	Clip, Bowl Retainer	13	9703439	Washer			
6	3400018	Screw	14	8533907	Nut			
7		Bowl Support and Pins (Refer to Color Variation Parts Page)	15		Column and Pins (Refer to Color Variation Parts Page)			
			16	W10401173	Beater, Flat			
8		Base and Foot Assembly (Refer to Color Variation Parts Page)	17	W10335442	Hook, Dough			
			18	9706885	Arm, Bowl Lift			
			19	9704309	Whip, Wire			