


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool 7ED2HTQXSQ00



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Refrigerador Whirlpool 7ED2HTQXSQ00

No. Ilus.	DESCRIPCIÓN	No. de Parte
2	Front Roller (2)	2174748
3	Screw (2)	3400517
4	Roller (Rear) (2)	2196236
5	Screw (2)	489427
6	Clip, Grille	2155013
7	Plate, Screw (2)	2304249
9	Shim	2209697
12	Hinge Top (FC)	2203770
13	Hinge, Top (RC)	2203771
14	Screw	488500
15	Hinge Cover (White)	2203407W
	Hinge Cover (Biscuit)	2203407T
	Hinge Cover (Black)	2203407B
16	Hinge Bottom (2)	2217075
18	Screw (4)	3400113
20	Screw	3400858
21	Filler, Wrapper (White)	2201014
	Filler, Wrapper (Biscuit)	2200926
	Filler, Wrapper (Black)	2201014
22	Grille (White)	2198469W
	Grille (Biscuit)	2198469T
	Grille (Black)	2198469B
23	Screw	489497
25	Screw (2)	3400103
27	Screw	489290
35	Screw	489464
41	Drain Fitting	940139

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool 7ED2HTQXSQ00


<u>No. Ilus.</u>	<u>DESCRIPCIÓN</u>	<u>No. de Parte</u>
42	Extension Tube	1108438
43	Clip, Drain Tube	1108439
47	Cover, Unit	2214543
48	Cabinet (Not A Serviceable Part)	***
49	Hinge Cover (White)	2203408W
	Hinge Cover (Biscuit)	2203408T
	Hinge Cover (Black)	2203408B
50	Screw	8281227
52	Clamp, Service Cord	489348
53	Screw	489084
54	Door Closer, Lower Cam (2)	2155311
55	Screw (2)	489483

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool 7ED2HTQXSQ00



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool 7ED2HTQXSQ00


No. Ilus.	DESCRIPCIÓN	No. de Parte
2	Escutcheon, Meat Pan Control	***
3	Slide, Meat Pan Control	***
4	Louver	2257741
5	Bracket, Dual Crisper Light	2256035
6	Clip (2)	2311612
7	Screw (2)	489290
12	Wire Harness, Crisper Light	2311637
24	Air Diffuser Assembly	2209753
25	Air Diffuser Cover	2152019
26	Cover, Conduit	2150331
27	Screw	486298
29	Socket	2162085
31	Reservoir	2256126
33	Light Bulb	527949
34	Light Lens	2209769
37	Screw (2)	488280

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool 7ED2HTQXSQ00



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Refrigerador Whirlpool 7ED2HTQXSQ00


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Shelf, Snack Pan	***
2	Glass, Cover	2174150
3	Cover, Crisper	2209698
4	Trim, Pan	***
5	Glass, Cover	2179259
6	Deflector	***
7	Trim, Meat Pan	***
8	Cover, Meat Pan	2311726
9	Slide, Humidity Control	***
10	Crisper Pan	2188661
11	Meat Pan	2188665
12	Stud Assembly	2196485
13	Screw	3400894
14	Housing, Humidity Control	***
15	Stud Assembly	2196483
16	Screw	8281158
17	Snack Pan	***
18	Trim, Handle	***
19	Shelf Assembly, Spillguard	2309561
21	Egg Bin	***

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool 7ED2HTQXSQ00



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Refrigerador Whirlpool 7ED2HTQXSQ00


<u>No. Ilus.</u>	<u>DESCRIPCIÓN</u>	<u>No. de Parte</u>
2	Slide, Ice Door	1115380
3	Door, Ice Compartment	2171712
4	Shelf, Wire	2309634
5	Screw	489478
6	Clip, Air Duct (2)	842534
7	Support, Stud (4)	2196206
11	Freezer Bin	2309758
19	Switch, Rocker Arm	1115373
22	Shelf, Wire	2309633
28	Slide, Container (Left Side)	1119237
	Slide, Container (Right Side)	1119293
29	Screw (4)	489100
30	Screw	3400893
31	Shelf, Wire	2309632

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool 7ED2HTQXSQ00



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Refrigerador Whirlpool 7ED2HTQXSQ00

<u>No. Ilus.</u>	<u>DESCRIPCIÓN</u>	<u>No. de Parte</u>
1	Bracket, Motor	2183728
2	Motor, Dispenser	2188242
3	Soleniod Assembly	2152713
4	Guide, Solenoid	2149100
5	Screw (2)	489355
7	Wiring Assembly, Ice Dispenser	2311639
8	Screw (6)	489399
9	Coupling, Motor	2205716
10	Screw	489478
11	Socket, Light	2162085
14	Ice Container	2196089
18	Spacer, Step (3)	1119005
19	Spacer, Flat (2)	1119007
20	Blade, Rotary	2257022
21	Blade, Rotary	2257023
22	Blade, Rotary	2257024
23	Washer, Plain	489235
24	Blade, Fixed (2)	1119009
25	Block, Blade	2157405
26	Roll Pin	489229
27	Auger	2196295
28	Drum	2209781
30	Floating Baffle	2171682
31	Nut, Bearing	1119018
32	Control Arm	2155231
33	Spring, Return	1119020
34	Retainer Clip, Rod	1119021

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool 7ED2HTQXSQ00


<u>No. Ilus.</u>	<u>DESCRIPCIÓN</u>	<u>No. de Parte</u>
35	Screw	488886
37	Housing, Crusher	2180348
38	Deflector, Ice	1119017
39	Washer, Plain	489234
40	Retainer Ring	489236
44	Front Cover, Ice Container	2171709
45	Light Bulb	527949
46	Light Lens, Dispenser	2171706
100	Ice Container (Complete)	2209779

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool 7ED2HTQXSQ00



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Refrigerador Whirlpool 7ED2HTQXSQ00


<u>No.illus.</u>	<u>DESCRIPCIÓN</u>	<u>No. de Parte</u>
1	Refrigerator Door (Includes Item 6)	2309926W
2	Door, Compartment	2256101
3	SCREW	8533920
4	Door Bin (3)	2193353W
6	Door Gasket, Magnetic	2309600
7	Handle (Includes 3) (White)	2186649W
8	Thimble-Top	2308091
9	Clip	2193353W
11	Door Closer, Upper Cam	2182178
12	Screw	489420
13	Bracket, Door Stop (Black)	2206629
15	Nameplate	2255121
19	Screw (4)	489491
22	Trivet	***
23	Screw	3400012

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool 7ED2HTQXSQ00



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Refrigerador Whirlpool 7ED2HTQXSQ00


No.Illus.	DESCRIPCIÓN	No. de Parte
1	Freezer Door	2309977W
2	Handle (Includes 4) Acero	2186649W
2a	Perno handle	***
2b	STUD-HANDLE, MOUNTING	***
2c	Screw Stud-handle 8-15 X .813 HW A	***
3	Thimble-Top	2182181
4	SCREW	489491
5	Clip	2193353W
6	Trivet (4)	2309717
7	Screw	3400012
8	Door Gasket, Magnetic	2159072
9	Trim, Door Shelf	2209680
10	Screw	488500
11	Wire Harness	2311642
12	Door Closer, Upper Cam	2182179
13	Screw	489420
14	Bracket, Door Stop (Chrome)	2206629
	Bracket, Door Stop (Black)	2206629
22	Screw (4)	489491
23	Connector	2154473

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool 7ED2HTQXSQ00



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Refrigerador Whirlpool 7ED2HTQXSQ00


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Housing, Dispenser (Not Serviced)	***
2	Screw	3196537
3	Retainer, Levers	2194719
4	Spring, Torsion	2180209
5	Pin	2196195
6	Door, Ice	2180353
7	Door Mechanism Assembly	2304355
8	Mechanism Delay	2205686
9	Grille, Overflow (White)	2206671W
	Grille, Overflow (Biscuit)	2206671T
	Grille, Overflow (Black)	2206671B
10	Water Fitting Assembly	8201537
11	Lever, Ice Dispenser (White)	2195089W
12	Guide, Ice	2180224
13	Lamp Holder	2180200
14	Switch (2)	2162361
15	Bracket, Control	2180226
16	Bulb, Light	3406124
17	Lever, Water Dispenser (White)	2195090W
	Lever, Water Dispenser (Biscuit)	***
	Lever, Water Dispenser (Black)	***
18	Switch Assembly	***
19	Overlay, Front Cover	***
20	Wire Assembly	2311640
21	Front Cover, Housing	***
22	Screw	489000
23	Front Cover Assembly (18, 19, 20 & 21)	2311691W

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool 7ED2HTQXSQ00



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Refrigerador Whirlpool 7ED2HTQXSQ00

No. Ilus.	DESCRIPCIÓN	No. de Parte
2	Fan, Blade	8201630
3	Condenser Assembly	2223953
4	Screw	489464
5	Clip, Wire	2208280
6	Screw (2)	8533993
7	Grommet	509812
8	Sleeve	2161302
9	Screw	488687
10	Wire, Capacitor (Production)	2311653
	Wire, Capacitor (Service)	2172890
12	Cover, Terminal (Production)	2217635
	Cover, Terminal (Service)	4387731
13	Overload (Production)	2162216
	Overload (Service)	2187145
14	Tube Suction	2220642
15	Clip, Condenser(2)	2311725
17	Capacitor (Production)	2255130
	Capacitor (Service)	999532
18	Tube, Condenser to Heat Loop	2261599
19	Relay (Production)	2262182
	Relay (Service)	2262185
21	Screw	489478
22	Evaporator	2188822
23	Clamp	2161324
24	Fan, Motor	2188874
25	Tray, Evaporator	1105523
26	Heat Shield	2217195

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool 7ED2HTQXSQ00


No. Ilus.	DESCRIPCIÓN	No. de Parte
27	Drier (Production)	2201796
	Drier (Service)	4387019
28	Compressor (I.10, 12, 13, 17, 19 & 27)	2255011
30	Unit Mounting Frame	2160501
31	Unit, Harness (Includes Power Cord)	2311735
32	Fan, Motor Bracket	2181929
33	Heater, Defrost	2188174
34	Clip (2)	2161324
37	Screw (4)	489373
39	Grommet (4) (Production)	1100826
	Grommet (4) (Service)	4387558
40	Screw	489340
41	Air Baffle	2196202
42	Clip, Heat Shield	2155547
43	Unit Cover, Bottom	2182057
44	Clip	489396
48	Unit Mounting Rail	2149718
49	Screw	8281232
50	Guard, Fan	1105612
52	Strap	2263990
53	Screw	489427
63	Union	2209709

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool 7ED2HTQXSQ00



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Refrigerador Whirlpool 7ED2HTQXSQ00


No. Ilus.	DESCRIPCIÓN	No. de Parte
1	Screw	489084
2	Chute, Water	2209774
5	Clip, Fuse	628379
7	Tube, Water	2304859
9	Screw	489478
10	Filter Valve Asm	2188778
14	Tube Clip	489385
18	Cover	2174155
19	Screw (2)	488649
20	Mold & Heater Assembly	628228
22	Cup, Water Fill	628356
23	Ejector	627843
24	Ice Striper	2182124
25	Support	2195914
26	Retainer, Thermostat	2315522
27	Thermostat	627985
28	Screw	8533917
30	Screw	489276
31	Shut Off Arm	2304354
33	Bracket	628320
35	Module Assembly	8201515
36	Screw	488208
37	Motor (Not Serviced, Order 35)	***
100	Complete Icemaker Assembly	4317943

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool 7ED2HTQXSQ00



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Refrigerador Whirlpool 7ED2HTQXSQ00


<u>No. Ilus.</u>	<u>DESCRIPCIÓN</u>	<u>No. de Parte</u>
1	Control Box	2311619
2	Mounting Bracket	2311611
3	Screw	3196537
4	Light Switch	2219875
5	Thermostat	2198202
6	Defrost Timer	482493
7	Screw (2)	489398
9	Screw	627068
11	Cam Assembly	2182195
12	Bearing Body	1110560
13	Screw (2)	487869
14	Damper Control	2196062
15	Pivot Arm	1110559
17	Light Socket	2162085
18	Barrier Tube, Thermostat	2196001
19	Light Bulb	527949
20	Control Box Harness	2311636
21	Clip, Wiring	1115374
22	Clip, Wiring	1115375
23	Connecting Rod	2311631
24	Fastener, Push-On	489285
26	Thermostat Knob	2311614
27	Control Knob	2311615
29	Spring Washer	489203

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Refrigerador Whirlpool 7ED2HTQXSQ00



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Refrigerador Whirlpool 7ED2HTQXSQ00

<u>No.Illus.</u>	<u>DESCRIPCIÓN</u>	<u>No. de Parte</u>
1	Fan Scroll	2182119
2	Retainer, Fan Motor	2155590
3	Diffuser, Air Duct	2149544
4	Bi-Metal, Defrost	2315504
5	Air Duct Freezer	4388357
6	Air Scoop	2161231
7	Fan Motor	2149299
8	Fan Blade	2169142
9	Gasket, Evaporator Cover (2)	2304241
10	Fan Grommet (2)	2176759
11	Duct, Icemaker	2182146
12	Harness, Fan Evaporator (Includes 4)	2187826
13	Gasket, Fan Scroll	2155788
16	Gasket	2203875
17	Cover, Evaporator (Includes 9)	2203840
18	Screw (6)	8281159
21	Screw	489478
22	Support, R.S	2203595
23	Support, L.S	2203596