


Distribuidor Autorizado


SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Refrigerador Whirlpool 7GB18DKXIB00




Refrigerador Whirlpool 7GB18DKXJB00





Refrigerador Whirlpool 7GB18DKXJB00




Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Refrigerador Whirlpool 7GB18DKXJB00




Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Refrigerador Whirlpool 7GB18DKXIB00




Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Refrigerador Whirlpool 7GB18DKXJB00




Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Refrigerador Whirlpool 7GB18DKXIB00




Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Refrigerador Whirlpool 7GB18DKXIB00






Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Refrigerador Whirlpool 7GB18DKXIB00





## Refrigerador Whirlpool 7GB18DKXJB00

<b>GABINETE</b>		
<b>1</b>	Literature Parts (Tech Sheet)	LIT8170600
	Literature Parts (Use & Care Guide)	LIT8170601
<b>3</b>	Plug, Button (3) (White)	4344209
	Plug, Button (3) (Biscuit)	8170487
	Plug, Button (3) (Black)	4344208
<b>4</b>	Insulation, Foot (Left Side)	8170534
	Insulation, Foot (Right Side)	8170576
<b>5</b>	Roller, Front Assy.	8170374
<b>6</b>	Clip, Grille	4344155
<b>7</b>	Pin, Center Hinge	4344177
<b>8</b>	Shim (Black)	4344188
	Shim (White)	4344187
<b>10</b>	Hinge Cover, Bottom (White)	8170573
	Hinge Cover, Bottom (Biscuit)	8170571
	Hinge Cover, Bottom (Black)	8170572
<b>11</b>	Screw	4344186
<b>13</b>	Shim, Hinge Top	8170540
<b>14</b>	Screw	4344198
<b>15</b>	Hinge, Center	8170535
<b>16</b>	Shim, Center Hinge (White)	4344427
	Shim, Center Hinge (Almond)	4344426
	Shim, Center Hinge (Black)	4344425
<b>19</b>	Hinge Bottom (White)	8170575
	Hinge Bottom (Black)	8170574
<b>20</b>	Screw	8170455
<b>21</b>	Pin, Bottom Hinge	4344178
<b>22</b>	Grille (White)	8170530
	Grille (Biscuit)	8170528



## Refrigerador Whirlpool 7GB18DKXJB00

<b>GABINETE</b>		
	Grille (Black)	8170529
<b>23</b>	Screw	4344267
<b>24</b>	Plug, I/M	4344264
<b>25</b>	Screw	4343759
<b>26</b>	Wire Cover	4344257
<b>27</b>	Back Cover	8170375
<b>28</b>	Harness, Control	8170520
<b>30</b>	Cover, Unit	8170377
<b>31</b>	Screw	8170373
<b>32</b>	Power Cord	4344263
<b>33</b>	Grommet	8170566
<b>34</b>	PLug	4344260
<b>38</b>	Clip	8170435
<b>39</b>	Clip	4344265
<b>40</b>	Shim, Hinge (White)	4354515
	Shim, Hinge (Black)	4354516
<b>41</b>	Hinge Top	8170539
<b>42</b>	Hinge Cover (White)	8170538
	Hinge Cover (Biscuit)	8170536
	Hinge Cover (Black)	8170537
<b>44</b>	Screw	8170380
<b>45</b>	Screw	4344293
<b>46</b>	Foot Break	4344298



## Refrigerador Whirlpool 7GB18DKXB00

LINER REFRIGERATOR		
<b>1</b>	Refrigerator Door Panel (White)	8170581
	Refrigerator Door Panel (Biscuit)	8170579
	Refrigerator Door Panel (Black)	8170580
<b>2</b>	Interior Panel	8170583
<b>3</b>	Door, Compartment	8170582
<b>5</b>	Shelf Bin (Deep)	8170586
<b>8</b>	Door Gasket, Magnetic (White)	8170519
	Door Gasket, Magnetic (Black)	8170517
<b>9</b>	Door Handle (White)	8170477
	Door Handle (Biscuit)	8170476
	Door Handle (Black)	8170475
<b>12</b>	Shelf Bin (4)	8170585
<b>13</b>	Trim, Handle (White)	8170480
	Trim, Handle (Biscuit)	8170479
	Trim, Handle (Black)	8170478
<b>14</b>	Trim, Door Shelf	8170584
<b>16</b>	Plug-Trim	4343810
<b>17</b>	Stop, Door (White)	4344463
	Stop, Door (Biscuit)	8170494
	Stop, Door (Black)	4344563
<b>18</b>	Plug, Button (White)	4344535
	Plug, Button (Biscuit)	8170495
	Plug, Button (Black)	4344533
<b>19</b>	Screw	4343811
<b>21</b>	Screw	4344333
<b>22</b>	Screw	8170499
<b>23</b>	Bushing (White)	4344362
	Bushing (Black)	4344361



## Refrigerador Whirlpool 7GB18DKXJB00

LINER REFRIGERATOR		
<b>24</b>	Plug, Button (White)	4344227
	Plug, Button (Biscuit)	8170497
	Plug, Button (Black)	4344364
<b>25</b>	Nameplate (White)	4344577
	Nameplate (Biscuit)	8170486
	Nameplate (Black)	4344575



## Refrigerador Whirlpool 7GB18DKXJB00

FREEZER LINER		
<b>3</b>	Glide, Shelf (Left Side)	8170532
	Glide, Shelf (Right Side)	8170533
<b>4</b>	Light Lens	4344205
<b>5</b>	Screw	4344206
<b>6</b>	Light Socket	8170384
<b>7</b>	Clip-Ground	4343682
<b>8</b>	Screw	4344396
<b>9</b>	Light Bulb	8170385
<b>10</b>	Housing, Frz. Light	8170381
<b>11</b>	Cover, Evaporator	8170543
<b>12</b>	Screw	4344167
<b>13</b>	Washer (2)	4344211
<b>14</b>	Cover, Switch	8170341
<b>16</b>	Switch, Light	4344571
<b>17</b>	Cover, Plug	4344166
<b>18</b>	Screw	8170456
<b>19</b>	Plug, Button	4344228
<b>20</b>	Gasket, Bottom	4344216
<b>22</b>	Cover, Fan Shroud	4344388
<b>23</b>	Gasket	4344587
<b>25</b>	Evap, Fan Shroud	8170387
<b>27</b>	Fan, Evaporator	8170544
<b>29</b>	Grommet	8170388
<b>30</b>	Motor, Evaporator	8170525
<b>31</b>	Spacer	8170390
<b>32</b>	Screw (2)	8170391
<b>33</b>	Plug, Button	4344227
<b>36</b>	Screw	4343860



**Refrigerador Whirlpool 7GB18DKXJB00**

<b>FREEZER LINER</b>		
<b>37</b>	Knob, Control	4344214
<b>38</b>	Screw	4344224
<b>39</b>	Cover, Frz. Control	8170392
<b>40</b>	Screw	4343861
<b>41</b>	Thermostat	4344225
<b>43</b>	Bracket, Control	4344578
<b>44</b>	Plug, Button	4344316
<b>45</b>	Grommet	4344321
<b>47</b>	Funnel-Drain (Includes 48 & 49, seal & gasket)	4344385
<b>48</b>	Seal	4344311
<b>49</b>	Gasket	4344310



## Refrigerador Whirlpool 7GB18DKXB00

FREEZER DOOR		
<b>1</b>	Freezer Door Panel (White)	8170589
	Freezer Door Panel (Biscuit)	8170588
	Freezer Door Panel (Black)	8170587
<b>2</b>	Handle (White)	4344162
	Handle (Biscuit)	8170485
	Handle (Black)	4344160
<b>3</b>	Plug, Button (White)	4344159
	Plug, Button (Biscuit)	8170484
	Plug, Button (Black)	4344157
<b>4</b>	Screw	8170396
<b>5</b>	Interior Panel	8170592
<b>6</b>	Trim, Shelf	8170593
<b>8</b>	Door Gasket, Magnetic (White)	8170518
	Door Gasket, Magnetic (Black)	8170516
<b>10</b>	Insulation	8170591
<b>11</b>	Retainer	8170590
<b>12</b>	Door, Stop (White)	4344463
	Door, Stop (Black)	4344563
<b>13</b>	Screw	4344333
<b>14</b>	Plug, Button (White)	4344535
	Plug, Button (Black)	4344533
	Plug, Button (Biscuit)	8170495
<b>17</b>	Bushing (White)	4344362
	Bushing (Black)	4344361
<b>18</b>	Plug, Button (White)	4344227
	Plug, Button (Black)	4344364
	Plug, Button (Biscuit)	8170497
<b>19</b>	Screw	4343811





## Refrigerador Whirlpool 7GB18DKXJB00

SHELF		
<b>1</b>	Roller	4344093
<b>3</b>	Ice Bucket	8170561
<b>4</b>	Shelf, Frz. Wire	8170563
<b>5</b>	Basket, Freezer	8170564
<b>6</b>	Handle, Basket	8170565
<b>7</b>	Track, Shelf	8170551
<b>8</b>	Shelf Assy, S/G	8170552
<b>9</b>	Meat Pan	8170548
<b>11</b>	Frame Assy, S/O	8170550
<b>12</b>	Shelf, S/G, S/O	8170549
<b>13</b>	Rack, Ice Tray	8170562
<b>14</b>	Tray, Ice Cube	4344171
<b>15</b>	Spacer	4344239
<b>16</b>	Screw	4344238
<b>17</b>	Crisper Pan	8170559
<b>18</b>	Support, Crisper Cvr	8170554
<b>19</b>	Gasket	8170555
<b>20</b>	Cover, Pan	8170558
<b>21</b>	Glass, Crisper Cover	8170560
<b>22</b>	Ladder, Center	4344322
<b>23</b>	Ladder, Side	8170577
<b>24</b>	Screw	4344396
<b>25</b>	Screw	8170578
<b>27</b>	Slide, Humidity Control	8170556
<b>28</b>	Body, Humidity Control	8170557
<b>30</b>	Screw	4344094



## Refrigerador Whirlpool 7GB18DKXJB00

<b>SEAL SISTEM</b>		
<b>1</b>	Screw	4343865
<b>2</b>	Fan, Blade	4344271
<b>3</b>	Condenser & Pan Assembly	8170515
<b>4</b>	Screw	4344599
<b>5</b>	Screw	4343691
<b>6</b>	Screw	4343860
<b>7</b>	Heat Shield	8170541
<b>8</b>	Drain Pan	8170569
<b>10</b>	Evaporator Heater	8170522
<b>11</b>	Cover	8170568
<b>12</b>	Overload	8170526
<b>13</b>	Gasket	4344587
<b>14</b>	Bi-Metal	4344231
<b>15</b>	Relay	8170527
<b>16</b>	Bracket, Timer	4344278
<b>17</b>	Capacitor	8170450
<b>18</b>	Shield, Capacitor	4344277
<b>19</b>	Clip, Wire	4343969
<b>20</b>	Drain Pan	8170542
<b>21</b>	Clamp	8170567
<b>22</b>	Evaporator	8170523
<b>23</b>	Dam (Right Side)	8170546
	Dam (Left Side)	8170545
<b>24</b>	Motor, Fan	8170524
<b>25</b>	Clip, Heater	4343918
<b>26</b>	Harness, Unit	8170521
<b>27</b>	Drier	4344268



## Refrigerador Whirlpool 7GB18DKXJB00

<b>SEAL SISTEM</b>		
<b>28</b>	Compressor (Includes Items 11, 12, 15, 17 & 27)	8170602
<b>30</b>	Washer	4344282
<b>31</b>	Shroud	4344554
<b>32</b>	Bracket, Fan Motor	4344272
<b>33</b>	Screw (2)	4344395
<b>34</b>	Clip, Drier	4343763
<b>35</b>	Cover, Timer	8170451
<b>37</b>	Screw	4343759
<b>38</b>	Timer, Defrost	8170404
<b>39</b>	Grommet (4)	4343845
<b>40</b>	Screw	4344562
<b>42</b>	Clip, Evaporator	4344219
<b>43</b>	Screw	4343772
<b>44</b>	Screw	4343847
<b>45</b>	Screw	4344545
<b>46</b>	Clamp	4343661
<b>48</b>	Screw	4343749
<b>49</b>	Cabinet, Brace	4344297
<b>50</b>	Screw	4344396
<b>51</b>	Axle-Roller	4344289
<b>52</b>	Roller-Rear	4344288
<b>53</b>	Screw	4344292
<b>54</b>	Plug, Button	4344287
<b>55</b>	Drain Tube	8170570
<b>58</b>	Clamp, Tube	4343777



## Refrigerador Whirlpool 7GB18DKXJB00

<b>ICE MAKER</b>		
<b>1</b>	Mold & Heater Assembly	628228
<b>2</b>	Clip	4343721
<b>3</b>	Bearing & Inlet	628356
<b>4</b>	Ejector	627843
<b>5</b>	Ice Stripper	2182124
<b>6</b>	Support	627790
<b>7</b>	Retainer, Thermostat (2)	627796
<b>8</b>	Thermostat (Also Order Cement Alumilastic)	627985 542369
<b>9</b>	Screw, (2) 10-32 x 49/64	489163
<b>10</b>	Fill Tube	8170414
<b>11</b>	Harness, Water Valve	8170413
<b>13</b>	Screw, (3)	4344397
<b>14</b>	Shutoff Arm	4344400
<b>15</b>	Wiring, Harness	4344399
<b>16</b>	Clip, Ice Maker	4343699
<b>18</b>	Cover	4344398
<b>19</b>	Module Assembly	628366
<b>20</b>	Valve, Solenoid	4344401
<b>23</b>	Clip, Thermal Fuse	628379
<b>24</b>	Screw	4344218
<b>25</b>	Compression Nut	4343704
<b>26</b>	Insert, Tube	4344402
<b>27</b>	Water Tube	4344404
<b>28</b>	Spring	4343685
<b>29</b>	Clip, Wire	4343984
<b>30</b>	Screw	4343675



## Refrigerador Whirlpool 7GB18DKXJB00

ICE MAKER		
<b>31</b>	Clip	4343703
	Ice Maker assembly	4344137
	Ice Cube Pan	2166261
	Trim, Ice Cube Pan	837122
	Coupling	4344548
	Tube Clamp	488878
	Plug, Hole	4344549
	Plug, Button	4344316