

KitchenAid®

**PANDORA BLENDER
Brazil**

MODELS:


7KSB4027MBM0 (Black Matte)
7KSB4027MCU0 (Contour Silver)
7KSB4027MPA0 (Passion Red)
7KSB4027MVB0 (Blue Velvet)
7KSB4027MWH0 (White)

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

LICUADORA 7KSB4027MPA0





LICUADORA 7KSB4027MPA0

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11279642	Lid Assembly
2	W11387671	Jar Assembly

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
3	W11396201	Pad, Jar
4	W10732366	Grip, Jar



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

LICUADORA 7KSB4027MPA0

Literature Parts





LICUADORA 7KSB4027MPA0

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W11333854	Use & Care Guide
2	W11179370	Trimband
3	W11219397	Plug, Coupler
4	W11214276	Bezel, Rotary Switch
5	697773	Screw
6	W11357978	Knob, Rotary Switch
7	W11183716	Base

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
8		Upper Base
	W11245946	Black Matte
	W11279715	Contour Silver
	W11245947	Passion Red
	W11245952	Blue Velvet / Matte Vintage Blue
	W11245949	White
9	W10276642	Screw
10	W11284908	Electronic Control

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
11	W11226930	Power Cord
12	3400617	Screw
13	W11294881	Coupler
14	W11174445	Screw, Coupler
15	3400814	Screw
16	W11211960	Seal, Motor
17	W11204699	Motor
18	W11238803	Reed Switch