

WIRING HARNESS PARTS

- 5 → [Terminal Block]
- 7 → [Terminal Block]
- 8 → [Terminal Block]
- 9 → [Terminal Block]
- 10 → [Terminal Block]
- 14 → [Terminal Block]
- 15 → [Terminal Block]
- 17 → [Terminal Block]


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



Secadora Whirlpool 7MGGW9200MW3

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8563880	Use & Care Guide
	8564135	Tech Sheet
2	8519251	Top
3	8299950	Harness, Main
4	8530587	Panel, Console
5	3394427	Clip, Harness
6	8519271	Bracket, Console
7	353424	Connector, Sensor
8	94614	Terminal
9	3936144	Plug, Terminal
10	94613	Terminal
11	3390647	Screw, 8-18 x 1/2
12	488886	Screw, 8-18 x 1/2
13	8519406	Bezel, Cycle
14	3936150	Connector, 7-Circuit
15	3395683	Connector, (Motor)
16	8281225	Screw, 8-18 x 1/2
17	2203186	Connector, 5-Circuit
18	46197020472	Knob, Assembly
19	8530589	User Interface
20	8530591	Button, Start
21	8530592	Button, Pause/Cancel

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



Secadora Whirlpool 7MGGW9200MW3

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8317340	Cover, Terminal Block	20	690997	TriRing	45	3393008	Screw, 10-16 x 1/2
2	3390814	Screw, 8-18 x 3/8	21	8066115	Cover-Plate	46	8519459	Clip, Toe Panel
3	697776	Screw, 10-32 x 5/8 (Ground)	22	8529053	Ramp, Door	50	8519207	Base, Cabinet
4	8578450	Panel, Side (R.H.)	23	8521961	Dry Rack Support	51	8562167	Front Panel
5	3394881	Switch, Broken Belt	24	693995	Screw, 8-18 x 3/8	52	696144	Strike, Door (2)
6	8521959	Dry Rack (Top)	25	8521957	Dry Rack Assembly	55	8299929	Harness, Digital Interface
7	8578437	Panel, Side (L.H.)	27	8538263	Motor Assembly 60 HZ.	56	8519273	Bracket, Control
8	3392100	Foot, Dryer	28	3398948	Wire, Jumper (Broken Belt Switch)	57	8546219	Control Board
	279810	Foot - Optional (Extended Length Package Of 2) (Not Included)	29	8578220	Pulley 60 HZ.	59	3400826	Screw, 8-18 x 3/4
9	660658	Clamp, Motor (2)	30	3387610	Belt, Drive	61	8519233	Toe, Panel
10	3387374	Spring, Idler	31	8529757	Bracket, Burner	62	8519219	Panel, Rear
11	3389420	Retainer, Idler	32	3387118	Bracket, Motor	63	692400	Nut, Push-In
12	697750	Plug, Multivent	33	3401401	Cord, Power	64	343641	Screw, 10-16 x 1/2
13	3388672	Pulley Assembly	34	49026	4" - 90 Elbow	Optional Parts Not Included		
14	3978776	Bracket, Gas Pipe	36	8563747	Exhaust Pipe & Bracket	Dryer Exhaust Kit		
15	8066120	Lever, Snap Switch	37	8563750	Exhaust Pipe (Short)	(For Side & Bottom Venting)		
16	3394081	Wire, Belt Switch	38	8563749	Exhaust Pipe (Long)	66	279818	White
17	8564132	Sound Panel	39	3388674	Idler Bracket			
18	233520	Washer, Thrust Assembly,	42	98129	Screw, 6-20 x 1 1/16			
19	8574875	Door Switch	43	3390647	Screw, 8-18 x 1/2			
			44	3387242	Seal, Front Panel			



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



Secadora Whirlpool 7MGGW9200MW3


Illus. No.	Part No.	DESCRIPTION
1	8575324	Shaft, R.H. Thread
2	3390647	Screw, 8-18 x 1/2
3	3394984	Door, Lint Screen
4	3406653	Harness, Sensor
5	3394346	Air Duct Assembly
6	697813	Seal, Outlet Housing
7	697814	Seal, Drum Front 8
	3934666	Nut, 3/8 x 16(R.H.)
9	8066086	Drum Hole Plug
10	3402841	Lens, Drum Light
11	489463	Screw, 8-18 x 1/16
12	8572105	Clip, Exhaust Pipe
13	8533971	Screw, 8-18 x 5/16
14	8529007	Plug, Rear Bulkhead
15	693995	Screw, 8-18 x 3/8
16	W10001120	Nut, 3/8-16(L.H.)

Illus. No.	Part No.	DESCRIPTION
17	8520836	Bulkhead, Rear
18	3387459	Washer, Support
19	8575325	Shaft, L.H. Thread
20	690997	Ring, Tri
21	8536973	Roller, Support
22	8563745	Exhaust Pipe
23	3394985	Housing, Outlet
24	3401850	Harness, Gas
25	697282	Complete Drum Assembly
26	97787	Screw, 11-16 x 3/4
27	697694	Seal, Drum
28	353424	Plug, 3-Way
29	90767	Screw, 8-18 x 3/8
30	8519221	Channel Bracket, Rear Bulkhead (2)
31	8519275	Bracket, Upper Rear Bulkhead
32	717252	Plug, 2-Way
33	3406124	Bulb, Light
34	3387223	Electrode, Sensor
35	3977373	Bracket, Drum Light

Illus. No.	Part No.	DESCRIPTION
36	3403634	Socket Assembly
37	697772	Wheel, Blower
38	3403498	Connector, 3-Position
39	3394986	Spring, Lint Screen Door
40	3403499	Connector, 2-Position
41	695240	Screw, 8-18 x 1/2
42	8577274	Thermistor
43	487909	Screw, 8-15 x 1/2
44	8544362	Housing, Blower
45	8066168	Lint Duct Assembly
46	8066047	Funnel, Burner
47	8573028	Thermostat, High-Limit 205°F (96°C)
48	338906	Sensor, Radiant 51
	3387230	Screw, 10-16 x 1
53	697693	Baffle, Drum
54	8519245	Bulkhead, Front
58	8299979	Grill, Outlet
59	3392519	Thermal Fuse
60	697770	Seal, Cover Plate
64	8066170	Lint, Screen

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1 AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



Secadora Whirlpool 7MGGW9200MW0

USE WITH TYPE1 – NATURAL
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES


Illus. No.	Part No.	DESCRIPTION
1	8318276	Burner Assembly 60 Hz. (Type 1) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8-32 x 7/8)
6	343641	Screw, 10-16 x 1/2
7	3389871	Base, Burner
8	3387057	Screw, 8-18 x 3/8
9		Orifice, Burner Type 1 229742 Type 4 (Butane) 234868 Type 4 (Propane)
10	8318281	Valve, Gas 60 Hz. (Complete) (Includes Pipe & Illus. #7).
11	694421	Screw, 8-32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak, Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
18	3390647	Screw, 8-18 x 1/2
20	239822	Plug, Pipe
25	3387561	Clamp, Pipe
26	3389889	Bracket, Support

Following Parts Not Illustrated

694572 Conversion Kit
(Type 1)
to Type (4) LPG).

BA-149

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



Illus. No.	Part No.	DESCRIPTION
1	8066209	Plug, Strip
2	8559709	Door Hinge Assembly
3	8534015	Screw, 10-32 x 3/8
4	9742177	Screw, 8-18 x 5/8
5	8529539	Bracket, Handle
6	8529930	Pad, Door Handle
7	8559739	Handle, Door Assembly (LH)
	8559738	Handle, Door Assembly (RH)
8	3357011	Screw, 10-16 x 1/2
9	8572960	Door Assembly (Outer)

Illus. No.	Part No.	DESCRIPTION
10	8557501	Door Assembly (Inner) (Includes Illus. 12)
11	355515	Screw, 8-18 x 11/16
12	3389441	Door Catch Assembly
14	8529540	Badge, Assembly
15	8528289	Filler Handle (LH)
	8528287	Filler Handle (RH)

Illus. No.	Part No.	DESCRIPTION
16	8559713	Cover-Hinge, Stationary (RH)
	8559712	Cover-Hinge Stationary (LH)
17	8559722	Cover-Hinge, Rotating
18	8547091	Clip, Trim Panel
19	8558683	Trim & Clip Assembly (Lower)
20	8558687	Trim & Clip Assembly (LH)
21	8558689	Trim & Clip Assembly (RH)
22	8530070	Kit, Door Reversing



Secadora Whirlpool 7MGGW9200MW0

Illus.	Part
No.	No. DESCRIPTION

PAINT, TOUCH-UP (1/2oz.)

72017 White

PAINT, PRESSURIZED SPRAY (12 oz.)

350930 White
350938 Primer, Gray

PAINT, BULK (1 qt.)

799344 White (Uncut)

ACCESSORY PARTS

8529894 Kit,
Hold Down
8541503 Kit,
Stack Assembly
80047 Kit,
Dryer Repair