


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Whirlpool 7MGX4626EZ0




Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Whirlpool 7MGX4626EZ0




Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Whirlpool 7MGX4626EZO




Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Whirlpool 7MGX4626EZO



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Secadora Whirlpool 7MGX4626EZ0

TOP AND CONSOLE

TOP AND CONSOLE		
1	Panel, Rear Console	3397545
3	Clip, Harness	3394427
4	Cap, End (L.H.)	3358019
5	Connector (Timer)	3397269
6	Clip	688805
7	Housing, Connector (Motor)	3395683
8	Cap, End (R.H.)	3358001
10	Handle & Lint Screen Assembly	349639
11	Cover, Lint Screen (Almond)	689310
12	Hinge, R.H.	339229
	Hinge, L.H.	339230
13	Screw, 8-18 x 5/8	688983
15	Screw, Hex Head	693995
16	Top (Almond)	3396023
17	Connector	353424
21	Timer Assembly (60 Hz.)	3392250
22	Connector, 2-Position (Gas Valve)	3403499
23	Connector, 3-Position (Gas Valve)	3403498
29	Screw, 8-18 x 5/16	3390646
30	Nut, Push-In (2)	357213
31	Harness, Wiring	3405113
39	Switch, Push-To-Start	3395382
48	Timer Knob Assembly	3406053
49	Knob, Push To Start	3350975
50	Receptacle, 2-Way	717252
51	Terminal, Male	94613
52	Terminal, Female	94614
53	Bracket, Control	3396293

Distribuidor Autorizado



Venta de Refacciones
Electrodomesticas

Secadora Whirlpool 7MGX4626EZ0

TOP AND CONSOLE

54	Panel, Control	3406025
70	Connector (Door Switch)	353425
72	Wire, Ground	690853
76	Screw, Console	388326

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Secadora Whirlpool 7MGX4626EZ0

CABINET		
1	Screw, 10-32 x 1/2 (External Ground)	697776
2	Screw, 10-16 x 1/2	343641
3	Clamp, Motor (W/Shield)	3404162
4	Bumper	238614
5	Cover, Block	3396795
6	Screw, Hex Washer Head	693995
7	Panel, Rear	3396805
8	Harness, Wire (Door Switch)	3405100
9	Lever, Door Switch	691581
10	Switch, Door	347207
11	Screw, 6-20 x 1-3/8	98129
13	Screw, 8-15 x 3/8	694091
14	Spring, Door (2)	692495
15	Screw, 10-16 x 1/2	3357011
16	Foot, Dryer	3392100
	Foot - Optional (Extended Not Included)	279810
18	Cabinet (Almond)	3399586
19	Clip, Ground (2)	98234
20	Lock, Front Top (2)	690363
21	Panel Front (Almond)	3395198
23	Clip, Felt Pad (2)	685203
24	Catch, Door Assembly	3398175
25	Seal, Door	3390731
26	Clip, Hinge (2)	337189
27	Screw	342043
28	Hinge, R.H.	692498
	Hinge, L.H.	692501
29	Clip, Front Panel	3394083

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Whirlpool 7MGX4626EZO

CABINET		
33	Strike, Panel	696144
35	Door, Rear	695737
36	Door, Front (Almond)	3393550
37	Handle, Door (Almond)	690271
38	Seal & Bearing Assembly	3406129
45	Cord, Power	344020
49	Plug, Front Panel (Almond)	3394976
51	Hinge, Top (2)	238088
53	Idler & Pulley Assembly	691366
56	Belt, Drive	660996
57	Base, Motor	348780
58	Bolt, 5/16-18 x 3/4	3400500
59	Pulley, 60 Hz.	3401143
62	Motor Assembly 60 Hz.	3395652
63	Clamp, Motor	660658
64	Valve, Gas 60 Hz. (Complete)	3401775
65	Ignitor	686590
66	Lock Screw & Washer (8-32 x 5/8)	3393909
67	Burner Assembly, 60 Hz.	3401771
68	Clamp, Pipe	341029
69	Kit, Conversion Type 1, 2 & 3 (LPG)	694572
70	Coil, 60 HZ. Split (3 Terminal)	694539
71	Coil, 60 Hz. (2 Terminal) (Main)	694540
73	Bracket, Coil	694538
74	Leak Limiter	694424
75	Screw, Regulator Adjustment	694423
76	Spring, Regulator	694422
79	Plug, Pipe	239822

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Whirlpool 7MGX4626EZ0

BULKHEAD		
1	Lint Chute Assembly	348368
2	Screw, 8-18 x 3/4``	3400800
3	Washer-Support	3388703
4	Seal, Lint Chute	347139
5	Screw, 8 x 3/8	90767
6	Bracket, Bulkhead	3406022
7	Fuse, Thermal	3392519
8	Screw	339554
9	Thermostat, Internal-Bias	660039
10	Wheel, Blower (Includes Illus. No. 21)	694089
11	Housing, Blower	3405016
12	Clip	3398161
13	Screw, 10-16 x 1/2	343641
14	Box, Heater	685458
15	Thermostat, 205~F (96~C)	3403140
16	Support, Heater Box	348484
17	Collar, Funnel	348516
18	Funnel, Burner	347389
21	Seal, Blower	3394196
41	Ring, Tri	690997
42	Shaft, L.H.	3399506
43	Shaft, R.H.	3399507
44	Roller, Support	3397588
46	Washer, Support	348197
47	Nut, 3/8-16	3359452
48	Bulkhead	3403491
49	Sensor, Radiant	338906
62	Ring, Bearing	692526

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Whirlpool 7MGX4626EZO

BULKHEAD

BULKHEAD		
63	Screw, 11-16 x 7/8	97787
66	Seal, Rear Drum	3406130
67	Drum Assembly	695587
68	Baffle, Drum (2)	692490
69	Bracket, Support	3394133
70	Clip	90296
71	Baffle, Drum (1)	3403636
73	Seal	339956
75	Shield, Exhaust	696302

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Secadora Whirlpool 7MGX4626EZO

BURNER		
1	Burner Assembly 60 Hz. (White Rodgers)	3401771
2	Tube, Burner	688617
3	Bracket, Ignitor	694298
4	Ignitor	686590
5	Screw & Washer (8-32 x 5/8)	3393909
6	Screw, 10-16 x 1/2	343641
7	Base, Burner	693986
8	Screw, 8-18 x 3/8 (2)	3387057
9	Orifice, Burner (Type 1)	234826
	Orifice, Burner (Type 2)	15775
	Orifice, Burner (Type 3)	15419
	Orifice, Burner (Type 4 (Butane))	229742
	Orifice, Burner (Type 4 (Propane))	234868
10	Valve, 60 Hz.	3401775
11	Screw, 8-32 x 1/2 (2)	694421
12	Bracket, Coil	694538
13	Coil, 60 Hz. (2 Terminal) (Main)	694540
14	Coil, 60 Hz.(3 Terminal) (Pilot Position)	694539
15	Leak Limiter	694424
16	Screw, Regulator Adjustment	694423
17	Spring, Regulator	694422
20	Plug, Pipe	239822
21	Pipe, Gas Supply	233273
22	Valve & Union, Shut-Off	345062
23	Pipe, Tail	3393767
24	Nut, Compression	233076
25	Clamp, Pipe	341029
	Conversion Kit to Type (4) L.P.G.	694572