


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Lavadora Whirlpool 7MLBR8444MT0





Lavadora Whirlpool 7MLBR8444MT0


<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
2	Top (White)	8271408
	Top (Biscuit)	8271410
3	Spacer, Cabinet To Top (4)	62750
4	Nut, Push-In	357213
5	Cabinet (White)	63128
	Cabinet (Biscuit)	3954777
6	Clip, Top & Cabinet & Rear Panel (2)	62780
7	Nut, Hex	680762
8	Screw & Washer, Lid Switch (2)	3356311
9	Screw, 10-24 x 3/8	3351614
10	Shield, Lid Switch	3950995
11	Switch, Lid	3950299
12	Screw, 10-16 x 1/2	308685
13	Screw, Lid Hinge Mounting (4)	355274
14	Dispenser, Bleach	3362952
15	Hinge, Lid (L.H.)	54584
16	Hinge, Lid (R.H.)	91770
17	Bumper, Lid Hinge	19119
18	Bearing, Lid Hinge (2)	21258
19	Lid (White)	285932
	Lid (Biscuit)	285933
20	Strike, Lid Switch	358684
22	Bumper, Lid (2)	9724509
28	Screw, 10-16 x 3/8 (4)	9420601
31	Clip, Harness	90016

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Lavadora Whirlpool 7MLBR8444MT0





# Lavadora Whirlpool 7MLBR8444MT0

<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
1	Washer, Water Inlet Hose (4)	16123
2	Wire, Ground	3395559
3	Hose, Water Inlet (Red)	89503
	Hose, Water Inlet (Blue)	89503
4	Nozzle-Drain Hose	3357027
5	Strap, Console (2)	8318255
6	Panel, Rear	8318407
7	Pad, Rear Panel	62747
8	Hose, Drain (4 Ft.)	285664
	Hose, Drain (9 Ft.) (Not Included)	285666
	Extension, Drain Hose (21 Inches)	285702
9	Timer, Control (50 Hz.)	3951603
10	Switch, Water Temperature	661614
11	Screw, 8-18 x 3/8	90767
12	Switch, Water Level	3366847
13	Bracket, Control	3948814
14	Cord, Power	8532158
15	Strain Relief, Power Cord	285777
16	Cap, End (L.H.) (White)	279962
	Cap, End (L.H.) (Biscuit)	8314852
17	Screw, 8-18 x 1/2	9740848
18	Valve, Water Mixing	3952164
19	Clamp, Hose	3976395
20	Clip, Capacitor	8318201
21	Clamp, Hose	596669
22	Hose, Vacuum Break	62662
23	Clamp, Hose	596669
24	Break, Vacuum	3347034



Lavadora Whirlpool 7MLBR8444MT0


<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
25	Edge Protector	3367669
26	Assembly, Drain Hose	8317940
27	Clamp, Hose	356138
28	Capacitor	661606
29	Screw, 10-16 x 3/8	9420601
30	Clamp, Hose	616099
31	Clamp, Hose	285655
32	Hose, Pump To Tub	285871
36	Screw, Timer Mounting	3400818
37	Screw, Ground	3179795
39	Panel, Console (White)	8539613
	Panel, Console (Biscuit)	8539614
41	Clip, Grounding	357572
44	Knob, Timer (White)	8271345
	Knob, Timer (Biscuit)	8271347
45	Dial, Timer (White)	8271351
	Dial, Timer (Biscuit)	8271370
47	Knob, Control (White)	8271339
	Knob, Control (Biscuit)	8271348
49	Screw, 8-18 x 1.25 (Panel to Top)	388326
50	Screw, 10-24 x 3/8	3351614
51	Cap, End (R.H.) (White)	279962
	Cap, End (R.H.) (Biscuit)	8314851
55	Clamp, Drain Hose	3357331
58	Shield, Inlet Valve	8314879
59	Clip, Harness	8528351
60	Harness, Wiring	3956527

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Lavadora Whirlpool 7MLBR8444MT0





## Lavadora Whirlpool 7MLBR8444MT0


<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>1</b>	Dispenser	63580
<b>2</b>	Screw & Washer (5/16-24 x 1)	285009
<b>4</b>	Agitator	64214
<b>5</b>	Tub Ring	3360611
<b>6</b>	Gasket, Tub Ring	3359586
<b>7</b>	Clip, Balance Ring (8)	8519815
<b>8</b>	Balance Ring	3956205
<b>11</b>	Screw (2)	63027
<b>12</b>	Nut, Spanner	21366
<b>13</b>	BASKET	3956207
<b>14</b>	Tub	63125
<b>15</b>	Block, Basket Drive	389140
<b>16</b>	Gasket, Centerpost	383727
<b>17</b>	Hose, Pressure Switch	353244
<b>20</b>	Extention, Agitator	64210
<b>22</b>	Clip, Agitator	3354845
<b>23</b>	Washer, Agitator	3355921
<b>26</b>	Washer	3949550

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Lavadora Whirlpool 7MLBR8444MT0







Lavadora Whirlpool 7MLBR8444MT0


<b>No.Illus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
1	Brake & Drive Tube (Complete)	285792
2	Washer, Spin Tube Thrust	63292
3	Ring, Spin Tube Support	62697
4	Ring, Retainer	285353
5	Clutch (Complete)	285785
6	Band & Lining, Clutch (Includes Illus. 7 & 8)	285790
7	Cap, Clutch Spring (2)	62646
8	Spring, Clutch	3946792
9	Gearcase (Complete)	8532118
10	Screw, Gearcase To Base (3)	3400516
11	Plate, Motor Mount To Gearcase	62611
12	Grommet, Motor (4)	62691
13	Coupling, Motor And Isolation	285753
14	Shield, Motor	3946532
16	Screw	3400516
17	Retainer, Motor (2)	3349637
18	Shield, Tub To Motor	3362316
19	Motor, Main Drive	389248
20	Switch, Main Drive Motor	3952056
21	Retainer, Pump (2)	62700
22	Pump (Complete)	3363394
25	Screw (2) 10-16 X 5/8	273556
26	Clip, Anti-Rattle	3355454

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Lavadora Whirlpool 7MLBR8444MT0






## Lavadora Whirlpool 7MLBR8444MT0

<b>No.illus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>1</b>	Screw, Bracket Mounting (10-32 x 5/8)	3400076
<b>2</b>	Bracket, Spring Outer (2)	64067
<b>3</b>	Spring (3)	63907
<b>4</b>	Support & Brake, Tub	3362087
<b>5</b>	Bracket, Spring Outer (L.F.)	64065
<b>6</b>	Link, Leveling Mechanism (2)	63138
<b>7</b>	Spring, Leveling Mechanism	8316845
<b>8</b>	Pin, Knurled	62837
<b>9</b>	Foot, Rear (2)	285244
<b>13</b>	Bearing, Centerpost (2)	359398
<b>14</b>	Seal, Centerpost (3)	359449
<b>15</b>	Spring, Counterweight	388492
<b>16</b>	Pad, Plate	285219
<b>17</b>	Plate, Suspension (Includes Illus. 16)	3946509
<b>18</b>	Pad, Base	285744
<b>19</b>	Base Assembly ( 6, 7, 8, 9, 16, 17, 18 & 26)	285459
<b>21</b>	Nut, Lock (3/8-16) (2)	3359452
<b>22</b>	Foot, Front (2)	389102
<b>23</b>	Seal, Centerpost (2)	356934
<b>24</b>	Centerpost Bearing Kit (Inc. 13, 14 & 23)	285203
<b>25</b>	Ring, Sound Deadening	63134
<b>26</b>	Retainer, Suspension Spring	63806

Lavadora Whirlpool 7MLBR8444MT0






## Lavadora Whirlpool 7MLBR8444MT0

<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>1</b>	Clip, Harness	3349557
<b>2</b>	Clip, Harness	388498
<b>3</b>	Clip, Harness	8528351
<b>4</b>	Clip, Harness	3348535
<b>5</b>	Clip, Harness	90016
<b>6</b>	Clip, Harness	8281256
<b>7</b>	Retainer, (Suds Models)	389379
<b>8</b>	Timer, Block Disconnect (White)	352090
<b>9</b>	Timer, Block Disconnect (Black)	352089
<b>10</b>	Receptacle, (Lid Switch)	62889
<b>11</b>	Plug, Terminal (3-Way) (Power Cord)	353424
<b>12</b>	Block, Disconnect (Motor 2 Speed)	62505
<b>13</b>	Block, Disconnect (Motor 3 Speed)	3348075
<b>14</b>	Block, Disconnect (Use Term. 352088)	3347243
<b>15</b>	Protector	63523
<b>16</b>	Connector (2-Way) (Use Term.94614)	717252
<b>17</b>	Plug, Terminal (4-Way)	387566
<b>18</b>	Clip, Harness	3352944
<b>19</b>	Block, Disconnect (12-Way) (Timer)	3390423
<b>20</b>	Receptacle (6-Way) (Use Term. 94613)	3347730
<b>21</b>	Plug, Terminal (12-Way)	388818
<b>22</b>	Timer, Block Disconnect (Black) (Amp)	3369366
<b>23</b>	Connector, Etc	3349494
<b>24</b>	Connector, Relay (Use Term.308569)	60687
<b>25</b>	E.T.C. Control	3955728
<b>26</b>	Connector (T.P.A.) (Lid Switch)	3948617
<b>27</b>	Connector (T.P.A.) (Pressure Switch)	3360056
<b>28</b>	Block, Connector (Cold Valve)	3354925
<b>29</b>	Block, Connector (Hot Valve)	3354926
<b>30</b>	Connector (6-Circuit) (Temp. Switch)	3948615

Lavadora Whirlpool 7MLBR8444MT0





Lavadora Whirlpool 7MLBR8444MT0


<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>1</b>	Brake And Drive Tube (Complete)	285792
<b>2</b>	Ring, Thrust	62658
<b>3</b>	Seal, Oil	91939
<b>4</b>	Seal, Drive Tube	356427
<b>5</b>	Spacer, Drive Tube	356937
<b>6</b>	Tube, Basket Drive (Inc. 3, 4, 5 & 9)	64208
<b>7</b>	Ring, Retaining	64035
<b>8</b>	Brake Shoe	285438
<b>9</b>	“T” Bearing, Spin Tube	62703
<b>10</b>	Cap, Brake Spring (2)	285658
<b>11</b>	Spring, Brake	62647
<b>12</b>	Sleeve, Brake Spring	285658
<b>13</b>	Cam, Brake Release	661516
<b>14</b>	Sleeve, Cam	63022
<b>15</b>	Driver, Brake Cam	285790
<b>16</b>	Ring, Retaining	90368

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Lavadora Whirlpool 7MLBR8444MT0










## Lavadora Whirlpool 7MLBR8444MT0

<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
1	Gearcase (Complete)	8532118
2	Cover, Gearcase	285202
3	Seal, Gearcase Cover	3349985
4	Sealer, Gasket (.20 Fl. Oz.) (6 ml)	285195
5	Pinion, Spin (Includes Illus. 25)	285362
6	Seal, Spin Pinion	356427
7	Shaft, Agitator (Complete)	389387
8	Ring, Retaining (2)	90369
9	Retainer, Spring (2)	62677
10	Spring, Agitate	62676
11	Gear, Agitate (Includes 15 & 29)	285509
12	Washer, Agitate Gear	62619
13	Cam Follower (Includes 14)	285206
14	Cam, Agitate (Includes 13)	285206
15	Shaft, Agitator (Includes 11 & 29)	285509
16	Washer, Cam Thrust	62618
17	Bearing, Thrust (Includes 18)	285205
18	Ball, Bearing (Includes 17)	285205
19	Bottom and Pinion, Gearcase	285515
20	Block Tab, Terminal	3949116
21	Seal, Thrust Plug	285352
22	Screw, Gearcase Cover Mounting	3351614
23	Ring, Retaining	285765
24	Washer Kit, Thrust	285766
25	Gear, Spin	285362
26	Neutral Assembly	388253
27	Rack, Connecting	3949609
28	Actuator, Shift	62621
29	Washer, Intermediate	388815

Lavadora Whirlpool 7MLBR8444MT0



WS400

<u>No. Ilus.</u>	<u>DESCRIPCIÓN</u>	<u>No. de Parte</u>
1	Connector Kit, Plastic Drain Hose	285442
2	Sleeve Kit, (Contains 2 Sleeves)	285321
3	Clamp, Hose	285655
4	Connector, Straight	16272
5	Siphon Break Kit (Not Included)	285320
6	Clamp, Hose	285655
7	Drain Protector (Not Included)	367031

