


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

Lavadora Whirlpool 7MLBR8444PQ1





Lavadora Whirlpool 7MLBR8444PQ1


<b>No.Illus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
2	Top (White)	8541617
	Top (Biscuit)	8541619
4	Nut, Push-In	357213
5	Cabinet (White)	63128
	Cabinet (Biscuit)	3954777
6	Clip, Top & Cabinet & Rear Panel (2)	62780
7	Dispenser, Bleach	3362952
8	Screw, Ground	3351614
9	Screw, 10-16 x 1/2	308685
11	Switch, Lid	8318084
12	Nut, Hex	680762
13	Screw, Lid Hinge Mounting (4)	355274
15	Hinge, Lid (L.H.)	8318088
16	Hinge, Lid (R.H.)	54583
17	Bumper, Lid Hinge	19119
18	Bearing, Lid Hinge (2)	21258
19	Lid (White)	8557513
	Lid (Biscuit)	8557514
22	Bumper, Lid (2)	9724509
28	Screw, 10-16 x 3/8 (4)	9420601

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Lavadora Whirlpool 7MLBR8444PQ1





## Lavadora Whirlpool 7MLBR8444PQ1

<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
1	Washer, Water Inlet Hose (4)	16123
2	Wire, Ground	3395559
3	Hose, Water Inlet (Red)	89503
	Hose, Water Inlet (Blue)	89503
4	Nozzle-Drain Hose	3357027
5	Strap, Console (2)	8568314
6	Panel, Rear	8541686
7	Pad, Rear Panel	62747
8	Hose, Drain (4 Ft.)	285664
	Hose, Drain (9 Ft.) (Not Included)	285666
	Extension, Drain Hose (21 Inches)	285702
9	Timer, Control (50 Hz.)	3951603
10	Switch, Water Temperature	661614
11	Screw, 8-18 x 3/8	90767
12	Switch, Water Level	3366847
13	Bracket, Control	3948814
14	Cord, Power	8559419
15	Strain Relief, Power Cord	285777
16	Cap, End (L.H.) (White)	279962
	Cap, End (L.H.) (Biscuit)	8314852
17	Screw, 8-18 x 1/2	9740848
18	Valve, Water Mixing	285805
19	Clamp, Hose	3976395
20	Clip, Capacitor	8318046
21	Clamp, Hose	596669
22	Hose, Vacuum Break	3357328
23	Clamp, Hose	596669
24	Break, Vacuum	3347034



Lavadora Whirlpool 7MLBR8444PQ1


<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
25	Edge Protector	3367669
26	Assembly, Drain Hose	8541656
27	Clamp, Hose	356138
28	Capacitor	661606
29	Screw, 10-16 x 3/8	9420601
30	Clamp, Hose	616099
31	Clamp, Hose	285655
32	Hose, Pump To Tub	285871
36	Screw, Timer Mounting	3400818
37	Screw, Ground	3179795
39	Panel, Console (White)	8539634
	Panel, Console (Biscuit)	8539635
41	Clip, Grounding	357572
44	Knob, Timer (White)	8544943
	Knob, Timer (Biscuit)	8544944
45	Dial, Timer (White)	8544947
	Dial, Timer (Biscuit)	8544948
47	Knob, Control (White)	8544935
	Knob, Control (Biscuit)	8544936
49	Screw, 8-18 x 1.25 (Panel to Top)	388326
50	Screw, Ground	3351614
51	Cap, End (R.H.) (White)	279962
	Cap, End (R.H.) (Biscuit)	8314851
55	Clamp, Drain Hose	3357331
58	Shield, Inlet Valve	8314879
59	Clip, Knob	8536939
60	Harness, Wiring	3956739

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Lavadora Whirlpool 7MLBR8444PQ1






## Lavadora Whirlpool 7MLBR8444PQ1

<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>1</b>	Dispenser	63580
<b>2</b>	Screw & Washer (5/16-24 x 1)	285009
<b>4</b>	Agitator	64214
<b>5</b>	Tub Ring	3360611
<b>6</b>	Gasket, Tub Ring	3359586
<b>7</b>	Clip, Balance Ring (8)	8519815
<b>8</b>	Balance Ring	3956205
<b>11</b>	Screw (2)	63027
<b>12</b>	Nut, Spanner	21366
<b>13</b>	BASKET	3956207
<b>14</b>	Tub	63125
<b>15</b>	Block, Basket Drive	389140
<b>16</b>	Gasket, Centerpost	383727
<b>17</b>	Hose, Pressure Switch	353244
<b>18</b>	Clip, Pressure Switch Hose	2219077
<b>20</b>	Extention, Agitator	64210
<b>22</b>	Clip, Agitator	3354845
<b>23</b>	Washer, Agitator	3355921
<b>26</b>	Washer	3949550

Lavadora Whirlpool 7MLBR8444PQ1







## Lavadora Whirlpool 7MLBR8444PQ1


<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
1	Brake & Drive Tube (Complete) (Refer to Page 11 For Further Breakdo	285792
2	Washer, Spin Tube Thrust	63292
3	Ring, Spin Tube Support	62697
4	Ring, Retainer	285353
5	Clutch (Complete)	285785
6	Band & Lining, Clutch (In. Illus. 7 & 8)	285790
7	Cap, Clutch Spring (2)	62646
8	Spring, Clutch	3946792
9	Gearcase (Complete)	3360629
10	Screw, Gearcase To Base (3)	3400516
11	Plate, Motor Mount To Gearcase	62611
12	Grommet, Motor (4)	62691
13	Coupling, Motor And Isolation Coupling	285753
14	Shield, Motor	3946532
16	Screw	3400516
17	Retainer, Motor (2)	3349637
18	Shield, Tub To Motor	3362089
19	Motor, Main Drive	389248
20	Switch, Main Drive Motor	3952056
21	Retainer, Pump (2)	8546127
22	Pump (Complete)	3363394
25	Screw (2) 10-16 x 5/8	273556
26	Clip, Anti-Rattle	3355454

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Lavadora Whirlpool 7MLBR8444PQ1






## Lavadora Whirlpool 7MLBR8444PQ1

<b>No.illus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>1</b>	Screw, Bracket Mounting (10-32 x 5/8)	3400076
<b>2</b>	Bracket, Spring Outer (2)	64067
<b>3</b>	Spring (3)	63907
<b>4</b>	Support & Brake, Tub	3362087
<b>5</b>	Bracket, Spring Outer (L.F.)	64065
<b>6</b>	Link, Leveling Mechanism (2)	63138
<b>7</b>	Spring, Leveling Mechanism	8316845
<b>8</b>	Pin, Knurled	62837
<b>9</b>	Foot, Rear (2)	285244
<b>13</b>	Bearing, Centerpost (2)	359398
<b>14</b>	Seal, Centerpost (3)	359449
<b>15</b>	Spring, Counterweight	388492
<b>16</b>	Pad, Plate	285219
<b>17</b>	Plate, Suspension (Includes Illus. 16)	3946509
<b>18</b>	Pad, Base	285744
<b>19</b>	Base Assembly(In.6, 7, 8, 9, 16, 17, 18 26)	285459
<b>21</b>	Nut, Lock (2) (3/8-16)	3359452
<b>22</b>	Foot, Front (2)	389102
<b>23</b>	Seal, Centerpost (2)	356934
<b>24</b>	Centerpost Bearing Kit (Inc. 13, 14 & 23)	285203
<b>25</b>	Ring, Sound Deadening	63134
<b>26</b>	Retainer, Suspension Spring	63806

Lavadora Whirlpool 7MLBR8444PQ1






## Lavadora Whirlpool 7MLBR8444PQ1

<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>1</b>	Clip, Harness	3349557
<b>2</b>	Clip, Harness	388498
<b>3</b>	Clip, Harness	8528351
<b>4</b>	Clip, Harness	8559320
<b>5</b>	Clip, Harness	90016
<b>6</b>	Clip, Harness	8281256
<b>7</b>	Retainer, (Suds Models)	389379
<b>8</b>	Timer, Block Disconnect (White)	3948614
	Timer, Block Disconnect (Black)	352089
<b>9</b>	Receptacle, Terminal (3-Way)	62889
<b>10</b>	Plug, Terminal (3-Way) (Power Cord)	353424
<b>11</b>	Block, Disconnect (Motor 2 Speed)	62505
<b>12</b>	Block, Disconnect (Use Term. 352088)	3347243
<b>13</b>	Protector	63523
<b>14</b>	Connector (2-Way) (Use Term.94614)	717252
<b>15</b>	Clip, Harness	3352944
<b>16</b>	Block, Disconnect (12-Way)	3390423
<b>17</b>	Receptacle (6-Way) (Use Term. 94613)	3347730
<b>18</b>	Connector, Etc	3349494
<b>19</b>	E.T.C. Control	3955728
<b>20</b>	Connector (T.P.A.) (3-Circuit)	3948617
<b>21</b>	Connector Pressure Switch)	3360056
<b>22</b>	Block, Connector (Cold Valve)	3354925
	Block, Connector (Hot Valve)	3354926

Lavadora Whirlpool 7MLBR8444PQ1





Lavadora Whirlpool 7MLBR8444PQ1


<b>No.Illus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>1</b>	Brake And Drive Tube (Complete)	285792
<b>2</b>	Ring, Thrust	62658
<b>3</b>	Seal, Drive Tube	356427
<b>4</b>	Tube, Basket Drive (Inc Illus. 3, 4, 5 & 9)	64208
<b>5</b>	Ring, Retaining	64035
<b>6</b>	Shoe, Brake (2)	285438
<b>7</b>	``T`` Bearing, Spin Tube	62703
<b>8</b>	Cap, Brake Spring (2)	285658
<b>9</b>	Spring, Brake	62647
<b>10</b>	Sleeve, Brake Spring	285658
<b>11</b>	Cam, Brake Release	661516
<b>12</b>	Sleeve, Cam	63022
<b>13</b>	Driver, Brake Cam	285790
<b>14</b>	Ring, Retaining	90368

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Lavadora Whirlpool 7MLBR8444PQ1










# Lavadora Whirlpool 7MLBR8444PQ1

<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
1	Gearcase (Complete)	3360629
2	Cover, Gearcase	285202
3	Seal, Gearcase Cover	3349985
4	Sealer, Gasket (.20 Fl. Oz.) (6 ml)	285195
5	Pinion, Spin (Includes Illus. 25)	285362
6	Seal, Spin Pinion	356427
7	Shaft, Agitator (Complete)	389387
8	Ring, Retaining (2)	90369
9	Retainer, Spring (2)	62677
10	Spring, Agitate	62676
11	Gear, Agitate (Includes 15 & 29)	285509
12	Washer, Agitate Gear	62619
13	Cam Follower (Includes 14)	285206
14	Cam, Agitate (Includes 13)	285206
15	Shaft, Agitator (Includes 11 & 29)	285509
16	Washer, Cam Thrust	62618
17	Bearing, Thrust (Includes 18)	285205
18	Ball, Bearing (Includes 17)	285205
19	Bottom and Pinion, Gearcase	285515
20	Block Tab, Terminal	3949116
21	Seal, Thrust Plug	285352
22	Screw, Gearcase Cover Mounting	3351614
23	Ring, Retaining	285765
24	Washer Kit, Thrust	285766
25	Gear, Spin	285362
26	Neutral Assembly	388253
27	Rack, Connecting	3949609
28	Actuator, Shift	62621
29	Washer, Intermediate	388815

Lavadora Whirlpool 7MLBR8444PQ1



<u>No. Ilus.</u>	<u>DESCRIPCIÓN</u>	<u>No. de Parte</u>
1	Connector Kit, Plastic Drain Hose	285442
2	Sleeve Kit, (Contains 2 Sleeves)	285321
3	Clamp, Hose	285655
4	Connector, Straight	16272
5	Siphon Break Kit (Not Included)	285320
6	Clamp, Hose	285655
7	Drain Protector (Not Included)	367031