



Secadora Whirlpool 7MLGR4634JT4

TOP AND CONSOLE PARTS
 For Models: 7MLGR4634JQ4, 7MLGR4634JT4
 (Designer White) (Biscuit)

Illus. No.	Part No. DESCRIPTION	Illus. No.	Part No. DESCRIPTION	Illus. No.	Part No. DESCRIPTION
1	Literature Parts LIT8543094 Use And Care Guide LIT3978910 Installation Instructions LIT8533203 Wiring Diagram	8	357213 Nut, Push-In (2)	24	3403499 Connector, 2-Position (Gas Valve)
		9	3395683 Housing, Connector (Motor)	25	3403498 Connector, 3-Position (Gas Valve)
		10	339392 Screen, Lint	26	3390646 Screw, 8-18 x 5/16
		11	8283378 White Cover, Lint Screen	27	3977456 Switch, Push-To-Start
			8283380 Biscuit	28	Timer Knob Assembly
		12	3978605 Hinge, R.H.		8312687 White
			3978606 Hinge, L.H.		8271404 Biscuit
		13	688983 Screw, 8-18 x 5/8	29	8271418 Bracket, Control
		14	388326 Screw, Console	30	3977834 White Panel, Control
		15	3397269 Connector (Timer)		3977835 Biscuit
		16	8271390 White Top	31	717252 Receptacle, Latching (2-Way)
			8271392 Biscuit		Knob, Push-To-Start
		17	3394427 Clip, Harness		8271341 White
		18	94614 Terminal		8271349 Biscuit
		19	297535 Bumper, Lint Lid		
		21	3976584 Timer Assembly, 60 Hz.		
		23	8299876 Harness, Wiring		

Following May Be Purchased

DO-IT-YOURSELF REPAIR MANUALS

- LIT677818 Dryer
- 2 3400859 Screw, Grounding
- 3 693995 Screw, Hex Head
- 4 Cap, End (L.H.)
8271365 White
8271368 Biscuit
- 5 3936144 Connector
- 6 8274261 Panel, Rear Console
- 7 Cap, End (R.H.)
8271359 White
8271362 Biscuit

OPTIONAL PARTS (NOT INCLUDED)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

ACCESSORY PARTS

- 279948 Kit, Dryer Repair
- 346764 Kit, Hold-Down (Gas Dryer Mobile Home Installation)
- 8522199 Kit, Dryer Vent Testing
- 689790 Dry Rack

PAINT, TOUCH-UP (1/2oz.)


- 72017 White
- 4392899 Biscuit

PAINT, PRESSURIZED SPRAY (12 oz.)

- 350930 White
- 4392901 Biscuit
- 350938 Primer, Gray

PAINT, BULK (1 qt.)

- 799344 White (Uncut)
- 4392900 Biscuit (Uncut)






Secadora Whirlpool 7MLGR4634JT4

Illus. No.	Part No.	DESCRIPTION
1	697776	Screw, 10-32 x 5/8
2	343641	Screw, 10-16 x 1/2
3	8541400	Bracket, Cabinet
4		Plug, Hinge Hole (4)
	3404413	White
	3404415	Biscuit
5	3396795	Cover, Block
6		Plug, Front Panel
	3394975	White
	3394978	Biscuit
7	3396807	Panel, Rear
8	342055	Screw, 8-18 x 1/2
10	3406104	Door Switch Assembly
11	697773	Screw, 6-20 x 7/8
15	3394083	Clip, Front Panel
16	3392100	Foot, Dryer
	279810	Foot - Optional (Extended Length Package Of 2) (Not Included)

Illus. No.	Part No.	DESCRIPTION
18		Cabinet (Includes Illus. 3)
	8530603	White
	8530606	Biscuit
19	98234	Clip, Ground (2)
20	690363	Lock, Front Top (2)
21		Front Panel Assembly
	3403574	White
	3403577	Biscuit
23	685203	Clip, Felt Pad
24	690081	Catch, Door
25	693995	Screw, Hex Head
26	3405514	Hinge & Pin Assembly
27	696144	Strike, Door
28	3403371	Door, Rear
29		Door, Front
	3403361	White
	3403363	Biscuit
30		Handle, Door
	3405184	White
	3405189	Biscuit

Illus. No.	Part No.	DESCRIPTION
31	8066124	Seal & Bearing Assembly
32	3405245	Seal, Door
33	344020	Cord, Power
34	238088	Hinge, Top (2)
35	691366	Idler & Pulley Assembly
36	8066065	Belt, Drive
37	348780	Base, Motor
38	3400500	Bolt, 5/16-18 x 3/4
39	3394341	Pulley, 60 Hz.
40	8538262	Motor, 60 Hz.
41	660658	Clamp, Motor
42	3404162	Clamp, Motor (W/Shield)
43	8318272	Burner Assembly, 60 Hz. (Refer To Pages 5 & 6 For Further Breakdown)
44	341029	Clamp, Pipe

USE WITH TYPE 1 - NATURAL AND TYPE 4 LIQUEFIED PROPANE
 AND BUTANE GASES





Secadora Whirlpool 7MLGR4634JT4


USE WITH TYPE 1 – NATURAL
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES

Illus. No.	Part No.	DESCRIPTION
1	8318272	Burner Assembly 60 Hz. (Type 1) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8-32 x 5/8)
6	343641	Screw, 10-16 x 1/2
7	693986	Base, Burner
8	3387057	Screw, 8-18 x 3/8
9		Orifice, Burner
	234826	Type 1
	229742	Type 4 (Butane)
	234868	Type 4 (Propane)
10	8318277	Valve, 60 Hz. (Includes Pipe & Illus. #7)
11	694421	Screw, 8-32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
20	239822	Plug, Pipe
25	341029	Clamp, Pipe

Following Parts Not Illustrated

694572 Conversion Kit
(Type 1)
to Type (4) L.P.G.

Secadora Whirlpool 7MLGR4634JT4



Illus. No.	Part No.	DESCRIPTION
1	694283	Lint Chute Assembly
2	343641	Screw, 10-16 x 1/2
3	3406022	Bracket, Bulkhead
4	3388703	Washer, Support
5	90767	Screw, 8-18 x 3/8
6	3392519	Fuse, Thermal
7	347139	Seal, Lint Chute
8	3387134	Thermostat, Internal-Bias
9	8066086	Funnel Hole Plug
10	694089	Wheel, Blower (Includes Illus. 22)
11	8557384	Housing, Blower

Illus. No.	Part No.	DESCRIPTION
12	3398161	Clip
13	489463	Screw, 8-18 x 5/8
14	8530285	Box, Heater
15	3403140	Thermostat, 205°F (96°C)
16	280010	Kit, Thermal Cut-Off (Includes Illus. 15)
17	3401707	Wire, Jumper
18	8066048	Funnel, Burner
19	3390647	Screw, 8-18 x 1/2
20	696302	Shield, Exhaust
21	3392247	Pad, Blower Housing
22	3394196	Seal, Blower Shaft

Illus. No.	Part No.	DESCRIPTION
23	690997	Ring, Tri
24	3399506	Shaft, L.H.
25	3399507	Shaft, R.H.
26	3397588	Roller, Support
27	348197	Washer, Support
28	3359452	Nut, 3/8-16
29	8529955	Bulkhead
30	338906	Sensor, Radiant
31	3394509	Ring, Bearing
32	97787	Screw, 11-16 x 3/4
33	8066085	Seal, Rear Drum
34	3396777	Drum Assembly
35	342847	Baffle, Drum
36	3976435	Bracket, Support
37	90296	Clip
38	339956	Seal

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST