


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Whirlpool 7MLGR5620MQ1



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Secadora Whirlpool 7MLGR5620MQ1

No. Ilus.	DESCRIPCIÓN	No. de Parte
2	Screw, Grounding	3400859
3	Clip, Harness	3394427
4	Cap, End (L.H.)	279962
5	Connector (Timer)	3397269
6	Panel, Rear Console	8274261
7	Housing, Connector (Motor)	3395683
8	Cap, End (R.H.)	279962
9	Buzzer, Mini	694419
10	Handle & Lint Screen Assembly	349639
11	Cover, Lint Screen	8283378
12	Hinge, R.H.	3978605
	Hinge, L.H.	3978606
13	Screw, 8-18 x 5/8	487240
14	Wire, Jumper (Black)	3401674
15	Screw, Hex Head	489069
16	Top	8521918
17	Bumper, Lint Lid	17258
18	Switch, End Of Cycle	3405152
19	Knob, Control	8271339
20	Wire, Jumper (Guard On/Off)	8283276
21	Timer Assembly (60 Hz.)	3976584
22	Connector, 2-Position (Gas Valve)	3403499
23	Connector, 3-Position (Gas Valve)	3403498
24	Connector, 6-Circuit	3347243
29	Screw, 8-18 x 5/16	3390646
30	Nut, Push-In (2)	357213
31	Harness, Wiring	8299877

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Secadora Whirlpool 7MLGR5620MQ1


No.Ilus.	DESCRIPCIÓN	No. de Parte
32	Switch, Push-To-Start	3977456
33	Timer Knob Assembly	8312687
34	Knob, Push-To-Start	8271341
35	Receptacle, 2-Way	717252
36	Terminal, Female	94614
37	Bracket, Control	8271418
38	Panel, Control	8543129
39	Connector	3936144
40	Screw, Console	388326
	ACCESSORY PARTS	
	Dry Rack	3404351

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Whirlpool 7MLGR5620MQ1



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Whirlpool 7MLGR5620MQ1

No.Ilus.	DESCRIPCIÓN	No. de Parte
1	Screw, 10-32 x 5/8 (External Ground)	4331106
2	Screw, 10-16 x 1/2	681414
3	Clamp, Motor (W/Shield)	3404162
4	Bracket, Cabinet	8541400
5	Cover, Block	3396795
6	Screw, Hex Washer Head	489069
7	Panel, Rear	280043
8	Clip, Door Spring	8546676
10	Door Switch Assembly	3406107
11	Screw, 6-20 x 7/8	3395530
13	Screw, 8-18 x 3/8	694091
14	Spring, Door (2)	8541401
15	Screw, 10-16 x 1/2	308685
16	Foot, Dryer	3392100
	Foot - Optional (Extended Length Package Of 2 (Not Included))	279810
18	Cabinet (Includes Illus. 4)	8533643
19	Clip, Ground (2)	98234
20	Lock, Front Top (2)	18776
21	Panel Front	279740
23	Clip, Felt Pad (2)	279220
24	Catch, Door Assembly	3389441
25	Seal, Door	3390731
26	Clip, Hinge (2)	337189
27	Screw, 10-32 x 3/8	486146
28	Hinge, R.H.	8066056
	Hinge, L.H.	8066057
29	Clip, Front Panel	3394083

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Secadora Whirlpool 7MLGR5620MQ1


No. Ilus.	DESCRIPCIÓN	No. de Parte
33	Strike, Panel	279570
35	Door, Rear	695737
36	Door, Front	3393549
37	Handle, Door	690270
38	Seal & Bearing Assembly	3406129
45	Cord, Power	3401402
49	Plug, Front Panel	3394975
51	Hinge, Top (2)	238088
53	Idler & Pulley Assembly	691366
56	Belt, Drive	341241
57	Base, Motor	687079
58	Bolt, 5/16-18 x 3/4	3400500
59	Pulley, 60 Hz.	3394341
62	Motor Assembly 60 Hz.	279827
63	Clamp, Motor	343481
67	Burner Assembly, 60 Hz.	279990
68	Clamp, Pipe	341029

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Whirlpool 7MLGR5620MQ1



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Secadora Whirlpool 7MLGR5620MQ1

No.Ilus.	DESCRIPCIÓN	No. de Parte
1	Lint Chute Assembly	3396352
2	Screw, 8-18 x 5/8	489463
3	Washer-Support	3388703
4	Seal, Lint Chute	347139
5	Screw, 8-18 x 3/8	90767
6	Bracket, Bulkhead	3406022
7	Fuse, Thermal	3392519
8	Drum Hole Plug	8066086
9	Thermostat, Internal-Bias	3387134
10	Wheel, Blower (Includes Illus. 21)	279711
11	Housing, Blower	8557384
12	CLIP	8066155
13	Screw, 10-16 x 1/2	681414
14	Box, Heater	279980
15	Thermostat, 205 F (96 C)	3403140
16	Kit, Thermal Cut-Off (Includes Illus. 15)	280010
17	Wire, Jumper	3401707
18	Funnel, Burner	8066049
19	Screw, 8-18 x 1/2	488729
20	Socket Assembly	3403634
21	Seal, Blower	3394196
22	Bracket, Light	3977373
23	Bulb, Light	17512
24	Lens, Light	8532165
25	Screw, 8-15 x 1/2	488729
26	Ring, Tri	690997
27	Shaft, L.H.	3399506

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Secadora Whirlpool 7MLGR5620MQ1

No. Ilus.	DESCRIPCIÓN	No. de Parte
28	Shaft, R.H.	339489
29	Roller, Support	349241T
30	Washer, Support	348197
31	Nut, 3/8-16	3359452
32	Bulkhead	279798
33	Sensor, Radiant	338906
34	Ring, Bearing	279441
35	Screw, 11-16 x 3/4	63027
36	Seal, Rear Drum	279857
37	Drum Assembly	695587
38	Baffle, Drum (2)	692490
39	Bracket, Support	3976434
40	Clip	90296
41	Baffle, Drum (1)	3403636
42	Seal	339956
43	Shield, Exhaust	696302


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Whirlpool 7MLGR5620MQ1

USE WITH TYPE 1 - NATURAL
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Secadora Whirlpool 7MLGR5620MQ1

No.Ilus.	DESCRIPCIÓN	No. de Parte
1	Burner Assembly 60 Hz. (Type 1)	279990
2	Tube, Burner	693140
3	Bracket, Ignitor	694298
4	Ignitor	279311
5	Screw & Washer (8-32 x 5/8)	3393909
6	Screw, 10-16 x 1/2	681414
7	Base, Burner	693986
8	Screw, 8-18 x 3/8	90767
9	Orifice, Burner (Type 1)	234826
	Orifice, Burner (Type 4 (Butane))	229742
	Orifice, Burner (Type 4 (Propane))	234868
10	Valve, 60 Hz. (Includes Pipe & Illus. 7)	8318277
11	Screw, 8-32 x 1/2 (2)	694421
12	Bracket, Coil	694538
13	Coil, 60 Hz. (2 Terminal) (Main)	694540
14	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)	694539
15	Leak Limiter	694424
16	Screw, Regulator Adjustment	694423
17	Spring, Regulator	694422
20	Plug, Pipe	239822
25	Clamp, Pipe	341029
	Conversion Kit L.P.G.	49572