

Literature Parts

WIRING HARNESS PARTS

- 5 → [Component]
- 36 → [Component]
- 35 → [Component]
- 39 → [Component]
- 7 → [Component]
- 3 → [Component]
- 22 → [Component]
- 23 → [Component]
- 24 → [Component]

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST




Secadora Whirlpool 7MLGR5620MQ2

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	10	349639	Handle & Lint Screen Assembly	24	3347243	Connector, 6-Circuit
	3978910	Installation Instructions	11	8283378	Cover, Lint Screen	25	688805	Spring, Clip Knob
	8543109	Use & Care Guide	12	3978605	Hinge, R.H.	26	8533971	Screw
	8528187	Wiring Diagram	12	3978606	Hinge, L.H.	29	3390646	Screw, 8-18 x 5/16
Following May Be Purchased			13	688983	Screw, 8-18 x 5/8	30	357213	Nut, Push-In (2)
DO-IT-YOURSELF REPAIR MANUALS			14	3401674	Wire, Jumper (Black)	31	8299877	Harness, Wiring
	677818	Dryer	15	693995	Screw, Hex Head	32	3977456	Switch, Push-To-Start
2	8533951	Screw, Grounding	16	8271390	Top	33	3957754	Timer Knob Assembly
3	3394427	Clip, Harness	17	297535	Bumper, Lint Lid	34	3957804	Knob, Push-To-Start
4	8271365	Cap, End (L.H.)	18	3405152	Switch, End of Cycle	35	717252	Receptacle, 2-Way
5	3397269	Connector (Timer)	19	3957799	Knob, Control	36	94614	Terminal, Female
6	8274261	Panel, Rear Console	20	8283292	Wire, Jumper (Guard On/Off)	37	8271418	Bracket, Control
7	3395683	Housing, Connector (Motor)	21	3976584	Timer Assembly (60 Hz.)	38	8543129	Panel, Control
8	8271359	Cap, End (R.H.)	22	3403499	Connector, 2-Position (Gas Valve)	39	3936144	Connector
9	694419	Buzzer, Mini	23	3403498	Connector, 3-Position (Gas Valve)	40	388326	Screw, Console

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

Secadora Whirlpool 7MLGR5620MQ2



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



Secadora Whirlpool 7MLGR5620MQ2


Illus. No.	Part No.	DESCRIPTION
1	697776	Screw, 10-32 x 5/8 (External Ground)
2	343641	Screw, 10-16 x 1/2
3	3404162	Clamp, Motor (W/Shield)
4	8541400	Bracket, Cabinet
5	3396795	Cover, Block
6	693995	Screw, Hex Washer Head
7	3396805	Panel, Rear
8	8546676	Clip, Door Spring
9	3980175	Clamp, Elbow
10	3406107	Door Switch Assembly
11	697773	Screw, 6-20 x 7/8
13	694091	Screw, 8-18 x 3/8
14	8541401	Spring, Door (2)
15	3357011	Screw, 10-16 x 1/2
16	3392100	Foot, Dryer
	279810	Foot - Optional (Extended Length Package Of 2 (Not Included))

Illus. No.	Part No.	DESCRIPTION
18	8530603	Cabinet (Includes Illus. 4)
19	98234	Clip, Ground (2)
20	690363	Lock, Front Top (2)
21	3395197	Panel Front
23	685203	Clip, Felt Pad (2)
24	3389441	Catch, Door Assembly
25	3390731	Seal, Door
26	337189	Clip, Hinge (2)
27	342043	Screw, 10-32 x 3/8
28	8066056	Hinge, R.H.
	8066057	Hinge, L.H.
29	3394083	Clip, Front Panel
33	696144	Strike, Panel
35	695737	Door, Rear
36	3393549	Door, Front
37	690270	Handle, Door

Illus. No.	Part No.	DESCRIPTION
38	3406129	Seal & Bearing Assembly
45	344020	Cord, Power
49	3394975	Plug, Front Panel
51	238088	Hinge, Top (2)
53	691366	Idler & Pulley Assembly
56	8066065	Belt, Drive
57	348780	Base, Motor
58	3400500	Bolt, 5/16-18 x 3/4
59	3394341	Pulley, 60 Hz.
62	8066206	Motor Assembly 60 Hz.
63	660658	Clamp, Motor
67	8318272	Burner Assembly, 60 Hz. (See Pages 7 & 8 For Further Burner Breakdown)
68	341029	Clamp, Pipe

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

Secadora Whirlpool 7MLGR5620MQ2





Secadora Whirlpool 7MLGR5620MQ2


Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly
2	489463	Screw, 8-18 x 5/8
3	3388703	Washer-Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8-18 x 3/8
6	3406022	Bracket, Bulkhead
7	3392519	Fuse, Thermal
8	8066086	Drum Hole Plug
9	3387134	Thermostat, Internal-Bias
10	694089	Wheel, Blower (Includes Illus. 21)
11	8577230	Housing, Blower
12	8066155	Clip
13	343641	Screw, 10-16 x 1/2

Illus. No.	Part No.	DESCRIPTION
14	8530285	Box, Heater
15	3403140	Thermostat, 205°F (96°C)
16	280010	Kit, Thermal Cut-Off (Includes Illus. 15)
17	3401707	Wire, Jumper
18	8066049	Funnel, Burner
19	3390647	Screw, 8-18 x 1/2
20	3403634	Socket Assembly
22	3977373	Bracket, Light
23	3406124	Bulb, Light
24	3402841	Lens, Light
25	487909	Screw, 8-15 x 1/2
26	690997	Ring, Tri
27	3399506	Shaft, L.H.

Illus. No.	Part No.	DESCRIPTION
28	3399507	Shaft, R.H.
29	3397590	Roller, Support
30	348197	Washer, Support
31	3359452	Nut, 3/8-16
32	3403493	Bulkhead
33	338906	Sensor, Radiant
34	692526	Ring, Bearing
35	97787	Screw, 11-16 x 3/4
36	3406130	Seal, Rear Drum
37	695587	Drum Assembly
38	692490	Baffle, Drum (2)
39	3976434	Bracket, Support
40	90296	Clip
41	3403636	Baffle, Drum (1)
42	339956	Seal
43	696302	Shield, Exhaust

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

USE WITH TYPE 1 - NATURAL
 AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

USE WITH TYPE 1 – NATURAL
 AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES

Illus. No.	Part No.	DESCRIPTION
1	8318272	Burner Assembly 60 Hz. (Type 1) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8-32 x 5/8)
6	343641	Screw, 10-16 x 1/2
7	693986	Base, Burner
8	3387057	Screw, 8-18 x 3/8
9		Orifice, Burner
	234826	Type 1
	229742	Type 4 (Butane)
	234868	Type 4 (Propane)
10	8318277	Valve, 60 Hz. (Includes Pipe & Illus. #7)
11	694421	Screw, 8-32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
20	239822	Plug, Pipe
25	341029	Clamp, Pipe

Following Parts Not Illustrated

694572 Conversion Kit
 (Type 1)
 to Type (4) L.P.G.



Secadora Whirlpool 7MLGR5620MQ2

Illus. No.	Part No.	DESCRIPTION
<u>ACCESSORY PARTS</u>		
	279948	Kit, Dryer Repair
	8522199	Kit, Dryer Vent Testing
	346764	Kit, Hold-Down (Gas Dryer Mobile Home Installation)
	3404351	Dry Rack
<u>PAINT, TOUCH-UP (1/2oz.)</u>		
	72017	White
<u>PAINT, PRESSURIZED SPRAY (12 oz.)</u>		
	350930	White
	350938	Primer, Gray
<u>PAINT, BULK (1 qt.)</u>		
	799344	White (Uncut)