


SECADORA 7MLGR7648PT0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

SECADORA 7MLGR7648PT0

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8564241	Instructions, Installation
	8572911	Sheet, Cycle Feature
	8565897	Use & Care Guide
	3979703	Wiring Diagram

Following May Be Purchased


DO-IT-YOURSELF REPAIR MANUALS

	677818	Dryer
2	3401684	Wire, Jumper (Black)
3	694419	Buzzer, Mini
4		Cap, End (L.H.)
	8271365	White
	8271368	Biscuit
5	717252	Plug, 2-Way Terminal
6	8274261	Panel, Rear Console
7	3399639	Switch, Temperature
8		Cap, End (R.H.)
	8271359	White
	8271362	Biscuit

Illus. No.	Part No.	DESCRIPTION
9	693995	Screw, Hex Washer Head
10		Lint Screen
	8557857	White
	8557858	Biscuit
11	8536939	Clip, Spring
12	3400985	Medallion
13	688983	Screw, 8-18 x 5/8
14	8533951	Screw, Grounding
15	3395683	Connector (Motor)
16		Top
	8557930	White
	8557931	Biscuit
18		Knob, Control (3)
	8544935	White
	8544936	Biscuit
	8544938	Gold
19	3394427	Clip-Harness
20	388326	Screw, Console
21	8299766	Timer Assembly (60 Hz.)
22	3397269	Connector-Timer
23	3401144	Connector, (PTS Relay)
24	3403499	Connector, 2-Position (Gas Valve)
25	3403498	Connector, 3-Position (Gas Valve)

Illus. No.	Part No.	DESCRIPTION
26	3397695	Wire, Jumper (Guard On/Off)
27	8533971	Screw, 8-18 x 5/16
28	357213	Nut, Push-In (2)
29	8299879	Harness, Wiring
30	3396029	Wire, Jumper (Temperature)
31	3347243	Connector 6-Circuit
32	3405156	Switch, Finish Guard
33	3398095	Switch, Push-To-Start
34		Timer Knob Assembly
	8544955	White
	8544956	Biscuit
	8544958	Gold
35	94614	Terminal, Female
36	8544895	Bracket, Control
37		Panel, Control (Includes Illus. 12)
	8318804	White
	8318806	Grey
	8318805	Biscuit
	8577307	Gold
38	3936144	Connector

SECADORA 7MLGR7648PT0




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

SECADORA 7MLGR7648PT0

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	697776	Screw, 10-32 x 5/8 (External Ground)	18		Cabinet (Includes Illus. 4)	37		Handle, Door
2	343641	Screw, 10-16 x 1/2					690270	White
3	693995	Screw, Hex Head		8530603	White		3977242	Biscuit
4	8541400	Bracket, Cabinet		8530606	Biscuit	38	3406129	Seal & Bearing Assembly
5	3396795	Cover, Block	19	98234	Clip, Ground (2)	39		Plug, Front Panel
6	3404162	Clamp, Motor (W/Shield)	20	690363	Lock, Front Top (2)		3394975	White
7	3396805	Panel, Rear	21		Panel Front		3394978	Biscuit
8	8546676	Clip, Door Spring		3395197	White	45	344020	Cord, Power
9	3980175	Clamp, Elbow		3977243	Biscuit	48	3394083	Clip, Front Panel
10	3406107	Door Switch Assembly	23	685203	Clip, Felt Pad (2)	51	238088	Hinge, Top (2)
11	697773	Screw, 6-20 x 7/8	24	3389441	Catch, Door Assembly	53	691366	Idler & Pulley Assembly
13	3357011	Screw, 10-16 x 1/2	25	3390731	Seal, Door	56	8066065	Belt, Drive
14	8541401	Spring, Door (2)	26	337189	Clip, Hinge (2)	57	348780	Base, Motor
16	3392100	Foot, Dryer	27	694091	Screw, 8-18 x 3/8	58	3400500	Bolt, 5/16-18 x 3/4
	279810	Foot-Optional (Extended Length) (Package of 2) (Not Included.)	28	8066056	Hinge, R.H.	59	3394341	Pulley, 60 Hz.
17	342043	Screw, 10-32 x 3/8		8066057	Hinge, L.H.	62	8066206	Motor Assembly 60 Hz.
			33	696144	Strike, Panel	63	660658	Clamp, Motor
			35	695737	Door, Rear	67	8318272	Burner Assembly, 60 Hz.
			36		Door, Front			(See Pages 7 & 8 For Further Burner Breakdown)
				3393549	White	68	341029	Clamp, Pipe
				3977241	Biscuit			

SECADORA 7MLGR7648PT0




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

SECADORA 7MLGR7648PT0

Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly
2	489463	Screw, 8-18 x 5/8
3	3388703	Washer-Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8-18 x 3/8
6	487909	Screw, 8-15 x 1/2
7	3392519	Fuse, Thermal
8	8066086	Drum Hole Plug
9	3387134	Thermostat, Internal-Bias
10	694089	Wheel, Blower (Includes Illus. 21)
11	8577230	Housing, Blower
12	3398161	Clip
13	343641	Screw, 10-16 x 1/2
14	8530285	Box, Heater
15	3403140	Thermostat, 205 F (96 C)
16	280010	Kit, Thermal Cut-Off (Includes Illus. 15)
17	3390647	Screw, 8-18 x 1/2
18	8066049	Funnel, Burner
19	3403634	Socket Assembly
20	3406124	Bulb
21	3394196	Seal, Blower
22	3977373	Bracket, Drum Light
23	3406022	Bracket, Bulkhead
24	3401707	Wire, Jumper
41	690997	Ring, Tri
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397590	Roller, Support
46	348197	Washer, Support
47	3359452	Nut, 3/8-16
48	3403413	Bulkhead
49	338906	Sensor, Radiant
53	3402841	Lens, Drum Light
62	692526	Ring, Bearing
63	97787	Screw, 11-16 x 3/4
66	3406130	Seal, Rear Drum
67	695587	Drum Assembly
68	692490	Baffle, Drum (2)
69	3976434	Bracket, Support
70	90296	Clip
71	3403636	Baffle, Drum (1)
73	339956	Seal
75	696302	Shield, Exhaust

SECADORA 7MLGR7648PT0

USE WITH TYPE 1 - NATURAL
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES



SECADORA 7MLGR7648PT0

USE WITH TYPE 1 – NATURAL
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES

Illus. No.	Part No.	DESCRIPTION
1	8318272	Burner Assembly 60 Hz. (Type 1) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8-32 x 5/8)
6	343641	Screw, 10-16 x 1/2
7	693986	Base, Burner
8	3387057	Screw, 8-18 x 3/8
9		Orifice, Burner
	234826	Type 1
	229742	Type 4 (Butane)
	234868	Type 4 (Propane)
10	8318277	Valve, 60 Hz. (Includes Pipe & Illus. #7)
11	694421	Screw, 8-32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
20	239822	Plug, Pipe
25	341029	Clamp, Pipe

Following Parts Not Illustrated

694572 Conversion Kit
(Type 1)
to Type (4) L.P.G.

OPTIONAL PARTS (NOT INCLUDED)

For Models: 7MLGR7648PQ0, 7MLGR7648PW0, 7MLGR7648PT0, 7MLGR7648PG0
(Designer White) (White/Grey) (Biscuit) (Gold)

Illus.	Part	
No.	No.	DESCRIPTION

ACCESSORY PARTS

279948	Kit, Dryer Repair
8522199	Kit, Dryer Vent Testing
346764	Kit, Hold-Down (Gas Dryer Mobile Home Installation)
3406839	Dry Rack

PAINT, TOUCH-UP (1/2oz.)

72017	White
4392899	Biscuit

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
4392901	Biscuit
350938	Primer, Gray

PAINT, BULK (1 qt.)

799344	White (Uncut)
4392900	Biscuit (Uncut)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST