


Secadora Maytag 7MMGDB950AG0




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



Secadora Maytag 7MMGDB950AG0

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10393006	Tech, Sheet
	W10526992	Guide, Use & Care
	W10492250	Installation, Instructions
2		Console Assembly
	W10496922	Cosmetallic
3	W10388669	Assembly, UI
4	W10051124	Cover, UI
5	W10338554	Knob, Assembly
6	W10432257	Control Electronic
7	8572039	Seal, UI
8	8563853	Bracket, Machine Controller
9	W10003770	Screw
10	8558863	Bracket, Console
11		Top
	W10338836	Cosmetallic
12	337686	Screw
13	W10112673	Clip, Console
14	W10393461	Harness, Wiring
15	W10131402	Screw

Secadora Maytag 7MMGDB950AG0






Secadora Maytag 7MMGDB950AGO

Illus. No.	Part No.	DESCRIPTION
1	98234	Clip, Ground
2	8544753	Bracket, Burner
3	3390631	Screw, 10-16 x 3/8
4	8558833	Plate, Cover Terminal Block
5	W10411937	Switch, Broken Belt
6	W10440460	Cord, Power Cabinet
7	W10304162	Cosmetallic
8	W10363894	Foot, Dryer
	279810	Foot - Optional (Extended Length Package Of 2) (Not Included)
9	660658	Clamp, Motor
10	W10446781	Spring, Idler
11	3389420	Retainer, Idler
12	3393008	Screw
13	8547160	Pulley Assembly
14	W10201446	Bracket, Gas Pipe
15	W10363887	Riser-FULL
16	W10111859	Seal, Inner Glass
17	W10323735	Badge

Illus. No.	Part No.	DESCRIPTION
18	W10111888	Plug, Strike
19	3394083	Clip, Front Panel
20	W10111906	Strike & Plate Assembly
21	W10463337	Assembly, Hinge
22	W10369542	Window, Outer
23	W10463264	Panel, Front
24	W10136930	Pulley Drum Motor
25	W10304170	Bezel
26	3393657	Restrainer, Belt
27	W10460374	Motor, Assembly 60 HZ.
28	W10140148	Panel, Rear
29	W10139247	Pulley, Blower
30	W10136934	Belt, Drive
31	W10123956	Sound Panel
32	W10308685	Bracket, Motor
33	W10111905	Door Catch Assembly

Illus. No.	Part No.	DESCRIPTION
34	3390647	Screw
35	8568303	Locator, Snap Down
36	W10215725	Cover, Door Switch
37	3400805	Screw
38	W10144494	Plug, Hole
39	W10221653	Seal, Door
40	342055	Screw
41	W10350909	Door Switch Assembly
42	W10111857	Glass, Inner Door
43	8576625	Lock, Top Front
44	W10044490	Seal, Front Panel
45	W10301055	Plug, Front Panel Cosmetallic
46	238088	Hinge Top
47	W10304172	Door, Inner Cosmetallic
48	W10316529	Seal, Foam
49	W10344649	Door, Outer Cosmetallic

Secadora Maytag 7MMGDB950AG0






Secadora Maytag 7MMGDB950AGO

Illus. No.	Part No.	DESCRIPTION
1	W10359271	Shaft, R.H. Thread
2	8577274	Thermistor, Blower Housing
3	90767	Screw
4	3394986	Spring, Lint Screen Door
5	W10385948	Air Duct Assembly
6	697813	Seal, Outlet Housing
7	8573068	Seal, Blower Cover
8	3934666	Nut, 3/8 x 16(R.H.)
9	8544742	Belt, Blower
10	8557244	Bulkhead Front
11	W10219342	Screw
12	3390647	Screw
13	8544721	Seal, Lint Duct
14	3394984	Door, Lint Screen
15	8544755	Exhaust Pipe
16	W10001120	Nut, 3/8 x 16(L.H.)
17	W10139797	Bulkhead, Rear
18	3387459	Washer, Support
19	W10359272	Shaft, L.H. Thread

Illus. No.	Part No.	DESCRIPTION
20	690997	Tri Ring
21	W10314171	Roller, Support
23	3394985	Outlet Housing Assembly
24	8544741	Bracket, Blower Housing
25	8557269	Complete Drum Assembly
26	W10049370	Lint Screen
27	W10116344	Seal, Drum
28	693995	Screw
29	3387223	Electrode, Sensor
30	3402841	Lens, Drum Light
31	3406124	Bulb, Light
32	8544737	Wheel, Blower
33	3977373	Bracket, Light
34	W10214261	Socket, Assembly
35	8573713	Thermal Cut-Off
36	3391912	Thermostat, High Limit
37	W10256512	Housing, Blower
38	8544786	Lint Duct Assembly
39	8573824	Funnel, Burner
40	338906	Sensor, Radiant
41	8544719	Cover, Blower (Includes No.7)

Illus. No.	Part No.	DESCRIPTION
42	3387230	Screw
43	8544739	Pulley, Blower
44	8563860	Baffle, Drum
45	3350424	Screw
46	8544718	Duct, Inlet Blower
47	8544723	Grill, Outlet
48	3390719	Thermal Fuse
49	8573070	Clip, Lint Duct
51	W10419068	Thermistor, Gas
52	W10130506	Valve & Hose Assembly, Complete
54	W10129424	Valve & Bracket Assembly
55	W10348593	Nozzle & Hose Assembly (Includes Items 56, 57, 58, 59)
56	W10277503	Nozzle & Screen Assembly
57	W10044599	Clip, Push To Connect
58	W10044605	Coupling, Hose
59	W10160575	Cover, Myst Valve
60	W10435653	Sleeve, Tube
61	W10044579	Washer, Nozzle
62	W10044628	Nut, 9/16 - 24

USE WITH TYPE 1 – NATURAL
 AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES



Illus. No.	Part No.	DESCRIPTION
1	W10398742	Burner Assembly 60 Hz. (Type 1) (Copreci)
2	8573010	Tube, Burner
3	694298	Bracket, Ignitor

Illus. No.	Part No.	DESCRIPTION
4	686590	Ignitor
5	3393909	Screw & Washer (8-32 x 7/8)
6	343641	Screw
7	W10183823	Bracket, Burner
8	3387057	Screw

Illus. No.	Part No.	DESCRIPTION
9		Orifice, Burner 15418 Type 1 229742 Type 4 (Propane)
10	W10304606	Valve, Gas 60 Hz. (Complete) (Includes Pipe & Illus. #7).
11	W10368268	Coil, 60 Hz.

OPTIONAL PARTS (NOT INCLUDED)

For Models: 7MMGDB950AG0
(Cosmetallic)

<u>Illus.</u>	<u>Part</u>	
<u>No.</u>	<u>No.</u>	<u>DESCRIPTION</u>

ACCESSORY PARTS

80047	Kit, Dryer Repair
8522199	Kit, Dryer Vent Testing
346764	Kit, Hold-Down (Gas Dryer Mobile)

PAINT, TOUCH-UP (1/2oz.)

72017 White

PAINT, PRESSURIZED SPRAY (12 oz.)

350930 White
350938 Primer, Gray

PAINT, BULK (1 qt.)

799344 White (Uncut)

Miscellaneous Parts Bag

W10206708 Bag Assembly
(Contains
The Following)

89503	Hose, Inlet 5' Hose
353362	Filter Washer
W10242307	CN-Washer, Hose
350027	Hose, Inlet 1' Hose
3357450	Washer, Hose Adaptor
W10269488	Connector, Hose Y