






29" GAS DRYER

MODELS:

7MMGDC300DW0 (White)



Illus.


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10652554	Use and Care Guide
	W10658640	Installation Instructions
	W10118081	Wiring Diagram
2		End Cap (Right)
	W10193821	White
3	694419	Buzzer, Mini
4		End Cap (Left)
	W10193824	White
5	W10476828	Control, Electronic
6	W10103406	Panel, Rear (Console)
7	W10565803	Harness, Wiring

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	8312709	Clip, Console
9	693995	Screw
10	W10641634	Lint Screen
11	3405156	Switch, Wrinkle Guard
12	8533971	Screw
13	688983	Screw
14		Assembly, Control Knob
	W10562155	Grey
15	3348629	Screw
16		Top
	W10225059	White
17	W10316616	Seal, Foam

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
18		Assembly, Timer Knob
	W10558463	Grey
19	W10117655	Switch, Push To Start
20		Console
	W10643298	White
21	8566184	Assembly, Timer (60 Hz.)
22	8530169	Switch, Rotary Temperature
23	W10199708	Badge



Illus.


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3390631	Screw
2	343641	Screw
3	693995	Screw
4	W10236073	Bracket, Cabinet
5	3396795	Cover, Terminal Block
6	W10121316	Clamp, Motor Mount
7	W10571724	Panel, Rear
8	W10567345	Plug, Strike
9	W10529198	Cover, Door Catch
10	W10569603	Switch, Door
11	697773	Screw
12	344020	Cord, Power
13	341029	Clamp, Pipe
14	3404413	Plug, Hole
15	3394083	Clip, Front Panel
16	W10561321	Foot, Dryer
17	3404162	Clamp, Motor (With Shield)
18	W10224934	Cabinet (With Seal, Spill Guard)

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
19	98234	Clip, Ground
20	8066092	Lock, Front Top
21		Panel, Front
	W10664698	White
22	8066217	Hinge, Top
23	685203	Clip, Felt Pad
24	W10610880	Assembly, Door Catch
25	W10389572	Seal, Door
26	691362	Assembly, Pulley & Bearing
27	342055	Screw
28	W10362431	Assembly, Hinge and Pin
29	W10396032	Assembly, Motor
30	8066184	Pulley, Motor
31	W10198086	Belt, Drive
32	3400500	Bolt
33	3403431	Strike, Door
34	348780	Base, Motor
35	W10463967	Door, Inner

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
36		Door, Front
	3402335	White
37		Handle, Door
	W10549553	White
38	W10663510	Assembly, Seal and Bearing
39		Plug, Front Panel
	8564457	White
40	8318272	Burner Assembly (60 Hz) (Type 1) (White Rodgers)
41	W10316529	Seal, Foam
42	W10316619	Seal, Spill Guard
43	3390647	Screw
44	W10529197	Bezel, Door Catch



Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	348368	Assembly, Lint Chute
2	489463	Screw
3	3388703	Washer
4	347139	Seal, Lint Chute
5	90767	Screw
6	W10389567	Shield, Exhaust
7	3392519	Fuse, Thermal (91C)
8	3976479	Pad, Sensor
9	8318268	Thermostat
10	694089	Wheel, Blower
11	8577230	Housing, Blower
12	3398161	Clip, Heater Box
13	343641	Screw
14	8530285	Box, Heater (96C)
15	W10423382	Thermostat H.L SPST (180F)
16	3977394	Thermal Cut-Off


Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
17	3390647	Screw
18	8066049	Funnel, Burner Light
19	339956	Seal
20	3403636	Baffle, Drum (Short)
21	3977373	Bracket, Drum Light
22	90296	Nut, Push On
23	3406022	Bracket, Bulkhead Chute
24	3976434	Bracket, Support
25	W10512946	Washer, Tri Ring
26	W10359270	Shaft, Drum Roller - Left Hand Thread
27	W10359269	Shaft, Drum Roller - Right Hand Thread
28	W10314171	Roller, Support
29	348197	Washer
30	W10298789	Nut, Hex
31	3403414	Bulkhead

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
32	338906	Sensor, Radiant
33	692490	Baffle, Drum (Long)
34	692526	Bearing, Ring
35	W10219342	Screw
36	W10663495	Seal, Rear Drum
37	W10389436	Assembly, Drum (Complete)
38	3406124	Bulb, Light
39	W10214261	Socket, Light
40	3402841	Lens, Drum Light

USE WITH TYPE 1 - NATURAL
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES



<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8318272	Burner Assembly (60 Hz) (Type 1) (White Rodgers)	9		Orifice, Burner	15	694424	Leak, Limiter
2	688617	Tube, Burner		234826	Type 1 (Natural)	16	694423	Screw, Regulator Adjustment
3	694298	Bracket, Ignitor		229742	Type 4 (Butane)	17	694422	Spring, Regulator
4	686590	Ignitor	10	234868	Type 4 (Propane)	18	239822	Plug, Pipe
5	W10366705	Screw	11	8318277	Valve, Gas (60 Hz)			Following Parts Not Illustrated
6	343641	Screw	12	694421	Screw, Coil		694572	Conversion Kit (Type 1 and 2) to Type (4) L.P.G.
7	693986	Base, Burner	13	694538	Bracket, Coil			
8	3387057	Screw	14	694540	Coil, 60 Hz. (2 Terminal) (Main)			
				694539	Coil, 60 Hz (Split) (3 Terminal) (Pilot Position)			

OPTIONAL PARTS (NOT INCLUDED)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	279948	Kit, Dryer Repair
	346764	Kit, Hold Down
	8522199	Kit, Dryer Vent Testing
	3406839	Dry Rack

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350938	Gray Primer