


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

SECADORA 7MWED1650EQ0






SECADORA 7MWED1650EQ0

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10791289	Installation Instructions
	W10791286	Use and Care Guide
	W10663954	Wiring Diagram
2	W10726632	Seal, Console
3	693995	Screw
4	W10836097	Panel, Dampening
5	9740848	Screw
6	W10756582	Panel, Rear
7	694419	Buzzer, Mini

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10298336	Nut, "U"
9	W10780469	Harness, Wiring
10		Lint Screen
	W10508973	White
11	Assembly, KnobW10743997	Chrome
12	8312709	Clip, Console
13	688983	Screw
14	W10446920	Switch, Push to Start
15	W10648593	Switch, Rotary (Wrinkle Control)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
16		Top
	W10613389	White
17	W10662472	Collar, Lint Chute
18		Assembly, Console
	W10749096	White
19	8536939	Clip, Spring
20	W10436303	Assembly, Timer
21		Assembly, Timer Knob
	W10743994	Chrome

SECADORA 7MWED1650EQ0






SECADORA 7MWED1650EQ0

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10782659	Pad, Power Cord
2	3390631	Screw
3	693995	Screw
4	W10316529	Seal, Foam
5	W10571619	Cover, Terminal Block
6	342043	Screw
7	W10571724	Panel, Rear
8	3390631	Screw
9	W10823580	Seal, Door
10	W10237959	Switch, Door
11	697773	Screw
12	3404162	Clamp, Motor (With Shield)
13	3357011	Screw
14	W10041960	Spring, Door
15	W10775448	Clip, Front Panel
16	W10754507	Foot, Dryer
17	279318	Terminal, Brass and Tinned (Includes Terminal Block Screw Kit)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
18		Cabinet
	8530603	White
19	98234	Clip, Ground
20	8066092	Lock, Front Top
21		Panel, Front
	W10664693	White
22	W10121316	Clamp, Motor Mount
23	685203	Clip, Felt Pad
24	3389441	Assembly, Door Catch
25	W10396029	Assembly, Motor
26	337189	Clip, Hinge
27	342055	Screw
28	8066056	Hinge, Door (Right)
	8066057	Hinge, Door (Left)
29	8066184	Pulley, Motor
30	3400500	Bolt
31	348780	Base, Motor
32	W10131364	Belt, Drive

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
33	696144	Strike, Door
34	691366	Idler Assembly
35	695737	Door, Rear
36		Door, Front
	W10714515	White
37		Handle, Door
	W10714516	White
38	W10803476	Assembly, Seal and Bearing
39	279393	Screw Kit, Terminal Block
40	343641	Screw
41	W10641296	Hinge, Top
42	W10575896	Clip, Spring
43	W10641295	Bracket, Rear
44	W10841728	Seal, Spill Guard

SECADORA 7MWED1650EQ0





SECADORA 7MWED1650EQ0

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	348368	Assembly, Lint Chute
2	3390647	Screw
3	3388703	Washer
4	3471139	Seal, Lint Chute
5	3348629	Screw
6	W10389567	Shield, Exhaust
7	3392519	Fuse, Thermal (91C)
8	3387134	Thermostat
9	W10900067	Kit, Thermal Cut-Off (Includes Thermostat)
10	3977767	Thermostat, 221 F (105 C)
11	694089	Wheel, Blower
12	8577230	Housing, Blower
13	343641	Screw

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
14	8541818	Box, Heater
15	3398161	Clip, Heater Box
16	3976434	Bracket, Support
17	W10724237	Element, Heater
18	W10653662	Pad, Foam
19	279457	Terminal Wire Kit (For Heater Element Wiring Harness Repair)
20	489463	Screw
21	339956	Seal
22	3403636	Baffle, Drum (Short)
23	90296	Nut, Push On
24	692526	Bearing, Ring
25	692490	Baffle, Drum (Long)
26	W10757750	Assembly, Drum (Complete)

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
27	W10856781	Seal, Rear Drum
28	W10512946	Washer, Tri Ring
29	W10359270	Shaft, Drum Roller - Left Hand Thread
30	W10359269	Shaft, Drum Roller - Right Hand Thread
31	3397590	Roller, Support
32	348197	Washer
33	W10298789	Nut, Hex
34	3403410	Bulkhead
35	W10219342	Screw

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

Illus.

No. Part No. Description

72017 White

PAINT, BULK (1 QT.)

Illus.

No. Part No. Description

799344 White (Uncut)

ACCESSORY PARTS

Illus.

No. Part No. Description

279948 Kit, Dryer Repair

346764 Kit, Hold Down

8522199 Kit, Dryer Vent Testing

W10322470A Dry Rack

PAINT, PRESSURIZED SPRAY (12 OZ.)

Illus.

No. Part No. Description

350930 White

350938 Gray Primer