

WIRING HARNESS PARTS

15	
17	
24	
25	
31	
18	
5	
9	

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



Secadora Whirlpool 7MWG445500SQ

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8565897	Use And Care Guide
	8579563	Sheet, Cycle Feature
	8564241	Installation Instructions
	8533203	Wiring Diagram

**Following May Be Purchased**


**DO-IT-YOURSELF REPAIR MANUALS**

	677818	Dryer
2	8533951	Screw, Grounding
3	693995	Screw, Hex Head
4		Cap, End (L.H.)
	8271369	White
	8314852	Biscuit
5	3936144	Connector
6	8274261	Panel, Rear Console

Illus. No.	Part No.	DESCRIPTION
7		Cap, End (R.H.)
	8271363	White
	8314851	Biscuit
8	357213	Nut, Push-In (2)
9	3395683	Housing, Connector (Motor)
10		Screen, Lint
	8557861	White
	8557862	Biscuit
11	8536939	Clip, Spring
12	688983	Screw, 8-18 x 5/8
14	388326	Screw, Console
15	3397269	Connector (Timer)
16		Top
	8557930	White
	8557931	Biscuit
17	3394427	Clip, Harness
18	94614	Terminal
21	3976584	Timer Assembly, 60 Hz.
23	8299876	Harness, Wiring

Illus. No.	Part No.	DESCRIPTION
24	3403499	Connector, 2-Position (Gas Valve)
25	3403498	Connector, 3-Position (Gas Valve)
26	8533971	Screw, 8-18 x 5/16
27	3977456	Switch, Push-To-Start
28		Timer Knob Assembly
	8566061	White
	8566064	Biscuit
29	8544895	Bracket, Control Panel, Control
30		White
	8543033	White
	8543034	Biscuit
31	717252	Receptacle, Latching (2-Way)
32		Knob, Push-To-Start
	8566065	White
	8566068	Biscuit

Secadora Whirlpool 7MWG445500SQ




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



Secadora Whirlpool 7MWG445500SQ0

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	697776	Screw, 10-32 x 5/8	19	98234	Clip, Ground (2)	31	8066123	Seal & Bearing Assembly
2	343641	Screw, 10-16 x 1/2	20	690363	Lock, Front Top (2)	32	3390734	Seal, Door
3	8541400	Bracket, Cabinet	21		Front Panel Assembly	33	344020	Cord, Power
5	3396795	Cover, Block		3394895	White Biscuit	34	8066217	Hinge, Top (2)
6		Plug, Front Panel		8537517	Biscuit	35	691366	Idler & Pulley Assembly
	3394975	White Biscuit	23	685203	Clip, Felt Pad	36	8066065	Belt, Drive
	3394978	Biscuit	24	3389441	Catch, Door	37	348780	Base, Motor
7	3396807	Panel, Rear	25	693995	Screw, Hex Head	38	3400500	Bolt, 5/16-18 x 3/4
8	342055	Screw, 8-18 x 1/2	26	348023	Hinge & Pin Assembly	39	8066184	Pulley, 60 Hz.
10	3406102	Door Switch Assembly	27	696144	Strike, Door	40	8066206	Motor, 60 Hz.
11	697773	Screw, 6-20 x 7/8	28	695656	Door, Rear	41	660658	Clamp, Motor
15	3394083	Clip, Front Panel	29		Door, Front	42	3404162	Clamp, Motor (W/Shield)
16	3392100	Foot, Dryer		348205	White Biscuit	43	8318272	Burner Assembly, 60 Hz. (Refer To Pages 5 & 6 For Further Breakdown)
	279810	Foot - Optional (Extended Length Package Of 2) (Not Included)	30		Handle, Door			
				686711	White Biscuit	44	341029	Clamp, Pipe
18		Cabinet (Includes Illus. 3)		3978592	Biscuit	45	3980175	Clamp-Elbow
	8530603	White						
	8530606	Biscuit						

USE WITH TYPE 1 - NATURAL  
 AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES



BA-150

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



Secadora Whirlpool 7MWG445500SQO


USE WITH TYPE 1 – NATURAL  
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES

Illus. No.	Part No.	DESCRIPTION
1	8318272	Burner Assembly 60 Hz. (Type 1) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8-32 x 5/8)
6	343641	Screw, 10-16 x 1/2
7	693986	Base, Burner
8	3387057	Screw, 8-18 x 3/8
9		Orifice, Burner
	234826	Type 1
	229742	Type 4 (Butane)
	234868	Type 4 (Propane)
10	8318277	Valve, 60 Hz. (Includes Pipe & Illus. #7)
11	694421	Screw, 8-32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
20	239822	Plug, Pipe
25	341029	Clamp, Pipe

Following Parts Not Illustrated

694572 Conversion Kit  
(Type 1)  
to Type (4) L.P.G.

Secadora Whirlpool 7MWG445500SQ



Illus. No.	Part No.	DESCRIPTION
1	694283	Lint Chute Assembly
2	343641	Screw, 10-16 x 1/2
3	3406022	Bracket, Bulkhead
4	3388703	Washer, Support
5	90767	Screw, 8-18 x 3/8
6	3392519	Fuse, Thermal
7	347139	Seal, Lint Chute
8	3387134	Thermostat, Internal-Bias
9	8066086	Drum Hole Plug
10	694089	Wheel, Blower (Includes Illus. 22)
11	8577230	Housing, Blower
12	3398161	Clip

Illus. No.	Part No.	DESCRIPTION
13	489463	Screw, 8-18 x 5/8
14	8530285	Box, Heater
15	3403140	Thermostat, 205 F (96 C)
16	280010	Kit, Thermal Cut-Off (Includes Illus. 15)
17	3401707	Wire, Jumper
18	8066048	Funnel, Burner
19	3390647	Screw, 8-18 x 1/2
20	696302	Shield, Exhaust
21	3392247	Pad, Blower Housing
23	690997	Ring, Tri

Illus. No.	Part No.	DESCRIPTION
24	3399506	Shaft, L.H.
25	3399507	Shaft, R.H.
26	3397590	Roller, Support
27	348197	Washer, Support
28	3359452	Nut, 3/8-16
29	8529955	Bulkhead
30	338906	Sensor, Radiant
31	3394508	Ring, Bearing
32	97787	Screw, 11-16 x 3/4
33	8066085	Seal, Rear Drum
34	695584	Drum Assembly
35	342847	Baffle, Drum
36	3976435	Bracket, Support
37	90296	Clip
38	339956	Seal

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



**Secadora Whirlpool 7MWG445500SQ0**

**Illus. Part**  
**No. No. DESCRIPTION**

---

**ACCESSORY PARTS**

---

- 279948 Kit,  
Dryer Repair
- 346764 Kit, Hold-Down  
(Gas Dryer Mobile  
Home Installation)
- 8522199 Kit, Dryer  
Vent Testing
- 689790 Dry Rack

**PAINT, TOUCH-UP (1/2oz.)**

---

- 72017 White
- 4392899 Biscuit

**PAINT, PRESSURIZED SPRAY  
(12 oz.)**

---

- 350930 White
- 4392901 Biscuit
- 350938 Primer, Gray

**PAINT, BULK (1 qt.)**

---

- 799344 White (Uncut)
- 4392900 Biscuit (Uncut)