


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Secadora Whirlpool 7MWG66700SQ



Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas



## Secadora Whirlpool 7MWG66700SQ

<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
2	Screw, Grounding	3400859
3	Clip, Harness	3394427
4	Cap, End (L.H.)	279962
5	Connector (Timer)	3397269
6	Panel, Rear Console	8274261
7	Housing, Connector (Motor)	3395683
8	Cap, End (R.H.)	279962
9	Buzzer, Mini	694419
10	Handle & Lint Screen Assembly	349639
11	Cover, Lint Screen	8283378
12	Hinge, R.H.	3978605
	Hinge, L.H.	3978606
13	Screw, 8-18 x 5/8	487240
14	Wire, Jumper (Black)	3401684
15	Screw, Hex Head	489069
16	Top	8521918
17	Bumper, Lint Lid	17258
18	Switch, End Of Cycle	3399639
19	Knob, Control	8565944
20	Wire, Jumper (Guard On/Off)	8283276
21	Timer Assembly (60 Hz.)	8299765
22	Connector, 2-Position (Gas Valve)	3403499
23	Connector, 3-Position (Gas Valve)	3403498
24	Connector, 6-Circuit	3347243
29	Screw, 8-18 x 5/16	3390646
30	Nut, Push-In (2)	357213
31	Harness, Wiring	8299877
32	Switch, Push-To-Start	3398095

Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas



## Secadora Whirlpool 7MWG66700SQ0


<b>No.Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>33</b>	Timer Knob Assembly	8566061
<b>34</b>	Knob, Push-To-Start	8566073
<b>35</b>	Receptacle, 2-Way	717252
<b>36</b>	Terminal, Female	94614
<b>37</b>	Bracket, Control	8566052
<b>38</b>	Panel, Control	8543037
<b>39</b>	Connector	3936144
<b>40</b>	Screw, Console	487909
	ACCESSORY PARTS	
	Dry Rack	3404351

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Secadora Whirlpool 7MWG66700SQ



Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas



## Secadora Whirlpool 7MWG66700SQ

<b>No.Illus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>1</b>	Screw, 10-32 x 5/8 (External Ground)	4331106
<b>2</b>	Screw, 10-16 x 1/2	681414
<b>3</b>	Clamp, Motor (W/Shield)	3404162
<b>4</b>	Bracket, Cabinet	8541400
<b>5</b>	Cover, Block	3396795
<b>6</b>	Screw, Hex Washer Head	489069
<b>7</b>	Panel, Rear	280043
<b>8</b>	Clip, Door Spring	8546676
<b>10</b>	Door Switch Assembly	3406107
<b>11</b>	Screw, 6-20 x 7/8	3395530
<b>13</b>	Screw, 8-18 x 3/8	694091
<b>14</b>	Spring, Door (2)	8541401
<b>15</b>	Screw, 10-16 x 1/2	308685
<b>16</b>	Foot, Dryer	3392100
	Foot - Optional	279810
<b>18</b>	Cabinet (Includes Illus. 4)	8533643
<b>19</b>	Clip, Ground (2)	98234
<b>20</b>	Lock, Front Top (2)	18776
<b>21</b>	Panel Front	279740
<b>23</b>	Clip, Felt Pad (2)	279220
<b>24</b>	Catch, Door Assembly	3389441
<b>25</b>	Seal, Door	3390731
<b>26</b>	Clip, Hinge (2)	337189
<b>27</b>	Screw, 10-32 x 3/8	486146
<b>28</b>	Hinge, R.H.	8066056
	Hinge, L.H.	8066057
<b>29</b>	Clip, Front Panel	3394083

Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas



## Secadora Whirlpool 7MWG66700SQ


<b>No.Illus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>33</b>	Strike, Panel	279570
<b>35</b>	Door, Rear	695737
<b>36</b>	Door, Front	3393549
<b>37</b>	Handle, Door	690270
<b>38</b>	Seal & Bearing Assembly	3406129
<b>45</b>	Cord, Power	3401402
<b>49</b>	Plug, Front Panel	3394975
<b>51</b>	Hinge, Top (2)	238088
<b>53</b>	Idler & Pulley Assembly	691366
<b>56</b>	Belt, Drive	341241
<b>57</b>	Base, Motor	687079
<b>58</b>	Bolt, 5/16-18 x 3/4	3400500
<b>59</b>	Pulley, 60 Hz.	3394341
<b>62</b>	Motor Assembly 60 Hz.	279827
<b>63</b>	Clamp, Motor	343481
<b>67</b>	Burner Assembly, 60 Hz.	279990
<b>68</b>	Clamp, Pipe	341029

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Secadora Whirlpool 7MWG66700SQ



Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas



## Secadora Whirlpool 7MWG66700SQ

<b>No.Illus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>1</b>	Burner Assembly 60 Hz.	279990
<b>2</b>	Tube, Burner	693140
<b>3</b>	Bracket, Ignitor	694298
<b>4</b>	Ignitor	279311
<b>5</b>	Screw & Washer (8-32 x 5/8)	3393909
<b>6</b>	Screw, 10-16 x 1/2	681414
<b>7</b>	Base, Burner	693986
<b>8</b>	Screw, 8-18 x 3/8	90767
<b>9</b>	Orifice, Burner (Type 1)	234826
	Orifice, Burner (Type 4 (Butane))	229742
	Orifice, Burner (Type 4 (Propane))	234868
<b>10</b>	Valve, 60 Hz. (Includes Pipe & Illus. 7)	8318277
<b>11</b>	Screw, 8-32 x 1/2 (2)	694421
<b>12</b>	Bracket, Coil	694538
<b>13</b>	Coil, 60 Hz. (2 Terminal) (Main)	694540
<b>14</b>	Coil, 60 Hz. (Split)	694539
<b>15</b>	Leak Limiter	694424
<b>16</b>	Screw, Regulator Adjustment	694423
<b>17</b>	Spring, Regulator	694422
<b>20</b>	Plug, Pipe	239822
<b>25</b>	Clamp, Pipe	341029
	Conversion Kit L.P.G.	49572




Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Secadora Whirlpool 7MWG66700SQ



Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas



## Secadora Whirlpool 7MWG66700SQ

<b>No.Illus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
1	Lint Chute Assembly	3396352
2	Screw, 8-18 x 5/8	489463
3	Washer-Support	3388703
4	Seal, Lint Chute	347139
5	Screw, 8-18 x 3/8	90767
6	Bracket, Bulkhead	3406022
7	Fuse, Thermal	3392519
8	Drum Hole Plug	8066086
9	Thermostat, Internal-Bias	3387134
10	Wheel, Blower (Includes Illus. 21)	279711
11	Housing, Blower	8557384
12	CLIP	8066155
13	Screw, 10-16 x 1/2	681414
14	Box, Heater	279980
15	Thermostat, 205 F (96 C)	3403140
16	Kit, Thermal Cut-Off (Includes Illus. 15)	280010
17	Wire, Jumper	3401707
18	Funnel, Burner	8066049
19	Screw, 8-18 x 1/2	488729
20	Socket Assembly	3403634
21	Seal, Blower	3394196
22	Bracket, Light	3977373
23	Bulb, Light	17512
24	Lens, Light	8532165
25	Screw, 8-15 x 1/2	488729
26	Ring, Tri	690997
27	Shaft, L.H.	3399506
28	Shaft, R.H.	339489

Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas



## Secadora Whirlpool 7MWG66700SQ

<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>29</b>	Roller, Support	349241T
<b>30</b>	Washer, Support	348197
<b>31</b>	Nut, 3/8-16	3359452
<b>32</b>	Bulkhead	279798
<b>33</b>	Sensor, Radiant	338906
<b>34</b>	Ring, Bearing	279441
<b>35</b>	Screw, 11-16 x 3/4	63027
<b>36</b>	Seal, Rear Drum	279857
<b>37</b>	Drum Assembly	695587
<b>38</b>	Baffle, Drum (2)	692490
<b>39</b>	Bracket, Support	3976434
<b>40</b>	Clip	90296
<b>41</b>	Baffle, Drum (1)	3403636
<b>42</b>	Seal	339956
<b>43</b>	Shield, Exhaust	696302