


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Secadora Whirlpool 7MWGD1705YM4





# Secadora Whirlpool 7MWGD1705YM4

## TOP AND CONSOLE PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10329763	Instructions, Installation
	W10368973	Use & Care Guide
	W10185994	Wiring Diagram
2	W10117655	Switch, Push To Start
3	694419	Buzzer, Mini
4		End Cap (Left)
	8566035	White
5		Assembly, Timer Knob
	W10034750	White/Metallic
6	W10103406	Panel, Rear (Console)
7	8530169	Switch, Rotary Temperature

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
8		End Cap (Right)
	8566032	White
9	693995	Screw
10		Screen, Lint
	W10641634	White
11	8536939	Clip, Spring
12	3348629	Screw
13	688983	Screw
14	8312709	Clip, Console
15	W10640704	Harness, Wiring
16		Top
	8559800	White
17	359625	Screw


<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
18		Assembly, Control Knob
	W10034380	White/Metallic
19	3405156	Switch, Wrinkle Guard
20	3400818	Screw
21	W10185992	Timer Assembly (60 Hz.)
22	W10476828	Control, Electronic
23	W10354025	Assembly, Panel and Bracket
24	W10123956	Panel, Dampening
25	W10316616	Seal, Foam

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Secadora Whirlpool 7MWGD1705YM4





# Secadora Whirlpool 7MWGD1705YM4

## CABINET PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	8533974	Screw
2	343641	Screw
3	693995	Screw
4	W10236073	Bracket, Cabinet
5	3396795	Cover, Terminal Block
6	3404162	Clamp, Motor (With Shield)
7	W10571724	Panel, Rear
8	W10595510	Tape, Foil
9	W10575896	Clip, Spring
10	W10569603	Switch, Door
11	697773	Screw
12	341029	Clamp, Pipe
13	3357011	Screw
14	W10041960	Spring, Door
15	8066217	Hinge, Top
16	3392100	Foot, Dryer
	279810	Foot, Optional (Extended Length Package Of 2) (Not Included)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
17	342043	Screw
18		Cabinet
	8530603	White
19	98234	Clip, Ground
20	8066092	Lock, Front Top
21		Panel, Front
	W10664692	White
22	W10121316	Clamp, Motor Mount
23	685203	Clip, Felt Pad
24	3389441	Assembly, Door Catch
25	W10389571	Seal, Door
26	337189	Clip, Hinge
27	342055	Screw
28	8066056	Hinge, Door (Right)
	8066057	Hinge, Door (Left)
29	W10396032	Assembly, Motor
30	8066184	Pulley, Motor
31	3400500	Bolt


<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
32	348780	Base, Motor
33	696144	Strike, Door
34	W10131364	Belt, Drive
35	695737	Door, Rear
36		Door, Front
	3393549	White
37	W10095180	Handle, Door
38	W10663510	Assembly, Seal and Bearing
39		Plug, Front Panel
	8564457	White
40	691366	Idler Assembly
41	344020	Cord, Power
42	3394083	Clip, Front Panel
43	8318272	Burner Assembly (60 Hz) (Type 1) (White Rodgers)
44	3390631	Screw

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Secadora Whirlpool 7MWGD1705YM4





## Secadora Whirlpool 7MWGD1705YM4

### BULKHEAD PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	348368	Assembly, Lint Chute
2	489463	Screw
3	3388703	Washer
4	347139	Seal, Lint Chute
5	90767	Screw
6	90296	Nut, Push On
7	3392519	Fuse, Thermal (91C)
8	3976434	Bracket, Support
9	8318268	Thermostat
10	694089	Wheel, Blower
11	8577230	Housing, Blower
12	3398161	Clip, Heater Box
13	343641	Screw
14	8530285	Box, Heater (96C)
15	W10423382	Thermostat H.L SPST (180F)
16	W10389567	Shield, Exhaust

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
17	339956	Seal
18	8066049	Funnel, Burner Light
19	W10214261	Socket, Light
20	3406124	Bulb, Light
21	3403636	Baffle, Drum (Short)
22	3977373	Bracket, Drum Light
23	3406022	Bracket, Bulkhead Chute
24	3390647	Screw
25	3977394	Thermal Cut-Off
26	692490	Baffle, Drum (Long)
27	3976479	Pad, Sensor
28	W10512946	Washer, Tri Ring
29	W10359270	Shaft, Drum Roller - Left Hand Thread
30	W10359269	Shaft, Drum Roller - Right Hand Thread
31	3397590	Roller, Support

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
32	348197	Washer
33	W10298789	Nut, Hex
34	3403414	Bulkhead
35	338906	Sensor, Radiant
36	3402841	Lens, Drum Light
37	692526	Bearing, Ring
38	W10219342	Screw
39	W10663495	Seal, Rear Drum
40	W10389436	Assembly, Drum (Complete)

# 8318272 BURNER ASSEMBLY PARTS

USE WITH TYPE 1 - NATURAL  
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES

