



SECADORA 7MWGD1730JQ0



SECADORA 7MWGD1730JQ0

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts Literatura	5		Assembly, Timer Knob	11	3348629	Screw Tornillo
	W11298250	Instruction Installation Instrucciones de Instalacion		W11291948	Chrome Ensamble Perilla de Reloj	12	W10775189	Panel, Rear Panel Trasero
	W11297958	Use & Care Guide Guia de Uso y Cuidado	6	8312709	Clip, Console Sujetador, Consola	13	693995	Screw Tornillo
	W10876312	Wiring Diagram Diagrama Electrico	7	W10446920	Switch, Push to Start Interruptor de Encendido	14		Top
2	W11287588	Fascia & Console Assembly Ensamble Consola	8	W10648593	Switch, Rotary (4 POS) Selector de 4 Posiciones	15	W10613389	White Panel Superior Screen, Lint
3		Assembly, Control Knob	9	694419	Buzzer, Mini Alarma	16	W10662472	Collar, Lint Chute Sello, Ducto para Pelusa
	W11367370	Chrome Ensamble Perilla	10	W10185981	Assembly, Timer (60 Hz.) Ensamble Reloj	17	688983	Screw Tornillo
4	688805	Clip, Spring Resorte Perilla				18	W11248246	Harness, Wiring Arnes Principal


SECADORA 7MWGD1730JQ0



SECADORA 7MWGD1730JQ0

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10773242	Screw Tornillo	19	98234	Clip, Ground Sujetador de Tornillo a Tierra	34	W10131364	Belt, Drive Banda de Transmision
2	343641	Screw Tornillo	20	8066092	Lock, Front Top Candado Frontal Superior	35	695737	Door, Rear Puerta Trasera
3	693995	Screw Tornillo	21		Panel, Front	36		Door, Outer W10714515 White
4	W10641295	Bracket, Rear		W10664692	White Panel Frontal	37		Handle, Door W10714516 White
5	3396795	Cover, Terminal Block Cubierta Bloque de Conexiones	22	W10121316	Clamp, Motor Mount	38	W10803476	Assembly, Seal and Bearing Ensamble de Sello
6	3404162	Clamp, Motor (With Shield) Abrazadera Motor	23	685203	Clip, Felt Pad Sujetador de Felpa	39		Plug, Front Panel 8564457 White
7	W10571724	Panel, Rear Panel Trasero	24	3389441	Assembly, Door Catch Ensamble Sujetador de Puerta	40	691366	Idler Assembly Ensamble Polea para Banda
8	3390647	Screw Tornillo	25	W10823580	Seal, Door Sello de Puerta	41	W10869141	Cord, Power Cable Tomacorriente
9	W10575896	Clip, Spring Resorte Perilla	26	337189	Clip, Hinge Sujetador Bisagra	42	W10775448	Clip, Front Panel Sujetador Panel Frontal
10	W10237959	Switch, Door Interruptor de Puerta	27	342055	Screw Tornillo	43	8318272	Burner Assembly (60 Hz) (Type 1) (White Rodgers) Ensamble Quemador
11	697773	Screw Tornillo	28	8066056	Hinge, Door (Right) Puerta de Bisagra (Derecha)	44	3390631	Screw Tornillo
12	341029	Clamp, Pipe Sujetador para Tubo		8066057	Hinge, Door (Left) Puerta de Bisagra (Izquierda)	45	W10316529	Seal, Foam Espuma de Sellado
13	3357011	Screw Tornillo	29	W10396029	Assembly, Motor Ensamble Motor	46	W10841728	Seal, Spill Guard Sello de Proteccion contra Derrames
14	W10041960	Spring, Door Resorte de Puerta	30	8066184	Pulley, Motor Polea de Motor			
15	W10641296	Hinge, Top	31	3400500	Bolt Tornillo			
16	W10754507	Foot, Dryer 279810 Foot, Optional (Extended Length Package Of 2) (Not Included) Pata Niveladora	32	348780	Base, Motor Base de Motor			
17	342043	Screw Tornillo	33	696144	Strike, Door Pasador de Puerta			
18	8530603	Cabinet White Gabinete						

SECADORA 7MWGD1730JQ0




SECADORA 7MWGD1730JQ0

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10798023	Assembly, Lint Chute Ducto para Pelusa	14	8530285	Box, Heater (96C) Caja Calefactora	25	W11050897	Kit, Thermal Cut-Off (Includes Thermostat) Kit de Corte Termico
2	489463	Screw Tornillo	15	W10754607	Thermostat, High Limit SPST (180F) Termostato, Limite Alto SPST	26	W11032820	Bracket, Support Soporte
3	3388703	Washer Arandela	16	W10389567	Shield, Exhaust Protector de Escape	27	692526	Bearing, Ring Anillo de Rodamiento
4	347139	Seal, Lint Chute Sello Plastico, Ducto para Pelusa	17	339956	Seal Sello	28	W10512946	Washer, Tri Ring Arandela, Triangular
5	90767	Screw Tornillo	18	8066049	Funnel, Burner Embudo para Quemador	29	W10359270	Shaft, Drum Roller - Left Hand Thread Rodillo de Tambor, Eje Izquierdo
6	90296	Nut, Push On Tuerca de Empuje	19	W10757750	Assembly, Drum (Complete) Ensamble Tambor	30	W10359269	Shaft, Drum Roller - Right Hand Thread Rodillo de Tambor, Eje Derecho
7	3392519	Fuse, Thermal (91C) Fusible Termico	20	W10856781	Seal, Rear Drum Sello Posterior del Tambor	31	W10756057	Roller, Support Soporte del Rodillo
8	092490	Baffle, Drum (Long) Deflector del Tambor (Largo)	21	3403636	Baffle, Drum (Short) Deflector del Tambor (Corto)	32	348197	Washer Arandela
9	3387134	Thermostat Termostato	22	W10219342	Screw Tornillo	33	W10298789	Nut, Hex Tuerca Hexagonal
10	694089	Wheel, Blower Soplador de Rueda	23	3406022	Bracket, Bulkhead Chute Soporte de Canasta	34	W10714466	Bulkhead Soporte de Tambor
11	8577230	Housing, Blower Cubierta del Soplador	24	3390647	Screw Tornillo	35	338906	Sensor, Radiant Sensor
12	3398161	Clip, Heater Box Sujetador de la Caja Calefactora						
13	343641	Screw Tornillo						

SECADORA 7MWGD1730JQ0

USE WITH TYPE 1 - NATURAL,
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES



SECADORA 7MWGD1730JQ0

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	8318272	Burner Assembly (60 Hz) (Type 1) (White Rodgers) Ensamble Quemador	10	8318277	Valve, Gas (60 Hz) Valvula de Gas	18	239822	Plug, Pipe Tapon del Tubo
2	688617	Tube, Burner Tubo del Quemador	11	694421	Screw, Coil Tornillo de la Bobina			Following Parts Not Illustrated Partes No Ilustradas
3	694298	Bracket, Ignitor Soporte del Encendedor	12	694538	Bracket, Coil Soporte de la Bobina	49572A		Conversion Kit (Type 1 and 2) to Type (4) L.P.G. Kit de Conversion (Tipo 1 y 2) LP
4	686590	Ignitor Encendedor	13	694540	Coil, 60 Hz. (2 Terminal) (Main) Bobina, 60 Hz (2 Terminales) (Principal)			
5	W10366705	Screw Tornillo	14	694539	Coil, 60 Hz (Split) (3 Terminal) (Pilot Position) Bobina, 60 Hz (Separado) (3 Terminales) (Posicion Piloto)			
6	343641	Screw Tornillo	15	694424	Leak, Limiter Limitador de fugas			
7	693986	Base, Burner Base del Quemador	16	694423	Screw, Regulator Adjustment Tornillo de ajuste del regulador			
8	3387057	Screw Tornillo	17	694422	Spring, Regulator Resorte del regulador			
9		Orifice, Burner Esprea del Quemador						
	234826	Type 1 (Natural) Tipo 1 (Natural)						
	229742	Type 4 (Butane) Tipo 4 (Butano)						
	234868	Type 4 (Propane) Tipo 4 (Propano)						

OPTIONAL PARTS (NOT INCLUDED)

Piezas Opcionales (No Incluidas)

ACCESSORY PARTS

PAINT, TOUCH-UP (1/2OZ.)

PAINT, BULK (1 QT.)

Illus.

Illus.

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
	279948	Kit, Dryer Repair Kit de Reparación para Secadora
	346764	Kit, Hold Down Kit Sujetador
	8522199	Kit, Dryer Vent Testing Kit de Prueba de Ventilacion
	W10322470A	Dry Rack Estante para Secado

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White Pintura de Retoque Blanca

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut) Pintura, Blanca (Sin Cortar)

PAINT, PRESSURIZED SPRAY (12 OZ.)

Illus.

No. Part No. Description

	350930	White Pintura en Aerosol, Blanca
	350938	Gray Primer Pintura en Aerosol, Gris