


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

Secadora Maytag 7MWGD1730YW4

## TOP AND CONSOLE PARTS



Distribuidor Autorizado

**Surte Rápido.com**

Venta de Refacciones  
Electrodomesticas



Secadora Maytag 7MWGD1730YW4

## TOP AND CONSOLE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8		End Cap (Right)	18		Assembly, Control Knob
	W10329763	Instructions, Installation		8566032	White		W10034380	White/Metallic
	W10368973	Use & Care Guide	9	693995	Screw	19	3405156	Switch, Wrinkle Guard
	W10185994	Wiring Diagram	10		Screen, Lint	20	3400818	Screw
2	W10117655	Switch, Push To Start		W10641634	White	21	W10185992	Timer Assembly (60 Hz.)
3	694419	Buzzer, Mini	11	8536939	Clip, Spring	22	W10476828	Control, Electronic
4		End Cap (Left)	12	3348629	Screw	23	W10354023	Panel & Console Assembly
	8566035	White	13	688983	Screw	24	W10123956	Panel, Dampening
5		Assembly, Timer Knob	14	8312709	Clip, Console	25	W10316616	Seal, Foam
	W10034750	White/Metallic	15	W10640704	Harness, Wiring			
6	W10103406	Panel, Rear (Console)	16		Top			
				8559800	White			
7	8530169	Switch, Rotary Temperature	17	359625	Screw			


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

Secadora Maytag 7MWGD1730YW4

## CABINET PARTS



Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas



## Secadora Maytag 7MWGD1730YW4

# CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8533974	Screw
2	343641	Screw
3	693995	Screw
4	W10236073	Bracket, Cabinet
5	3396795	Cover, Terminal Block
6	3404162	Clamp, Motor (With Shield)
7	W10571724	Panel, Rear
8	3390647	Screw
9	W10575896	Clip, Spring
10	W10569603	Switch, Door
11	697773	Screw
12	341029	Clamp, Pipe
13	3357011	Screw
14	W10041960	Spring, Door
15	8066217	Hinge, Top
16	3392100	Foot, Dryer
	279810	Foot, Optional (Extended Length Package Of 2) (Not Included)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
17	342043	Screw
18		Cabinet
	8530603	White
19	98234	Clip, Ground
20	8066092	Lock, Front Top
21		Panel, Front
	W10664692	White
22	W10121316	Clamp, Motor Mount
23	685203	Clip, Felt Pad
24	3389441	Assembly, Door Catch
25	W10389571	Seal, Door
26	337189	Clip, Hinge
27	342055	Screw
28	8066056	Hinge, Door (Right)
	8066057	Hinge, Door (Left)
29	W10396032	Assembly, Motor
30	8066184	Pulley, Motor
31	3400500	Bolt

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
32	348780	Base, Motor
33	696144	Strike, Door
34	W10131364	Belt, Drive
35	695737	Door, Rear
36		Door, Outer
	3393549	White
37	W10095180	Handle, Door
38	W10663510	Assembly, Seal and Bearing
39		Plug, Front Panel
	8564457	White
40	691366	Idler Assembly
41	344020	Cord, Power
42	3394083	Clip, Front Panel
43	8318272	Burner Assembly (60 Hz) (Type 1) (White Rodgers)
44	3390631	Screw


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

Secadora Maytag 7MWGD1730YW4

## BULKHEAD PARTS



Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas



Secadora Maytag 7MWGD1730YW4

## BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	348368	Assembly, Lint Chute	15	W10423382	Thermostat H.L SPST (180F)	28	W10512946	Washer, Tri Ring
2	489463	Screw	16	W10389567	Shield, Exhaust	29	W10359270	Shaft, Drum Roller - Left Hand Thread
3	3388703	Washer	17	339956	Seal	30	W10359269	Shaft, Drum Roller - Right Hand Thread
4	347139	Seal, Lint Chute	18	8066049	Funnel, Burner Light	31	3397590	Roller, Support
5	90767	Screw	19	W10214261	Socket, Light	32	348197	Washer
6	90296	Nut, Push On	20	3406124	Bulb, Light	33	W10298789	Nut, Hex
7	3392519	Fuse, Thermal (91C)	21	3403636	Baffle, Drum (Short)	34	3403414	Bulkhead
8	692490	Baffle, Drum (Long)	22	3977373	Bracket, Drum Light	35	338906	Sensor, Radiant
9	8318268	Thermostat	23	3406022	Bracket, Bulkhead Chute	36	3402841	Lens, Drum Light
10	694089	Wheel, Blower	24	3390647	Screw	37	692526	Bearing, Ring
11	8577230	Housing, Blower	25	3977394	Thermal Cut-Off	38	W10219342	Screw
12	3398161	Clip, Heater Box	26	3976434	Bracket, Support	39	W10663495	Seal, Rear Drum
13	343641	Screw	27	3976479	Pad, Sensor	40	W10389436	Assembly, Drum (Complete)
14	8530285	Box, Heater (96C)						

Distribuidor Autorizado


SurteRápido.com

Venta de Refacciones  
Electrodomesticas

Secadora Maytag 7MWGD1730YW4

## 8318272 BURNER ASSEMBLY PARTS

USE WITH TYPE 1 – NATURAL  
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES



Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas



Secadora Maytag 7MWGD1730YW4

## 8318272 BURNER ASSEMBLY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8318272	Burner Assembly (60 Hz) (Type 1) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	W10366705	Screw
6	343641	Screw
7	693986	Base, Burner
8	3387057	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
9		Orifice, Burner
	234826	Type 1 (Natural)
	229742	Type 4 (Butane)
	234868	Type 4 (Propane)
10	8318277	Valve, Gas (60 Hz)
11	694421	Screw, Coil
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz (Split) (3 Terminal) (Pilot Position)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
15	694424	Leak, Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
18	239822	Plug, Pipe
		Following Parts Not Illustrated
	W10307153	Conversion Kit (Type 1 and 2) to Type (4) L.P.G.