


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Maytag 7MWGD1730YW5

TOP AND CONSOLE PARTS



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Secadora Maytag 7MWGD1730YW5

TOP AND CONSOLE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	8		End Cap (Right)	18		Assen
	W10329763	Instructions, Installation		8566032	White		W10034380	White
	W10368973	Use & Care Guide	9	693995	Screw	19	3405156	Switch
	W10185994	Wiring Diagram	10		Screen, Lint	20	3400818	Screw
2	W10117655	Switch, Push To Start		W10717210	White	21	W10185992	Timer
3	694419	Buzzer, Mini	11	8536939	Clip, Spring	22	W10476828	Contro
4		End Cap (Left)	12	3348629	Screw	23	W10354023	Panel
	8566035	White	13	688983	Screw			Assen
5		Assembly, Timer Knob	14	8312709	Clip, Console	24	W10123956	Panel
	W10034750	White/Metallic	15	W10640704	Harness, Wiring	25	W10316616	Seal,
6	W10103406	Panel, Rear (Console)	16		Top			
				8559800	White			
7	8530169	Switch, Rotary Temperature	17	359625	Screw			


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Maytag 7MWGD1730YW4

CABINET PARTS



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Maytag 7MWGD1730YW4

CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8533974	Screw	17	342043	Screw	32	348780	Base, Motor
2	343641	Screw	18		Cabinet	33	696144	Strike, Door
3	693995	Screw		8530603	White	34	W10131364	Belt, Drive
4	W10236073	Bracket, Cabinet	19	98234	Clip, Ground	35	695737	Door, Rear
5	3396795	Cover, Terminal Block	20	8066092	Lock, Front Top	36		Door, Outer
6	3404162	Clamp, Motor (With Shield)	21		Panel, Front		3393549	White
7	W10571724	Panel, Rear		3395197	White	37		Handle, Door
8	3390647	Screw	22	W10121316	Clamp, Motor Mount		W10095180	White
9	W10575896	Clip, Spring	23	685203	Clip, Felt Pad	38	W10663510	Assembly, Seal and Bearing
10	W10569603	Switch, Door	24	3389441	Assembly, Door Catch	39		Plug, Front Panel
11	697773	Screw	25	W10389571	Seal, Door		8564457	White
12	341029	Clamp, Pipe	26	337189	Clip, Hinge	40	691366	Idler Assembly
13	3357011	Screw	27	342055	Screw	41	344020	Cord, Power
14	W10041960	Spring, Door	28	8066056	Hinge, Door (Right)	42	3394083	Clip, Front Panel
15	8066217	Hinge, Top		8066057	Hinge, Door (Left)	43	W10336852	Burner Assembly (1/2 Hz) (Type 1 and 2)
16	3392100	Foot, Dryer	29	W10396032	Assembly, Motor	44	3390631	Screw
	279810	Foot, Optional (Extended Length Package Of 2) (Not Included)	30	8066184	Pulley, Motor			
			31	3400500	Bolt			


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Maytag 7MWGD1730YW5

BULKHEAD PARTS



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Maytag 7MWGD1730YW5

BULKHEAD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	348368	Assembly, Lint Chute	15	W10423382	Thermostat, High Limit SPST (180F)	28	W10512946	Washer, Tri Ring
2	489463	Screw	16	W10389567	Shield, Exhaust	29	W10359270	Shaft, Drum Roller - Left Hand Thread
3	3388703	Washer	17	339956	Seal	30	W10359269	Shaft, Drum Roller - Right Hand Thread
4	347139	Seal, Lint Chute	18	8066049	Funnel, Burner Light	31	3397590	Roller, Support
5	90767	Screw	19	W10214261	Socket, Light	32	348197	Washer
6	90296	Nut, Push On	20	3406124	Bulb, Light	33	W10298789	Nut, Hex
7	3392519	Fuse, Thermal (91C)	21	3403636	Baffle, Drum (Short)	34	3403414	Bulkhead
8	692490	Baffle, Drum (Long)	22	3977373	Bracket, Drum Light	35	338906	Sensor, Radiant
9	8318268	Thermostat	23	3406022	Bracket, Bulkhead Chute	36	3402841	Lens, Drum Light
10	694089	Wheel, Blower	24	3390647	Screw	37	692526	Bearing, Ring
11	8577230	Housing, Blower	25	3977394	Thermal Cut-Off	38	W10219342	Screw
12	3398161	Clip, Heater Box	26	3976434	Bracket, Support	39	W10663495	Seal, Rear Drum
13	343641	Screw	27	3976479	Pad, Sensor	40	W10389436	Assembly, Drum (Complete)
14	8530285	Box, Heater (96C)						

Distribuidor Autorizado


SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Maytag 7MWGD1730YW5

W10336852 BURNER ASSEMBLY PARTS

USE WITH TYPE 1 - NATURAL, TYPE 2 - MIXED,
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



Secadora Maytag 7MWGD1730YW5

W10336852 BURNER ASSEMBLY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10336852	Burner Assembly (60 Hz) (Type 1 and 2)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	W10366705	Screw
6	343641	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	693986	Base, Burner
8	3387057	Screw
9		Orifice, Burner
	234826	Type 1 (Natural)
10	W10304604	Valve, Gas (60 Hz)
11	W10295523	Pipe Plug

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
12	3389889	Bracket, Support
13	W10328463	Coil (60 Hz)
14	326049536	Screw
		Following Parts Not Illustrated
	W10307153	Conversion Kit (Type 1 and 2) to Type (4) L.P.G.