


# SECADORA 7MWGD1800EM2






# SECADORA 7MWGD1800EM2

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10829632	Installation Instructions
	W10829619	Use and Care Guide
	W10876312	Wiring Diagram
2		Assembly, Panel & Bracket
	W10775960	White
3	694419	Buzzer, Mini
4		End Cap (Left)
	W10520782	White
5	8312709	Clip, Console
6	W10556829	Panel, Rear (Console)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10661453	Switch, Temperature
8		End Cap (Right)
	W10520780	White
9	693995	Screw
10		Lint Screen
	W11451394	White
11	688805	Clip, Spring
12	693995	Screw
13	688983	Screw
14	W10773242	Screw
15	3348629	Screw
16		Top
	W10225059	White

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
17	W10117655	Switch, Push To Start
18		Assembly, Control Knob
	W10576636	White/Metallic
19		Assembly, Timer Knob
	W10576634	White/Metallic
20	W10185981	Assembly, Timer (60 HZ.)
21	W10872688	Harness, Wiring
22	W10316529	Seal, Foam
23	3400818	Screw
24	W10556828	Control Bracket

# SECADORA 7MWGD1800EM2





# SECADORA 7MWGD1800EM2

**Illus.**  
**No.**    **Part No.**    **Description**

1	W10773242	Screw
2	3390631	Screw
3	693995	Screw
4	W10841728	Seal, Spill Guard
5	3396795	Cover, Terminal Block
6	3404162	Clamp, Motor (With Shield)
7	W10571724	Panel, Rear
8	W10041960	Spring, Door
9	W10569603	Switch, Door
10	697773	Screw
11	342055	Screw
12	W10575896	Clip, Spring
13	W10561321	Foot, Dryer
14	3357011	Screw
15		Cabinet
	8530603	White
16	98234	Clip, Ground
17	8066092	Lock, Front Top


**Illus.**  
**No.**    **Part No.**    **Description**

18		Panel, Front
	W10664692	White
19	685203	Clip, Felt Pad
20	3389441	Assembly, Door Catch
21	W10823580	Seal, Door
22	343641	Screw
23	341029	Clamp, Pipe
24	8066056	Hinge, Door (Right)
	8066057	Hinge, Door (Left)
25	W10727507	Clamp, Pipe
26	695737	Door, Rear
27		Door, Outer
	W10714515	White
28		Handle, Door
	W10714516	White
29	W10803476	Assembly, Seal and Bearing
30		Plug, Hinge Hole
	8564457	White

**Illus.**  
**No.**    **Part No.**    **Description**

31	W10869141	Cord, Power
32	W10775448	Clip, Front Panel
33	8066217	Hinge, Top
34	691366	Idler Assembly
35	W10131364	Belt, Drive
36	348780	Base, Motor
37	3400500	Bolt
38	8066184	Pulley, Motor
39	W10396029	Assembly, Motor
40	W10121316	Clamp, Motor Mount
41	8318272	Burner Assembly (60 Hz) (Type 1) (White Rodgers)
42	337189	Clip, Hinge
43	342043	Screw
44	696144	Strike, Door
45	W10316619	Seal, Spill Guard

# SECADORA 7MWGD1800EM2





# SECADORA 7MWGD1800EM2

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10798023	Assembly, Lint Chute
2	489463	Screw
3	3388703	Washer
4	347139	Seal, Lint Chute
5	90767	Screw
6	339956	Seal
7	3392519	Fuse, Thermal (91C)
8	W10856781	Seal, Rear Drum
9	3387134	Thermostat
10	694089	Wheel, Blower
11	8577230	Housing, Blower
12	3398161	Clip, Heater Box
13	3390631	Screw
14	8530285	Box, Heater (96C)
15	W10754607	Thermostat, High Limit SPST (180F)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
16	W10480709	Kit, Thermal Cut-Off (Includes Thermostat)
17	3390647	Screw
18	8066049	Funnel, Burner
19	3403636	Baffle, Drum (Short)
20	90296	Nut, Push On
21	3976434	Bracket, Support
22	3406022	Bracket, Bulkhead Chute
23	W10389567	Shield, Exhaust
24	W10512946	Washer, Tri Ring
25	W10359270	Shaft, Drum Roller - Left Hand Thread
26	W10359269	Shaft, Drum Roller - Right Hand Thread
27	W10756057	Roller, Support

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
28	348197	Washer
29	W10298789	Nut, Hex
30	3403413	Bulkhead
31	338906	Sensor, Radiant
32	692490	Baffle, Drum (Long)
33	692526	Bearing, Ring
34	W10219342	Screw
35	W10757750	Assembly, Drum (Complete)
36	8578825	Bracket, Drum Light
37	W10214261	Socket, Light
38	3406124	Bulb, Light
39	3402841	Lens, Drum Light



# SECADORA 7MWGD1800EM2

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	8318272	Burner Assembly (60 Hz) (Type 1) (White Rodgers) Ensamble Quemador	10	8318277	Valve, Gas (60 Hz) Valvula de Gas	18	239822	Plug, Pipe Tapon del Tubo
2	688617	Tube, Burner Tubo del Quemador	11	694421	Screw, Coil Tornillo de la Bobina			Following Parts Not Illustrated Partes No Ilustradas
3	694298	Bracket, Ignitor Soporte del Encendedor	12	694538	Bracket, Coil Soporte de la Bobina		49572A	Conversion Kit (Type 1 and 2) to Type (4) L.P.G. Kit de Conversion (Tipo 1 y 2) LP
4	686590	Ignitor Encendedor	13	694540	Coil, 60 Hz. (2 Terminal) (Main) Bobina, 60 Hz (2 Terminales) (Principal)			
5	W10366705	Screw Tornillo	14	694539	Coil, 60 Hz (Split) (3 Terminal) (Pilot Position) Bobina, 60 Hz (Separado) (3 Terminales) (Posicion Piloto)			
6	343641	Screw Tornillo	15	694424	Leak, Limiter Limitador de fugas			
7	693986	Base, Burner Base del Quemador	16	694423	Screw, Regulator Adjustment Tornillo de ajuste del regulador			
8	3387057	Screw Tornillo	17	694422	Spring, Regulator Resorte del regulador			
9		Orifice, Burner Esprea del Quemador						
	234826	Type 1 (Natural) Tipo 1 (Natural)						
	229742	Type 4 (Butane) Tipo 4 (Butano)						
	234868	Type 4 (Propane) Tipo 4 (Propano)						

# OPTIONAL PARTS (NOT INCLUDED)

## PAINT, TOUCH-UP (1/2OZ.)

Illus.

No.   Part No.   Description

72017   White  
Pintura de Retoque  
Blanca

## PAINT, PRESSURIZED SPRAY (12 OZ.)

Illus.

No.   Part No.   Description

350930   White  
Pintura en Aerosol,  
Blanca

350938   Gray Primer  
Pintura en Aerosol,  
Gris

## PAINT, BULK (1 QT.)

Illus.

No.   Part No.   Description

799344   White (Uncut)  
Pintura, Blanca (Sin  
Cortar)

## ACCESSORY PARTS

Illus.

No.   Part No.   Description

279948   Kit, Dryer Repair  
  
Kit de Reparación para  
Secadora

346764   Kit, Hold Down  
Kit Sujetador

8522199   Kit, Dryer Vent Testing  
  
Kit de Prueba de  
Ventilacion

W10322470A   Dry Rack  
Estante para Secado