




Secadora Whirlpool 7MWGD1900DW2

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	Literature Parts W10652257 Use and Care Guide		9	693995	Screw	20	W10185992	Timer Assembly (60 Hz.)
	W10658639 Installation Instructions		10		Screen, Lint	21	W10640708	Harness, Wiring
	W10663990 Diagram, Wiring			W10717210	White	22	3405155	Switch, Temperature
2	Assembly, Console		11	8536939	Clip, Spring	23	W10556828	Bracket, Control
	W10643287 White		12	3400818	Screw	24	W10476828	Control, Electronic
3	694419 Buzzer, Mini		13	688983	Screw			
4	End Cap (Left) W10520782 White		14	8533974	Screw			
5	8312709 Clip, Console		15	3348629	Screw			
6	W10556829 Panel, Rear (Console)		16	Top				
7	3405156 Switch, Wrinkle Guard			8559800	White			
8	End Cap (Right) W10520780 White		17	W10117655	Switch, Push ToStart			
			18	Assembly, Control Knob	W10576637			
					White/Metallic			
			19	Assembly, Timer Knob	W10576635			
					White/Metallic			






Secadora Whirlpool 7MWGD1900DW2

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	8533974	Screw
2	3390631	Screw
3	693995	Screw
4	W10236073	Bracket, Cabinet
5	3396795	Cover, TerminalBlock
6	3404162	Clamp, Motor (With Shield)
7	W10571724	Panel, Rear
8	W10575896	Clip, Spring
9	W10569603	Switch, Door
10	697773	Screw
11	342055	Screw
12	342043	Screw
13	W10561321	Foot, Dryer
14	W10041960	Spring, Door Cabinet
15	8530603	White
16	98234	Clip, Ground

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
17	8066092	Lock, Front Top
18		Panel, Front
	3395197	White
19	685203	Clip, Felt Pad
20	3389441	Assembly, DoorCatch
21	W10389571	Seal, Door
22	343641	Screw
23	341029	Clamp, Pipe
24	8066056	Hinge, Door (Right)
	8066057	Hinge, Door (Left)
25	696144	Strike, Door
26	695737	Door, Rear
27		Door, Outer
	3393549	White
28		Handle, Door W10861225 White
29	W10663510	Assembly, Seal and Bearing

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
30		Plug, Hinge Hole 8564457 White
31	344020	Cord, Power
32	3394083	Clip, Front Panel
33	8066217	Hinge, Top
34	691366	Idler Assembly
35	W10131364	Belt, Drive
36	348780	Base, Motor
37	3400500	Bolt
38	8066184	Pulley, Motor
39	W10396029	Assembly, Motor
40	W10121316	Clamp, Motor Mount
41	W10336852	Burner Assembly (60 Hz) (Type 1 and 2)
42	337189	Clip, Hinge
43	3357011	Screw

Secadora Whirlpool 7MWGD1900DW2






Secadora Whirlpool 7MWGD1900DW2

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	348368	Assembly, Lint Chute
2	489463	Screw
3	3388703	Washer
4	347139	Seal, Lint Chute
5	90767	Screw
6	W10389567	Shield, Exhaust
7	3392519	Fuse, Thermal (91C)
8	3976479	Pad, Sensor
9	8318268	Thermostat
10	694089	Wheel, Blower
11	8577230	Housing, Blower
12	3398161	Clip, Heater Box
13	3390631	Screw
14	8530285	Box, Heater (96C)
15	W10423382	Thermostat, High Limit SPST (180F)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
16	3977394	Thermal Cut-Off
17	3390647	Screw
18	8066049	Funnel, Burner Light
19	W10214261	Socket, Light
20	3406124	Bulb, Light
21	3977373	Bracket, Drum Light
22	3406022	Bracket, Bulkhead Chute
23	339956	Seal
24	W10512946	Washer, Tri Ring
25	W10359270	Shaft, Drum Roller -Left Hand Thread
26	W10359269	Shaft, Drum Roller - Right Hand Thread
27	3397590	Roller, Support
28	348197	Washer
29	W10298789	Nut, Hex

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
30	3403414	Bulkhead
31	338906	Sensor, Radiant
32	3402841	Lens, Drum Light
33	692526	Bearing, Ring
34	W10219342	Screw
35	W10663495	Seal, Rear Drum
36	W10389436	Assembly, Drum (Complete)
37	692490	Baffle, Drum (Long)
38	3976434	Bracket, Support
39	90296	Nut, Push On
40	3403636	Baffle, Drum (Short)

USE WITH TYPE 1 - NATURAL, TYPE 2 - MIXED,
 TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES





Secadora Whirlpool 7MWGD1900DW2

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10336852	Burner Assembly (60 Hz) (Type 1 and 2)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	W10366705	Screw
6	343641	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
7	693986	Base, Burner
8	3387057	Screw
9	234826	Orifice, Burner Type 1 (Natural)
10	W10304604	Valve, Gas (60 Hz)
11	W10295523	Pipe Plug

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
12	3389889	Bracket, Support
13	W10328463	Coil (60 Hz)
14	326049536	Screw
		Following Parts Not Illustrated
		W10307153 Conversion Kit (Type 1 and 2) to Type (4) L.P.G.

OPTIONAL PARTS (NOT INCLUDED)

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	8522199	Kit, Dryer Vent Testing
	8529894	Kit, Hold Down
	80047	Kit, Dryer Repair
	W10322470A	Dry Rack

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350938	Gray Primer