





Secadora Whirlpool 7MWGD5550XW0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST




Secadora Whirlpool 7MWGD5550XW0

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10329763	Installation Instructions
	W10329761	Guide, Use & Care
	W10097033	Tech Sheet
2	W10329788	Panel, Console
3	W10251392	Knob Assembly
4	W10269624	User Interface
5	W10298336	Nut, 8-18 U-Type

Illus. No.	Part No.	DESCRIPTION
6	W10274524	Tensioner
7	W10280079	Seal, Console
8	W10285495	Cable, User Interface
9	W10096969	Panel, Rear Console
10	8533971	Screw, 8-16 x 5/16
11	W10325119	Spacer, Knob
12	W10260246	Top
13	3390647	Screw, 8-18 x 1/2
14	8312709	Clip, Console
15	W10338363	Cover, Terminal Block

Illus. No.	Part No.	DESCRIPTION
16	W10279552	Plug, Upper Rear Panel
17	3390814	Screw, 8-18 x 1/2
18	8536939	Clip, Spring
19	W10253982	Harness, Wiring
20	W10323092	Seal, UI
21	W10219342	Screw, 8-16 x 1/2
22	W10271580	Bracket, Motor
23	W10331077	Control, Electronic
24	W10123956	Panel, Dampening




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



Secadora Whirlpool 7MWGD5550XW0

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	697773	Screw, 6-20 x 7/8	18	W10121334	Washer, Thrust	37	3387242	Seal, Front Panel
2	8529757	Bracket, Burner	19	W10291934	Clip (2)	38	696144	Strike, Door
3	3390647	Screw, 8-18 x 1/2	20	690997	Tri-Ring	39	3388674	Idler Bracket
4	3394331	Plate, Cover	21	3387560	Hinge, Door (R.H.)	40	3357011	Screw, 10-16 x 1/2
5	W10246525	Switch, Broken Belt		3387559	Hinge, Door (L.H.)	41	3406107	Door Switch Assembly
6	344020	Cord, Power	22	3387565	Spring, Door (2)	42	W10325058	Door Seal
7	8310656	Cabinet	23	8066045	Door, Rear	43	690081	Catch, Door Assembly
8	3392100	Foot, Dryer	24	3388229	Retainer	44	W10279553	Door, Front
	279810	Foot - Optional (Extended Length Package Of 2) (Not Included)	25	49026	4" - 90 Elbow	45	697215	Toe Panel (Includes Illus. 36)
9	660658	Clamp, Motor (2)	26	697227	Upper Front Panel	46	W10336128	Foam, Cabinet
10	3387374	Spring, Idler	27	8538263	Motor, Assembly 60 HZ.	47	W10312811	Foam Seal
11	3389420	Retainer, Idler	28	8563750	Exhaust Pipe (Short)	Optional Parts Not Included		
12	49252	White Plug, Multivent	29	8578220	Pulley, Motor	Dryer Exhaust Kit		
13	3388672	Pulley Assembly	30	3387610	Belt, Drive	(For Side & Bottom Venting)		
14	343641	Screw, 10-16 x 1/2	31	693995	Screw, 8-18 x 3/8			
15	8533971	Screw, Ground	32	W10242878	Bracket, Motor	49 W10331132 White		
16	342055	Screw, 8-18 x 3/8	33	8563749	Exhaust Pipe (Long)			
17	8563747	Exhaust Pipe & Bracket	34	W10236068	Bracket, Cabinet			
			35	W10284093	Handle, Door			
			36	693152	Bumper			




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



Secadora Whirlpool 7MWGD5550XW0

Illus. Part	Illus. Part	Illus. Part
No. No. DESCRIPTION	No. No. DESCRIPTION	No. No. DESCRIPTION
1 W10359271 Shaft, Drum Roller (R.H.) Threads	16 W10001120 Nut, 3/8-16 (L.H.)	34 3387223 Electrode, Sensor
2 3390647 Screw, 8-18 x 1/2	17 8520836 Bulkhead, Rear	35 3402841 Lens, Drum Light
3 90767 Screw, 8-18 x 3/8	18 3387459 Washer, Support	36 3406124 Bulb, Light
4 3394986 Spring, Lint Screen Door	19 W10359272 Shaft, Roller Drum (L.H.) Threads	37 697772 Wheel, Blower
5 W10293765 Air Duct Assembly	20 690997 Ring, Tri	38 8578825 Bracket, Light
6 697813 Seal, Outlet Housing	21 W10314171 Roller, Support	39 W10214261 Socket, Assembly
7 697814 Seal, Drum Front	22 695240 Screw, 8-18 x 1/2	40 697770 Seal, Cover Plate
8 3934666 Nut, 3/8 x 16(R.H.)	23 W10153423 Outlet Housing Assembly	41 W10049370 Lint Screen
9 338906 Sensor, Radiant	24 359625 Screw, 8-18 x 1/2	42 8577274 Thermostat, Internal Bias
10 3387230 Screw, 10-16 x 3/16	25 8318215 Complete Drum Assembly	43 3391912 Thermostat, High-Limit (255)
11 W10153414 Housing, Outlet	26 W10219342 Screw, 8-16 x 3/4	44 8544362 Housing, Blower
12 8066208 Clip, Spring	27 W10166807 Seal, Drum	45 8066168 Lint Duct Assembly
13 697693 Baffle, Drum	28 8533971 Screw	46 8573824 Funnel, Burner
14 W10153413 Door, Lint Screen	29 697557 Bulkhead, Front	47 W10298258 Harness, Sensor
15 8066224 Exhaust Pipe	30 8572105 Clip, Exhaust	48 8573713 Thermal, Cutoff
	31 489463 Screw	49 3401707 Jumper, TCO-High Limit
	32 W10153412 Grille, Outlet	50 W10305870 Harness, Gas
	33 3392519 Thermal Fuse	

USE WITH TYPE 1 - NATURAL
 AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

USE WITH TYPE 1 – NATURAL
 AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES

Illus. No.	Part No.	DESCRIPTION
1	8576353	Burner Assembly 60 Hz. (Type 1) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8-32 x 7/8)
6	343641	Screw, 10-16 x 1/2
7	3389871	Base, Burner
8	3387057	Screw, 8-18 x 3/8
9		Orifice, Burner
	15418	Type 1
	15422	Type 4 (Butane)
	234867	Type 4 (Propane)
10	W10118347	Valve, Gas 60 Hz. (Complete) (Includes Pipe & Illus. #7).
11	694421	Screw, 8-32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak, Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
18	3390647	Screw, 8-18 x 1/2
20	239822	Plug, Pipe
25	3387561	Clamp, Pipe
26	3389889	Bracket, Support

Following Parts Not Illustrated

8576846 Conversion Kit
(Type 1)
to Type (4) LPG).



Secadora Whirlpool 7MWGD5550XW0

Illus. Part
No. No. DESCRIPTION

ACCESSORY PARTS

- 80047 Kit,
Dryer Repair
- 8522199 Kit, Dryer
Vent Testing
- 346764 Kit, Hold-Down
(Gas Dryer Mobile
Home Installation)
- W10071550A Dry Rack

PAINT, TOUCH-UP (1/2oz.)

- 72017 White

PAINT, PRESSURIZED SPRAY
(12 oz.)

- 350930 White
- 350938 Primer, Gray

PAINT, BULK (1 qt.)

- 799344 White (Uncut)