




Secadora Whirlpool 7MWGD8000EW2

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10807522	Installation Instructions
	W10807508	Owners Manual
	W10777449	Tech Sheet
	W10809795	Quickstart Guide
2		Assembly, Console
	W10806854	White
3	W10777444	Wiring Harness
4	W10123956	Panel, Dampening

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
5	W10593673	Harness, User Interface
6	W10728156	Screw
7	W10298336	Nut, "U"
8	W10726632	Seal, Console
9	W10622402	Panel, Rear Console
10	W10219342	Screw
11	W10739352	Control, Electronic
12		Top
	W10508981	White

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
13	9740848	Screw
14	8312709	Clip, Console
15	8317339	Cover, Terminal Block
16	W10631629	Console Mount (Right)
17	W10631630	Console Mount (Left)
18	W10791315	Fascia
19	W10568405	Assembly, Speaker
20	W10460893	Screw

Secadora Whirlpool 7MWGD8000EW2






**Secadora Whirlpool 7MWGD8000EW2**

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	8533974	Screw
2	W10613683	Base, Cabinet
3	W10636208	Screw
4	3397659	Block, Terminal
5	W10824895	Panel, Rear
6	693995	Screw
7		Panel, Side (Right)
	W10645768	White (With Cutout)
		Panel, Side (Left)
	W10633648	White (Without Cutout)
8	3392100	Foot, Dryer
	279810	Foot, Optional (Extended Length Package Of 2) (Not Included)
9	W10121316	Clamp, Motor Mount
10	W10446781	Spring, Idler
11	3389420	Screw
12	488729	Screw
13	W10468057	Assembly, Pulley
14	279318	Terminal, Brass and Tinned (Includes Terminal Block Screw Kit)
15	6-920119	Screw
16	W10632348	Spacer Bracket, Upper

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
17	W10778071	Strike
18	W10512946	Washer, Tri Ring
19	W10632347	Spacer Bracket, Lower
20		Panel - Rear, Dryer Bulkhead
	W10672088	White
21	W10596959	Bracket, Hinge
22	W10622391	Bracket, Rear Panel Upper
23		Plug, Hinge
	W10590953	White
24	W10316616	Seal, Foam
25	W10660592	Screw
26	W10111888	Plug, Strike
27	W10806759	Assembly, Motor
28	W10622383	Ballast
29	W10669447	Pulley, Motor
30	W10610882	Belt, Drive
31		Panel, Front
	W10861063	White
32	W10578053	Bracket, Motor Mounting
33	279393	Screw Kit, Terminal Block
34	W10459026	Switch, Door
35	W10722502	Brace, Cab and Seal Assembly
36	W10704731	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
37	W10706056	Cord, Power
38	343641	Screw
39	W10547287	Assembly, Idler
40	3400805	Screw (Zinc)
41	3387242	Seal, Front Panel
42	W10774832	Switch, Broken Belt
43		Plug, Front Panel
	8564457	White
44	8529757	Bracket, Burner
45	8563749	Pipe, Exhaust (Long)
46	W10587890	Pipe, Exhaust (Medium)
47	W10331278	Pipe, Exhaust (Short)
48	W10416072	Elbow
49	W10354249	Plate, Cover
50		Plug, Multivent
	W10404617	White
51	W10344699	Collar, Duct
		Optional Parts Not Included Dryer Exhaust Kit (For Side & Bottom Venting)
52	W10704365	Kit, 4-Way Vent

Secadora Whirlpool 7MWGD8000EW2






Secadora Whirlpool 7MWGD8000EW2

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10359271	Shaft, Drum Roller - Right Hand Thread
2	489463	Screw
3	3390647	Screw
4	W10608808	Door, Lint Screen
5	W10834203	Duct, Inlet Assembly
6	W10701355	Seal, Housing Outlet to Lint Duct
7	3387230	Screw
8	3934666	Nut, Hex
9	W10657328	Sensor Jumper, Moisture
10	W10629046	Assembly, Drum Light
11	693995	Screw
12	3357011	Screw
13		Screen, Lint W10608811 White
14	W10651569	Thermistor, Gas Inlet
15	338906	Sensor, Radiant

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
16	W10001120	Nut, Hex (Left Hand Thread)
17	W10638203	Bulkhead, Rear
18	3387459	Washer
19	W10359272	Shaft, Drum Roller - Left Hand Thread
20	W10512946	Washer, Tri Ring
21	W10314171	Roller, Support
22	W10567155	Screw
23	W10608812	Assembly, Outlet Housing
24	W10219015	Spring, Lint Screen Door
25	W10626460	Assembly, Drum
26	W10219342	Screw
27	W10664120	Seal, Drum
28	W10767090	Baffle, Drum Low
29	W10767074	Baffle, Drum High
30	693995	Screw
31	90767	Screw
32	W10608817	Pipe, Exhaust

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
33	697770	Seal, Plate Cover
34	W10608814	Sensor, Electrode
35	W10344699	Collar, Duct
36	W10608806	Housing, Outlet
37	697772	Wheel, Blower
38	W10608815	Spring Clip, Lint Screen
39	W10861007	Bulkhead, Front
40	W10608813	Grille, Outlet
41	W10693363	Fuse, Thermal (91C)
42	8577274	Thermistor
43	3391912	Thermostat, Hi Limit
44	W10667717	Housing, Blower
45	W10608803	Assembly, Lint Duct
46	8573824	Funnel, Burner
47	8573713	Cut-Off, Thermal
48	359702	Cap





**Secadora Whirlpool 7MWGD8000EW2**


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Outer
	W10614976	Black
2		Bezel, Door Catch
	W10631401	White
3	9742177	Screw
4		Assembly, Inner Door
	W10614997	White

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5	W10783754	Door, Hinge (Upper)
6	W10783755	Door, Hinge (Lower)
7		Hinge Cover, Top
	W10631395	White
8	W10610880	Assembly, Door Catch
9	W10763835	Seal, Door

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
10		Hinge Cover, Bottom
	W10631396	White
11		Cover, Door Catch
	W10631410	White
12	342055	Screw



USE WITH TYPE 1 - NATURAL,  
 AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES





## Secadora Whirlpool 7MWGD8000EW2

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10608838	Burner Assembly
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	W10366705	Screw
6	343641	Screw
7	3389871	Base, Burner
8	3387057	Screw
9		Orifice, Burner 15418 Type 1 (Natural)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
10	W10118312	Valve, Gas 60 Hz. (Complete)
11	694421	Screw, Coil
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz (Split) (3 Terminal) (Pilot Position)
15	694424	Leak, Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
18	3390647	Screw
19	239822	Plug, Pipe
20	3978776	Bracket, Gas Pipe
21	3389889	Bracket, Support
		Following Parts Not Illustrated
	8576846	Conversion Kit (Type 1 to Type 4 LPG)

# OPTIONAL PARTS (NOT INCLUDED)

## PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	W10446202	Chrome Shadow

## PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350938	Gray Primer

## PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

## ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	279948	Kit, Dryer Repair
	346764	Kit, Hold Down
	W10242307	Washer, Hose
	3976300	Washer, Inlet Hose
	W10336486	Connector, Hose -"Y"
	W10636192	Dry Rack

**ACCESSORY PARTS|THE FOLLOWING POWER CORD CAN BE ORDERED. IMPORTANT: CHECK LOCAL WIRING CODE REQUIREMENTS TO SEE IF ONE OF THESE MEETS YOUR NEEDS.**

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	PT220L	4', 30 Amp, 4 Wire, Dryer Cord
	PT400L	4', 30 Amp, 4 Wire, Dryer Cord
	PT600L	6', 30 Amp, 4 Wire, Dryer Cord