


Lavadora Whirlpool 7MWTW1501AW0




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



Lavadora Whirlpool 7MWTW1501AW0

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10329765	Installation Instructions
	W10454963	Use & Care Guide
	W10280489	Tech Sheet
	W10454967	Energy Guide
2	W10251299	Top
3	W10251302	Lid
		(Includes Item 4)
4	9724509	Bumper, Lid
5	9740848	Screw, 8-18 x 1/2
6	91770	Hinge, Lid
7	W10119872	Screw, Lid Hinge
8	W10240513	Strike, Lid Lock
9	W10273971	Screw, 6-19 x 1/2
10	W10192089	Dispenser, Bleach
11	W10392041	Bezel, Lid Lock
12	21258	Bearing, Lid Hinge
13	90016	Clip, Lid
		Lock Harness
14	W10238287	Latch, Lid
		Lock Assembly
15	8281163	Screw, 8-16 x 1/2
16	W10250884	Panel, Rear
17	W10251994	Cabinet
		(Includes Item 22)
18	W10215098	Brace, Cabinet
		Top - Front
19	W10215099	Brace, Cabinet
		Top - Rear
20	1157158	Screw, 8-18 x 3/8
21	W10248088	Lock, Top
22	W10335586	Foot Assembly, Leveling
23	W10215102	Hinge, Top
24	W10142728	Screw, 8-32 x 3/8
25	W10215139	Cover, Harness
26	3400076	Screw, 10-23 x 5/8
27	W10221546	Hose, Outer Drain Assembly (Includes Items 28 & 29)
28	W10280024	U-Bend,
29		Drain Hose
	356138	Clamp, Hose
30	W10339879	Cable Tie
31	3359452	Nut, Locking




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



Lavadora Whirlpool 7MWTW1501AW0

Illus. No.	Part No.	DESCRIPTION
1	W10465109	Panel, Console
2	8536939	Clip, Knob
3	8566035	Cap, End (L.H.) (Includes Item 5)
4	8566032	Cap, End (R.H.) (Includes Item 5)
5	8312709	Clip, Console
6	W10460940	Control Unit Assembly, Machine & Motor
7	W10420985	Panel, Console Rear Cover
8	1157158	Screw, 8-18 x 3/8
9	W10268911	Switch, Water Level
10	90767	Screw, 8-18 x 3/8
11	W10276649	Cord, Power
12	3400076	Screw, Power Cord Ground
13	W10034750	Knob, Timer
14	W10034380	Knob, Control
15	W10285512	Switch, Rotary Encoder
16	W10291178	Harness, Upper
17	W10432360	Inlet Assembly, Water
18	W10352256	Valve, Water Mixing
19	W10441423	Vacuum Break
20	W10238347	Hose, Vacuum Break
21	W10117298	Clamp, Hose
22	W10344775	Harness, Valve
23	8281163	Screw, 8-16 x 1/2
24	3400818	Screw, 8-18 x .20
25	W10348582	Clamp
26	W10251309	Pushbutton, Start

Lavadora Whirlpool 7MWTW1501AW0




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



Lavadora Whirlpool 7MWTW1501AW0

Illus. No.	Part No.	DESCRIPTION
1	63580	Dispenser, Fabric Softener
2	W10003790	Screw & Washer Assembly
3	3949550	Washer
4	63235	Agitator
5	W10215108	Ring, Tub
6	21366	Nut, Spanner
7	W10389330	Basket Assembly
8	389140	Block, Basket Drive
9	W10339098	Shield, Splash
10	W10238320	Tub (Includes Item 11)
11	W10006371	Seal, Tub
12	W10215093	Filter, Drain Pump
13	8533928	Screw, 8-18 x 3/4
14	W10257088	Damper Assembly, Tub Suspension (Set Of 4-Includes Items 15 & 16)
15	W10405423	Ball, Suspension (Set Of 4 - Includes Item 16)
16	W10256551	Bushing, Suspension (Set Of 4 - Includes Item 15)
17	W10297444	Harness, Lower (Includes Items 18 & 21)
18	W10297436	Hose, Pressure Switch
19	W10005430	Clamp, Pressure Hose Retainer
20	8533943	Screw, 10-16 x 3/4
21	W10298887	Cable Tie
22	W10348658	Spring, Tub Centering
23	W10429200	Retainer, Push In



Illus. No.	Part No.	DESCRIPTION
1	W10276397	Pump Assembly, Drain
2	W10004910	Screw, 12-16 x 1.25
3	W10215091	Hose, Inner Drain Assembly
4	8317496	Clamp, Hose
5	W10006378	Gearcase Assembly
6	W10249633	Screw, 7.2-1.6 x 30
7	W10006425	Motor, Drive
8	W10094780	Screw, M8-1.25 x 20
9	W10006382	Spring, Splutch (Includes Items 10, 11, 12 & 13)
10	W10006352	Slider, Splutch (Includes Items 9, 11, 12 & 13)
11	W10006353	Cam Ring, Splutch (Includes Items 9, 10, 12 & 13)
12	W10006354	Cam, Splutch (Includes Items 9, 10, 11 & 13)
13	W10006356	Pulley
14	W10163336	Nut, Pulley
15	W10006384	Belt, Drive
16	W10006355	Actuator, Shift
17	9741052	Screw, 6-32 x 1.00
18	W10278556	Capacitor, Motor Run
19	357640	Screw, 10-16 x 5/8
20	W10006383	Shield, Pulley Cover