




Lavadora Whirlpool 7MWTW1501AW1

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10478095	Installation Instructions
	W10481431	Use & Care Guide
	W10468340	Tech Sheet
	W10454967	Energy Guide
2		Top
	W10251299	White
3		Lid & Bumper Assembly
	W10251302	White
4	9724509	Bumper, Lid
5	9740848	Screw
6	91770	Hinge, Lid
7	W10119872	Screw
8	W10240513	Strike, Lid Lock
9	W10273971	Screw
10	W10192089	Dispenser, Bleach
11	W10392041	Bezel, Lid Lock
12	21258	Bearing, Lid Hinge
13	90016	Clip, Harness
14	W10238287	Latch, Lid Lock Assembly
15	8281163	Screw
16	W10250884	Panel Rear
17		Cabinet
	W10251994	White
18	W10215098	Brace, Cabinet Top - Front
19	W10215099	Brace, Cabinet Top - Rear
20	1157158	Screw
21	W10248088	Lock, Top
22	W10397767	Foot Assembly, Leveling
23	W10215102	Hinge, Top
24	W10142728	Screw
25	W10215139	Cover, Harness
26	3400076	Screw
27	W10221546	Hose, Outer Drain Assembly


<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
28	W10280024	U-Bend, Drain Hose
29	356138	Clamp, Hose
30	W10339879	Tie, Cable
31	3359452	Nut, Hex






## Lavadora Whirlpool 7MWTW1501AW1

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10465109	Panel, Console
2	8536939	Clip, Spring
3		End Cap (Left)
	8566035	White
4		End Cap (Right)
	8566032	White
5	8312709	Clip, Console
6	W10480338	Control Unit Assembly, Machine & Motor
7	W10461159	Panel, Console Rear Cover
8	1157158	Screw
9	W10268911	Switch, Water Level
10	90767	Screw
11	W10525194	Cord, Power
12	3400076	Screw
13		Knob, Timer
	W10034750	White/Metallic
14		Knob, Control
	W10034380	White/Metallic
15	W10285512	Switch, Rotary Encoder (4 Position)
16	W10291178	Harness, Upper
17	W10472844	Inlet Assembly, Water
18	W10423127	Harness, Valve
19	353362	Washer, Filter
20		Hose, Water Inlet
	W10194210	Cold Water
	W10194211	Hot Water
21	W10242307	Washer, Inlet Hose
22	W10251309	Push Button, Start
23	8281163	Screw
24	3400818	Screw
25	W10348582	Clamp, Hose



<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	63580	Dispenser Assembly, Fabric Softener
2	W10003790	Screw & Washer
3	3949550	Washer
4	63235	Agitator Assembly
5	W10215108	Ring, Tub
6	21366	Nut, Spanner
7	W10389330	Basket Assembly
8	389140	Block, Basket Drive
9	W10339098	Shield, Splash
10	W10238320	Tub (Includes Tub Seal)
11	W10006371	Seal, Tub
12	W10215093	Filter, Drain Pump
13	8533928	Screw
14	W10257088	Damper Assembly, Tub Suspension (Set Of 4-Includes Ball & Bushing)
15	W10405423	Ball, Suspension (Set of 4 - Includes Suspension Bushings)
16	W10256551	Bushing - Upper Suspension (Set of 4 - Includes Suspension Balls)
17	W10376574	Harness, Lower (Includes Pressure Hose & Cable Tie)
18	W10297436	Hose, Pressure Switch
19	W10005430	Clamp, Cable
20	8533943	Screw
21	W10298887	Cable Tie
22	W10429200	Retainer, Push-In





Lavadora Whirlpool 7MWTW1501AW1

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10276397	Pump Assembly, Drain
2	W10004910	Screw
3	W10215091	Hose, Inner Drain Assembly
4	8317496	Clamp, Hose
5	W10473144	Gearcase Assembly
6	W10249633	Screw
7	W10416668	Motor, Drive
8	W10094780	Screw
9	W10006382	Spring, Splutch
10	W10006352	Slider, Splutch
11	W10006353	Cam Ring, Splutch
12	W10006354	Cam, Splutch
13	W10006356	Pulley
14	W10163336	Nut, Pulley
15	W10006384	Belt, Drive
16	W10006355	Actuator, Shift
17	9741052	Screw
18	W10390451	Capacitor, Motor Run
19	357640	Screw
20	W10427633	Shield, Pulley Cover





Lavadora Whirlpool 7MWTW1501AW1

**PAINT, TOUCH-UP (1/2OZ.)**

Illus.  
No.    Part No.    Description

72017 White

**PAINT, PRESSURIZED SPRAY (12 OZ.)**

Illus.  
No.    Part No.    Description

350938 Gray Primer

350930 White

**PAINT, BULK (1 QT.)**

Illus.  
No.    Part No.    Description

799344 White

**WATER SYSTEM PARTS**

Illus.  
No.    Part No.    Description

285834 Siphon Break Kit

367031 Drain Protector

3363920 Adapter, Standpipe  
2" Diameter to 1"  
Diameter

DRNEXT4 Drain Hose Extension  
Kit

**SEALER**

Illus.  
No.    Part No.    Description

285195 Sealer, Gasket (.20 Fl.  
Oz.) (6ml)

**COUPLING**

Illus.  
No.    Part No.    Description

384496 Coupling, Hose  
Extension Kit

**ACCESSORY PARTS**

Illus.  
No.    Part No.    Description

W10355010 Kitchen & Appliance  
Cleaner

8212526 Washer, Drip Tray

8212546RP Inlet Hoses, 4 Ft.  
(Two Black Hoses  
W/ Straight Ends & 4  
Rubber Washers)

8212641RP Inlet Hoses, 5 Ft.  
(Two Black Hoses  
W/ Straight Ends & 4  
Rubber Washers)

8212545RP Inlet Hoses, 5 Ft. (One  
Red Hose & One Blue  
Hose W/ Straight Ends  
& 4 Rubber Washers)

8212487RP Inlet Hoses, 5 Ft.  
(Two Braided Hoses  
W/ Straight Ends & 4  
Rubber Washers)

8212637RP Inlet Hoses, 6 Ft. (Two  
Black Hoses W/ One  
Straight End & One  
90 Degree End & 4  
Rubber Washers)

8212638RP Inlet Hoses, 6 Ft (Two  
Braided Hoses W/  
One Straight End &  
One 90 Degree End &  
4 Rubber Washers)

8212656RP Inlet Hoses, 10 Ft.  
(Two Black Hoses  
W/ Straight Ends & 4  
Rubber Washers)

285448A Hose Washers  
(Package of 4)

285452A Hose Screen  
(Package of 2)

W10135699 Affresh Odor Remover