


Lavadora Whirlpool 7MWTW1604DM0






Lavadora Whirlpool 7MWTW1604DM0

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10658634	Installation Instructions
	W10655225	Owners Manual
	W10468340	Tech Sheet
	W10658018	Energy Guide
2		Top
	W10251299	White
3		Lid and Bumper Assembly
	W10251302	White
4	9724509	Bumper, Lid
5	9740848	Screw
6	91770	Hinge, Lid
7	W10119872	Screw
8		Strike, Lid Lock
	W10240513	White

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	9	W10273971 Screw
10	W10192089	Dispenser, Bleach
11		Bezel, Lid Lock
	W10392041	White
12	21258	Bearing, Lid Hinge
13	90016	Clip, Harness
14	W10238287	Latch, Lid Lock Assembly
15	8281163	Screw (Stainless)
16	W10250884	Panel, Rear
17		Cabinet
	W10478060	White
18	W10215098	Brace, Cabinet Top - Front
19	W10512626	Brace, Cabinet Top - Rear

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
20	1157158	Screw
21	356138	Clamp, Hose
22	W10397994	Foot, Leveling
23	W10339879	Tie, Cable
24	W10142728	Screw
25	W10676061	Cover, Harness
26	3400076	Screw
27	W10221546	Hose, Outer Drain Assembly
28	W10280024	U-Bend, Drain Hose






**Lavadora Whirlpool 7MWTW1604DM0**

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10643276	Panel, Console
2	8536939	Clip, Spring
3		End Cap (Left)
	W10520782	White
4		End Cap (Right)
	W10520780	White
5	8312709	Clip, Console
6	W10658736	Control Unit Assembly, Machine and Motor
7	W10552335	Panel, Console Rear Cover
8	1157158	Screw
9	W10285512	Temperature Control
10	90767	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
11	W10525194	Cord, Power
12	3400076	Screw
13		Knob, Timer
	W10576634	White/Metallic
14		Assembly, Control Knob
	W10576636	White/Metallic
15	W10285511	Switch, Rotary Encoder (2 Position)
16	W10579238	Harness, Upper
17	W10683653	Inlet Assembly, Water
18	W10684972	Harness, Valve
19	W10598040	Grommet, Push to Start
20	W10596298	Button, Push to Start

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
21	W10582444	Harness, Jumper
22	353362	Washer, Filter
23		Hose, Water Inlet
	W10194210	Cold Water
	W10194211	Hot Water
24	W10242307	Washer, Inlet Hose

Lavadora Whirlpool 7MWTW1604DM0






**Lavadora Whirlpool 7MWTW1604DM0**

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	8575076	Dispenser, Fabric Softener
2	3354733	Cap, Barrier
3	W10072840	Seal, Inner Cap
4	W10003790	Screw and Washer
5	3949550	Washer
6	3348117	Agitator (Complete)
7	3363663	Cam, Driven
8	3366877	Dog, Agitator Clutch
9	3363661	Bearing, Cam
10	3348752	Mover, Clothes
11	3350389	Spacer, Thrust
12	3347288	Agitator
13	W10215108	Ring, Tub

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
14	21366	Nut, Spanner
15	W10358261	Basket Assembly
16	389140	Block, Basket Drive
17	8533943	Screw
18	W10238320	Tub (Includes Tub Seal)
19	W10006371	Seal, Tub
20	W10215093	Filter, Drain Pump
21	8533928	Screw (Stainless)
22	W10257088	Damper Assembly, Tub Suspension (Set Of 4-Includes Ball & Bushing)
23	W10560146	Ball, Suspension (Set of 4 - Includes Suspension Bushings)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
24	W10256551	Bushing - Upper Suspension (Set of 4 - Includes Suspension Balls)
25	W10504126	Harness, Lower
26	W10236981	Hose, Pressure Switch
27	W10005430	Clamp, Cable





**Lavadora Whirlpool 7MWTW1604DM0**

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10465543	Pump Assembly, Drain
2	W10004910	Screw
3	W10215091	Hose, Inner Drain Assembly
4	8317496	Clamp, Hose
5	W10473144	Gearcase Assembly
6	W10249633	Screw
7	W10416668	Motor, Drive
8	W10094780	Screw
9	W10006382	Spring, Splutch (Includes Items 10, 11, 12 and 13)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
10	W10006352	Slider, Splutch (Includes Items 9, 11, 12 and 13)
11	W10006353	Cam Ring, Splutch (Includes Items 9, 10, 12 and 13)
12	W10006354	Cam, Splutch (Includes Items 9, 10, 11 and 13)
13	W10536113	Pulley
14	W10604214	Nut, Pulley
15	W10006384	Belt, Drive

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
16	W10006355	Actuator, Shift
17	9741052	Screw
18	W10390451	Capacitor, Motor Run
19	357640	Screw
20	W10427633	Shield, Pulley Cover



# OPTIONAL PARTS (NOT INCLUDED)

## PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White

## PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350938	Gray Primer
	350930	White

## PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White

## WATER SYSTEM PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	285835	Connector Assembly
	285863	4" Drain Hose w/Clamp
	285834	Siphon Break Kit
	367031	Drain Protector
	3363920	Adapter, Standpipe 2" Diameter to 1" Diameter
	DRNEXT4	Drain Hose Extension Kit

## SEALER

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	285195	Sealer, Gasket (.20 Fl. Oz.) (6ml)

## COUPLING

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	384496	Coupling, Hose Extension Kit

## ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	W10355010	Kitchen and Appliance Cleaner
	W10135699	Affresh OdorRemover
	8212546RP	Inlet Hoses, 4 Ft. (Two Black Hoses W/ Straight Ends and 4 Rubber Washers)
	8212641RP	Inlet Hoses, 5 Ft. (Two Black Hoses W/ Straight Ends and 4 Rubber Washers)
	8212545RP	Inlet Hoses, 5 Ft. (One Red Hose and One Blue Hose W/ Straight Ends and 4 Rubber Washers)
	8212487RP	Inlet Hoses, 5 Ft. (Two Braided Hoses W/ Straight Ends and 4 Rubber Washers)
	8212637RP	Inlet Hoses, 6 Ft. (Two Black Hoses W/ One Straight End and One 90 Degree End and 4 Rubber Washers)
	8212638RP	Inlet Hoses, 6 Ft (Two Braided Hoses W/ One Straight End and One 90 Degree End and 4 Rubber Washers)
	8212656RP	Inlet Hoses, 10 Ft. (Two Black Hoses W/ Straight Ends and 4 Rubber Washers)
	285448A	Hose Washers (Package of 4)
	285452A	Hose Screen (Package of 2)
	8212526	Washer, Drip Tray