


Lavadora Whirlpool 7MWTW1702BQ0






Lavadora Whirlpool 7MWTW1702BQ0

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10478095	Installation Instructions
	W10564678	Use & Care Guide
	W10468340	Tech Sheet
	W10566788	Energy Guide
2		Top
	W10251319	White
3		Lid & Bumper Assembly
	W10027624	White
4	9724509	Bumper, Lid
5	9740848	Screw
6	91770	Hinge, Lid
7	W10119872	Screw
8	W10240513	Strike, Lid Lock

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
9	W10273971	Screw
10	W10192089	Dispenser, Bleach
11	W10392041	Bezel, Lid Lock
12	21258	Bearing, Lid Hinge
13	90016	Clip, Harness
14	W10238287	Latch, Lid Lock Assembly
15	8281163	Screw
16	W10250884	Panel Rear
17		Cabinet
	W10251994	White
18	W10215098	Brace, Cabinet Top - Front
19	W10215099	Brace, Cabinet Top - Rear
20	1157158	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
21	W10248088	Lock, Top
22	W10397994	Foot, Leveling
23	W10215102	Hinge, Top
24	W10142728	Screw
25	W10215139	Cover, Harness
26	3400076	Screw
27	W10221546	Hose, Outer Drain Assembly
28	W10280024	U-Bend, Drain Hose
29	356138	Clamp, Hose
30	W10339879	Tie, Cable






Lavadora Whirlpool 7MWTW1702BQ0

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10552361	Panel, Console
2	8536939	Clip, Spring
3		End Cap (Left)
	8566035	White
4		End Cap (Right)
	8566032	White
5	8312709	Clip, Console
6	W10570362	Control Unit Assembly
7	W10461159	Panel, Console Rear Cover
8	1157158	Screw
9	W10251309	Push Button, Start

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
10	90767	Screw
11	W10525194	Cord, Power
12	3400076	Screw
13		Knob, Timer
	8566061	White
14		Knob, Control
	8565944	White
15	W10285512	Switch, Rotary Encoder (4 Position)
16	W10291183	Harness, Upper
17	W10472844	Inlet Assembly, Water
18	W10423127	Harness, Valve

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
19	8281163	Screw
20	3400818	Screw
21	W10242307	Washer, Inlet Hose
22	353362	Washer, Filter
23		Hose, Water Inlet
	W10194210	Cold Water
	W10194211	Hot Water
24	W10285511	Switch, Rotary Encoder (2 Position)






Lavadora Whirlpool 7MWTW1702BQ0

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	8575076	Dispenser, Fabric Softener
2	3354733	Cap, Barrier
3	W10072840	Seal, Inner Cap
4	W10003790	Screw & Washer
5	3949550	Washer
6	3951744	Agitator (Complete)
7	3951682	Cam, Driven
8	3366877	Dog, Agitator Clutch
9	3952374	Bearing, Cam
10	3363003	Mover, Clothes
11	3951608	Spacer-Thrust
12	3951632	Agitator

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
13	W10215108	Ring, Tub
14	21366	Nut, Spanner
15	W10358261	Basket Assembly
16	389140	Block, Basket Drive
17	W10267532	Cable Tie
18	W10238320	Tub (Includes Tub Seal)
19	W10006371	Seal, Tub
20	W10215093	Filter, Drain Pump
21	8533928	Screw
22	W10257088	Damper Assembly, Tub Suspension (Set Of 4-Includes Ball & Bushing)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
23	W10405423	Ball, Suspension (Set of 4 - Includes Suspension Bushings)
24	W10256551	Bushing - Upper Suspension (Set of 4 - Includes Suspension Balls)
25	W10504125	Harness, Lower (Includes Pressure Hose & Cable Tie)
26	W10297436	Hose, Pressure Switch
27	W10005430	Clamp, Cable
28	8533943	Screw





Lavadora Whirlpool 7MWTW1702BQ0

<u>Illus.</u>	<u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1	W10465543	Pump Assembly, Drain
	2	W10004910	Screw
	3	W10215091	Hose, Inner Drain Assembly
	4	8317496	Clamp, Hose
	5	W10473144	Gearcase Assembly
	6	W10249633	Screw
	7	W10416654	Motor, Drive

<u>Illus.</u>	<u>No.</u>	<u>Part No.</u>	<u>Description</u>
	8	W10094780	Screw
	9	W10006382	Spring, Splutch
	10	W10006352	Slider, Splutch
	11	W10006353	Cam Ring, Splutch
	12	W10006354	Cam, Splutch
	13	W10006356	Pulley
	14	W10163336	Nut, Pulley
	15	W10006384	Belt, Drive

<u>Illus.</u>	<u>No.</u>	<u>Part No.</u>	<u>Description</u>
	16	W10006355	Actuator, Shift
	17	9741052	Screw
	18	W10390451	Capacitor, Motor Run
	19	357640	Screw
	20	W10427633	Shield, Pulley Cover

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350938	Gray Primer
	350930	White

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White

WATER SYSTEM PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	285834	Siphon Break Kit
	367031	Drain Protector
	3363920	Adapter, Standpipe 2" Diameter to 1" Diameter
	DRNEXT4	Drain Hose Extension Kit

SEALER

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	285195	Sealer, Gasket (.20 Fl. Oz.) (6ml)

COUPLING

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	384496	Coupling, Hose Extension Kit

ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	W10355010	Kitchen & Appliance Cleaner
	8212526	Washer, Drip Tray
	8212546RP	Inlet Hoses, 4 Ft. (Two Black Hoses W/ Straight Ends & 4 Rubber Washers)
	8212641RP	Inlet Hoses, 5 Ft. (Two Black Hoses W/ Straight Ends & 4 Rubber Washers)
	8212545RP	Inlet Hoses, 5 Ft. (One Red Hose & One Blue Hose W/ Straight Ends & 4 Rubber Washers)
	8212487RP	Inlet Hoses, 5 Ft. (Two Braided Hoses W/ Straight Ends & 4 Rubber Washers)
	8212637RP	Inlet Hoses, 6 Ft. (Two Black Hoses W/ One Straight End & One 90 Degree End & 4 Rubber Washers)
	8212638RP	Inlet Hoses, 6 Ft (Two Braided Hoses W/ One Straight End & One 90 Degree End & 4 Rubber Washers)
	8212656RP	Inlet Hoses, 10 Ft. (Two Black Hoses W/ Straight Ends & 4 Rubber Washers)
	285448A	Hose Washers (Package of 4)
	285452A	Hose Screen (Package of 2)
	W10135699	Affresh Odor Remover