


Lavadora Whirlpool 7MWTW1800DM1






Lavadora Whirlpool 7MWTW1800DM1

<u>Illus.</u>	<u>No.</u>	<u>Part No. Description</u>
	1	Literature Parts W10693226 Installation Instructions
		W10693225 Owners Manual
		W10468340 Tech Sheet
		W10663446 Energy Guide
	2	Top
		W10251319 White
	3	Lid and Bumper Assembly
		W10027624 White
	4	9724509 Bumper, Lid
	5	9740848 Screw
	6	91770 Hinge, Lid
	7	W10119872 Screw
	8	Strike, Lid Lock
		W10240513 White

<u>Illus.</u>	<u>No.</u>	<u>Part No. Description</u>
	9	W10273971 Screw
	10	W10192089 Dispenser, Bleach
	11	Bezel, Lid Lock W10392041 White
	12	21258 Bearing, Lid Hinge
	13	90016 Clip, Harness
	14	W10238287 Latch, Lid Lock Assembly
	15	8281163 Screw(Stainless)
	16	W10250884 Panel, Rear
	17	Cabinet
		W10478060 White
	18	W10215098 Brace, Cabinet Top- Front
	19	W10512626 Brace, Cabinet Top- Rear

<u>Illus.</u>	<u>No.</u>	<u>Part No. Description</u>
	20	1157158 Screw
	21	356138 Clamp, Hose
	22	W10397994 Foot, Leveling
	23	W10339879 Tie, Cable
	24	W10142728 Screw
	25	W10676061 Cover, Harness
	26	3400076 Screw
	27	W10221546 Hose, Outer Drain Assembly
	28	W10280024 U-Bend, Drain Hose






Lavadora Whirlpool 7MWTW1800DM1

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10643280	Panel, Console
2	8536939	Clip, Spring
3	End Cap (Left) W10520782	White
4	End Cap (Right) W10520780	White
5	8312709	Clip, Console
6	W10658737	Control Unit Assembly, Machine and Motor
7	W10552335	Panel, Console Rear Cover
8	1157158	Screw
9	W10285512	Temperature Control
10	90767	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
11	W10525194	Cord, Power
12	3400076	Screw
13		Knob, Timer
	W10576634	White/Metallic
14		Assembly, Control Knob
	W10576636	White/Metallic
15	W10285511	Switch, Rotary Encoder (2 Position)
16	W10579238	Harness, Upper
17	W10683653	Inlet Assembly, Water
18	W10684972	Harness, Valve
19	W10598040	Grommet, Push to Start
20	W10596298	Button, Push to Start

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
21	W10582444	Harness, Jumper
22	353362	Washer, Filter
23		Hose, Water Inlet
	W10194210	Cold Water
	W10194211	Hot Water
24	W10242307	Washer, Inlet Hose






Lavadora Whirlpool 7MWTW1800DM1

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	8575076	Dispenser, Fabric Softener
2	3354733	Cap, Barrier
3	W10072840	Seal, Inner Cap
4	W10003790	Screw and Washer
5	3949550	Washer
6	3951744	Agitator (Complete)
7	3951682	Cam, Driven
8	3366877	Dog, Agitator Clutch
9	3952374	Bearing, Cam
10	3363003	Mover, Clothes
11	3951608	Spacer-Thrust
12	3951632	Agitator
13	W10215108	Ring, Tub

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
14	21366	Nut, Spanner
15	W10358261	Basket Assembly
16	389140	Block, Basket Drive
17	8533943	Screw
18	W10238320	Tub (Includes Tub Seal)
19	W10006371	Seal, Tub
20	W10215093	Filter, Drain Pump
21	8533928	Screw (Stainless)
22	W10257088	Damper Assembly, Tub Suspension (Set Of 4-Includes Ball & Bushing)
23	W10560146	Ball, Suspension (Set of 4 - Includes Suspension Bushings)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
24	W10256551	Bushing - Upper Suspension (Set of 4 - Includes Suspension Balls)
25	W10746348	Harness, Lower
26	W10236981	Hose, Pressure Switch
27	W10005430	Clamp, Cable





Lavadora Whirlpool 7MWTW1800DM1

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10465543	Pump Assembly, Drain
2	W10004910	Screw
3	W10215091	Hose, Inner Drain Assembly
4	8317496	Clamp, Hose
5	W10473144	Gearcase Assembly
6	W10249633	Screw
7	W10416668	Motor, Drive
8	W10094780	Screw
9	W10006382	Spring, Splutch (Includes Items 10, 11, 12 and 13)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
10	W10006352	Slider, Splutch (Includes Items 9, 11, 12 and 13)
11	W10006353	Cam Ring, Splutch (Includes Items 9, 10, 12 and 13)
12	W10006354	Cam, Splutch (Includes Items 9, 10, 11 and 13)
13	W10536113	Pulley
14	W10604214	Nut, Pulley
15	W10006384	Belt, Drive

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
16	W10597177	Actuator, Shift
17	9741052	Screw
18	W10390451	Capacitor, Motor Run
19	357640	Screw
20	W10427633	Shield, Pulley Cover



Lavadora Whirlpool 7MWTW1800DM1

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350938	Gray Primer
	350930	White

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White

WATER SYSTEM PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	285835	Connector Assembly
	285863	4' Drain Hose w/Clamp
	285834	Siphon Break Kit
	367031	Drain Protector
	3363920	Adapter, Standpipe 2" Diameter to 1" Diameter
	DRNEXT4	Drain Hose Extension Kit

SEALER

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	285195	Sealer, Gasket (.20 Fl. Oz.) (6ml)

COUPLING

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	384496	Coupling, Hose Extension Kit

Illus. ACCESSORY PARTS

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
	W10355010	Kitchen and Appliance Cleaner
	W10135699	Affresh Odor Remover
	8212546RP	Inlet Hoses, 4 Ft. (Two Black Hoses W/ Straight Ends and 4 Rubber Washers)
	8212641RP	Inlet Hoses, 5 Ft. (Two Black Hoses W/ Straight Ends and 4 Rubber Washers)
	8212545RP	Inlet Hoses, 5 Ft. (One Red Hose and One Blue Hose W/ Straight Ends and 4 Rubber Washers)
	8212487RP	Inlet Hoses, 5 Ft. (Two Braided Hoses W/ Straight Ends and 4 Rubber Washers)
	8212637RP	Inlet Hoses, 6 Ft. (Two Black Hoses W/ One Straight End and One 90 Degree End and 4 Rubber Washers)
	8212638RP	Inlet Hoses, 6 Ft (Two Braided Hoses W/ One Straight End and One 90 Degree End and 4 Rubber Washers)
	8212656RP	Inlet Hoses, 10 Ft. (Two Black Hoses W/ Straight Ends and 4 Rubber Washers)
	285448A	Hose Washers (Package of 4)
	285452A	Hose Screen (Package of 2)
	8212526	Washer, Drip Tray