

Whirlpool

SERVICE

CENTRO DE SOLUCIONES



LO ORIGINAL MARCA DIFERENCIA

**EXPLOSIONADO DE PARTES
-REFRIGERADOR-
MODELO 7WCS25SDHM02**

acros



Whirlpool
CORPORATION

MAYTAG

KitchenAid

REFRIGERADOR 7WCS25SDHM02

34



REFRIGERADOR 7WCS25SDHM02


<u>No. ilustración</u>	<u>Descripción</u>	<u>Piezas</u>	<u>No. Parte</u>
2	ROLLER	1	W10304660
3	SCREW	-	No serviceable
4	ROLLER CABINET	1	2150304
5	AXLE, ROLLER	1	2262072
6	CLIP, GRILLE	2	2155013
7	PLATE, SCREW	1	W10247935
8	CLIP, ROLLER	2	W11087168
9	TOP HINGE RC Right	1	W11167023
	TOP HINGE FC Left	1	W11167022
10	SCREW	-	No serviceable
11	SCREW	-	No serviceable
12	TUBE FILTER - INLET	1	W10900449
13	HINGE, BOTTOM FC	1	W11093938
14	SCREW	-	N/A
15	FRONT ROLLER RIGHT	1	W10304659
16	FILLER, WRAPPER	2	No serviceable
17	GRILLE	1	W11226338
18	SCREW, HINGE	-	No serviceable
19	SCREW	-	No serviceable
20	SCREW	-	No serviceable
21	SCREW	-	No serviceable
22	DRAIN FITTING	1	2304888
23	EXTENSION, DRAIN FITTING	1	W10153550
24	COVER UNIT	1	W10904634
25	HINGE, BOTTOM RC	1	W11097327
26	TUBE FILTER – OUTLET	1	W10900447
28	CLAMP, POWER CORD	1	W11242280
29	SCREW	-	No serviceable
30	DOOR CLOSER, FREEZER	1	W10905504
31	SCREW	-	No serviceable
32	HOUSING & FILTER ASSY.	1	W11030555
33	CABINET	-	No serviceable
34	CONTROL BOARD	1	W11133692

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

REFRIGERADOR 7WCS25SDHM02



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

REFRIGERADOR 7WCS25SDHM02


<u>No. Ilustración</u>	Descripción	Piezas	No. Parte
1	LINER	-	No Serviceable
2	SHIELD ASSY-LIGHT	1	W11397250
3	HEMERA 30 DEGLEDMODULE-5v	1	W11520324
4	RESERVOIR	1	W11222026
5	SCREW	-	No Serviceable
6	AIR DIFFUSER ASSEMBLY	1	W11204060

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

REFRIGERADOR 7WCS25SDHM02






REFRIGERADOR 7WCS25SDHM02

<u>No. Ilustración</u>	Descripción	Piezas	No. Parte
1	Shelf, Snack Pan	2	W11135532
2	Trim, Handle	1	W11046496
3	Slide, Humidity	1	W10532732
4	Housing, Humidity	1	W10532706
5	Assembly, Cover	2	W11135529
6	Pan, Snack	1	W11046493
7	Roller	2	#N/A
8	Axle, Roller	1	#N/A
9	Pan, Crisper	1	W11046494
10	Pan, Meat	1	W11046495
11	Trim, Handle	1	W11180284
12	Assembly, Shelf	1	W11135529

REFRIGERADOR 7WCS25SDHM02

17



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

REFRIGERADOR 7WCS25SDHM02


No. Ilustración	Descripción		Piezas	No. Parte
1	Liner	-		No serviceable
2	Assembly, Cover	1		#N/A
3	Shelf, Glass Upper	2		W11048563
4	Thermistor	1		W10384183
5	Shelf, Glass Lower	1		W11048562
6	Pan, Freezer	1		2309757
7	Roller	2		No serviceable
8	Axle, Roller	2		No serviceable
9	Trim, Handle	1		No serviceable
10	Switch, Rocker Arm FC	1		W10847849
11	Socket, Light	1		W10134764
12	Lamp, LED	4		W11125625
13	Switch, Rocker Arm RC	1		W10847849
14	Cover, Thermistor	1		No serviceable
15	Lens	1		#N/A
16	Socket, Light	1		W10134764
17	Pizza Pocket Asyy	1		#N/A

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

REFRIGERADOR 7WCS25SDHM02



Distribuidor Autorizado



Venta de Refacciones
Electrodomesticas

REFRIGERADOR 7WCS25SDHM02


<u>No. Ilustración</u>	Descripción	Piezas	No. Parte
	ASSY - MOTOR & BRACKET 25	1	W11369458
1	BRACKET-ICE DISPENSER MOTOR	1	W11307589
2	MOTOR ASSY-ICE CRUSHER	1	W10884561
4	SOLENOID ASSY	1	2152713

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

REFRIGERADOR 7WCS25SDHM02



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

REFRIGERADOR 7WCS25SDHM02


<u>No.</u> <u>Ilustración</u>	<u>Descripción</u>	<u>Piezas</u>	<u>No. Parte</u>
1	Door, Refrigerator	1	W11110269
2	Bin, Gallon Door	3	W10900538
3	Screw	-	----
4	Can Rack	1	W11034218
5	Gasket, Door	1	W10912081
6	Handle	1	W11045530
7	Thimble, Top	1	2200087
8	Screw	-	----
9	Closer, Upper Cam Door	1	W10900464
10	Screw	-	----
11	Bracket, Door Stop	1	W10900463
12	Nameplate	1	W10884773
13	Screw	-	----
14	Cover, Door Stop Assembly, Utility	1	#N/A
15	Compartment	1	2256101

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

REFRIGERADOR 7WCS25SDHM02



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



REFRIGERADOR 7WCS25SDHM02


No. Ilustración	Descripción	Piezas	No. Parte
1	FREEZER DOOR (INCLUYE ITEM 8	1	W11110266
2	HANDLE	1	W11045530
3	THIMBLE	1	2200087
4	BRACKET, DOOR STOP	1	W10900531
5	SCREW	--	#N/A
6	TRIM, DOOR	3	2309718
7	SCREW	--	#N/A
8	DOOR GASKET MAGNETIC	1	W10911389
9	TRIM, DOOR SHELF	1	W10307494
10	SCREW	--	#N/A
11	DOOR CLOSER, UPPER CAM	1	W10900532

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

REFRIGERADOR 7WCS25SDHM02



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

REFRIGERADOR 7WCS25SDHM02


No. Ilustración	Descripción	Piezas	No. Parte
1	Housing, Dispenser	-	No serviceable
2	Grate, Drip Tray	1	No serviceable
3	Bracket, Ice Door	1	No serviceable
4	Guide, Ice	1	No serviceable
5	Motor, Dispenser	1	N/A
6	Assembly, Separator	1	W11231384
7	Support, Ice Door	1	#N/A
8	Screw	-	#N/A
9	Ring, Trim	1	#N/A
10	Assembly, LED	1	#N/A
11	Assembly, User Interface	1	W11169239
12	Pad, Ice and Water	2	#N/A
13	Tray, Drip	1	#N/A
14	Cover, Front	1	W11169239
15	Assembly, Water Fitting	1	W10898317

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

REFRIGERADOR 7WCS25SDHM02



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

REFRIGERADOR 7WCS25SDHM02


<u>No. Ilustración</u>	Descripción	Piezas	No. Parte
1	SCROLL, FAN	1	W11228713
2	RETAINER, FAN MOTOR	1	W10188846
3	SCREW	--	#N/A
4	THERMISTOR RC	1	W10384183
5	AIR DUCT FREEZER	1	W10128722
6	GASKET	1	2155789
7	FAN MOTOR	1	2315549
8	BLADE, FAN	1	2169142
9	GASKET, EVAPORATOR COVER	2	2304241
10	GROMMET, MOTOR	2	2176759
11	SCREW	--	#N/A
12	HARNESS, FAN TUBE EVAPORATOR	1	W10911770
13	GASKET, EVAPORATOR COVER	2	2304241
14	COVER, EVAPORATOR	1	W10463011
15	SUPPORT, RIGHT HAND	1	2203595
16	SUPPORT, LEFT HAND	1	2203596

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

REFRIGERADOR 7WCS25SDHM02



REFRIGERADOR 7WCS25SDHM02


No. Ilustración	Descripción	Piezas	No. Parte
1	Strap, Bale	1	2212996
2	Blade, Fan	1	2169142
3	Condenser Assembly	1	W10904626
4	Screw	--	No serviceable
5	Clip, Wire	3	#N/A
6	Screw	--	#N/A
7	Connector, Water Tube	1	W10271541
8	Sleeve, Pressure Switch Hose	1	2161302
9	Screw	--	No serviceable
10	Tube, Suction	1	W10745337
11	Clip, Condenser	2	2311725
12	Capacitor	1	W10350564
13	Tube, Process	--	No serviceable
14	Start Device Combination (Start	1	W10197427
15	Screw	--	No serviceable
16	Evaporator, FC	1	2188823
17	Clip, Defrost Heater	2	2161324
18	Motor, Condenser	1	W11042949
19	Tray, Evaporator	1	W10897557
20	Heat Shield and Drain Pan	1	W10194475
21	Drier	1	W10771114
22	Screw	--	No serviceable
23	Frame, Unit Mounting	1	W10900446
24	Unit, Harness	1	#N/A
25	Bracket, Fan Motor	1	2181929
26	Heater, Defrost	1	2188175
27	Clip, Defrost Heater	2	2161324
28	Compressor	1	W11199564
29	Grommet	4	W10836504
30	Screw	4	489340
31	Air Baffle	1	W10897567

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

REFRIGERADOR 7WCS25SDHM02





REFRIGERADOR 7WCS25SDHM02

**No.
Ilus.**

DESCRIPCIÓN

Cant.

No. de Parte

1	SCREW	--	No serviceable
3	CLIP, THERMAL FUSE	1	628379
4	TUBE, WATER	1	W10357076
5	SCREW	--	No serviceable
6	FILTER VALVE ASSEMBLY	1	W10179146
7	ARM, SHUTT OFF	1	W11182354
8	COVER, ICEMAKER	1	W10289690
9	SCREW	--	No serviceable
10	ASSEMBLY, MOLD & HEATER	1	W10300025
11	CUP-WATER FILL	1	W10435665
12	EJECTOR, ARM	1	W10318914
13	STRIPPER, ICE	1	W10699925
14	SUPPORT	1	2194712
15	RETAINER, THERMOSTAT	2	2315522
16	THERMOSTAT	1	2321258
17	SCREW	--	No serviceable
18	ASSEMBLY, MODULE	1	626691
19	MOTOR (NO SERVICEABLE)	--	No serviceable
20	SCREW	--	No serviceable
	COMPLETE ICEMAKER ASSEMBLY	1	W10300022