




## **FRENCH DOOR BOTTOM MOUNT REFRIGERATOR**

### **MODELS:**

7WF736SDAM13 (Monochromatic Stainless)



**Illus.**



<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10666412	Use and Care
	W10568023	Tech Sheet
2	W10453401	Supply, Power
3	W10344432	Block, Pivot
4	W10505487	Gasket
5	W10589838	Control, Electronic
6	W10415341	Gasket, HV Box
7		Plug, Button
	A3076901	Black
8	W10141622	Brake, Roller
9	12992602	Screw
10		Hinge, Top
	W10248410	Left Hand
	W10248409	Right Hand
11	W10403212	Screw
12		Cover, Right Hinge
	W10407158	Grey

**Illus.**

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
13		Cover, Left Hinge
	W10471618	Grey
14	W10308751	Screw (Black)
15		Hinge, Center (Right)
	W10248703	Grey
16	W10336736	Cover, Roller
17		Cover, Corner
	12587703AP	Grey
18	W10394076	Valve, Water
19		Assembly, Roller
	W10515763	Left Hand
	W10515762	Right Hand
20	12991302	Screw
21	12990701	Screw
22		Grille, Toe
	W10637671	Grey
23	12992601	Screw

**Illus.**

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
24		Hinge, Center (Left)
	W10248706	Grey
25	W10141645	Screw
26	12990511	Screw
27	12990302	Screw
28	W10485658	Cover, Control Box
29	12466105	Switch, Light
30	W10577369	Cover, Unit
31	M0108107	Clamp, Tube
32	W10141645	Screw
33	W10277839	Lid, HV
34	W10505294	Coupler, Door
35	W10212137	Retainer, Door
36		Cabinet (Not a Servicable Part)
37	489348	Clamp, Tube
38	W10678712	Tube, Water



**Illus.**

<b>No.</b>	<b>Part No.</b>	<b>Description</b>
1		Liner (Not A Serviceable Part)
2	A3189392	Gasket, Foam
3	W10456436	Module, LED
4	W10513428	Cover, Evaporator
5	12990511	Screw
6	12956601	Clip, Fan Motor
7	C3680310V	Switch, Light
8	12990504	Screw
9	W10496613	Grille, Air (Freezer)

**Illus.**


<b>No.</b>	<b>Part No.</b>	<b>Description</b>
10	W10363507	Shroud, Evaporator Fan
11	12986101	Blade, Fan
12	12951101	Grommet, Fan Motor
13	W10561029	Motor, Evaporator (Includes Harness, Thermistor, & Defrost Thermostat)
14	W10503218	Assembly, Drain Funnel
15	M0500703	Seal
16	B8381501	Gasket, Drain

**Illus.**

<b>No.</b>	<b>Part No.</b>	<b>Description</b>
17	W10405166	Cover, Thermistor
18	W10531268	Gasket, Dual Evaporator
19	W10280385	Thermistor



# REFRIGERADOR 7WF736SDAM13



**Illus.**


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)
2	W10705147	Housing, Water System
3	W10736144	Tube, Fill
4	W10711460	Reservoir, Water (Also Order Wire Tie Part 8567668)
5	W10341329	Valve, Dual Water
6	W10238156	Housing, Water Filter
7	W10279854	Enclosure, Valve
8	W10575423	Cover, Water Box
9	2223877	Latch, Push
10	W10277949	Door, Filter Access
11	W10680605	Filter, Water

**Illus.**

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
12	W10315189	Filter, Air
13	W10674102	Waterline, Valve To Hinge
14	W10706850	Heater, Fill Tube
15	12990518	Screw
16	W10598013	Cover, Icebox
17	W10347640	Assembly, Icebox
18	W10524406	Assembly, LED
19	W10682878	Assembly, Air Tower
20	W10515072	Trim, Icebox
21	W10667566	Fan, Icebox
22	W10392172	Gasket, Fan
23	W10456436	Module, LED
24	W10320706	Gasket, Rear Return

**Illus.**

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
25	W10553630	Assembly, Fascia
26	C3680310V	Switch, Light
27	W10280988	Gasket, Rear Supply
28	W10280983	Insulation
29	W10530312	Cover, Damper
30	W10635023	Assembly, Ice Box Adapter
31	W10479155	Damper, Control
32	W10438957	Cover, Thermistor
33	W10445802	Cup, LED Bracket
		Following Parts Not Illustrated
	W10570726	Harness, LED Light
	W10570599	Harness, Dual Valve





**Illus.**


<b>No.</b>	<b>Part No.</b>	<b>Description</b>
1		Door, Freezer
	W10422791	Stainless
2		Handle, Door
	W10719666N	Stainless
3	W10460893	Screw
4	W10503521	Shaft, Rack
5		Assembly, Bracket
	W10625067	Left Hand
	W10625068	Right Hand

**Illus.**

<b>No.</b>	<b>Part No.</b>	<b>Description</b>
6	W10590552	Pan Assembly, Lower
7	12990518	Screw
8	W10704089	Assembly, Upper Pan
9	W10709748	Clip, Shaft
10	W10507444	Divider, Lower
11		Stop, Pan
	W10485096	Left Hand
	W10485089	Right Hand
12	W10485654	Divider, Upper

**Illus.**

<b>No.</b>	<b>Part No.</b>	<b>Description</b>
13	W10469177	Support, Pan
14	489443	Screw (Stainless)
15		Gasket, Door
	W10248749	Grey



**Illus.**


<b><u>No.</u></b>	<b><u>Part No.</u></b>	<b><u>Description</u></b>
1		Door, Left
	W10630233	Stainless
2		Door, Right
	W10422771	Stainless
3	W10464016	Screw
4	W10549592	Assembly, Ice Door
5		Latch, Door
	W10712952	Left Hand
	W10712953	Right Hand
6		Mullion, Door
	W10698199	Grey
7	12990204	Screw
8		Handle, Door
	W10713676	Stainless
9	12990504	Screw

**Illus.**

<b><u>No.</u></b>	<b><u>Part No.</u></b>	<b><u>Description</u></b>
10		Bumper, Door
	W10407188	Grey
11		Nameplate
	W10393265	Grey
12	W10460893	Screw
13	W10555822	Assembly, Trivet
14	W10493524	Bucket, Gallon
15	489214	Screw
16	W10347085	Gasket, Ice Door
17	W10245516	Clip, Tube
18	W10518658	Board, Receiver Circuit
19	W10258510	Cover, Receiver
20	3400065	Screw (Stainless)
21	W10258502	Cover, Emitter
22	W10258540	Slide, Icemaker Shut Off

**Illus.**

<b><u>No.</u></b>	<b><u>Part No.</u></b>	<b><u>Description</u></b>
23	W10518659	Board, Emitter Circuit
24	W10400825	Retainer, Ice Chute
25	W10347087	Gasket, Ice Chute
26	W10646855	Vent, Thermistor
27	W10258520	Door, Emitter
28	2198635	Spring, Door
29	2198634	Pin, Door
30		Gasket, Door
	W10407146	Grey
31	W10499015	Tube, Water



**Illus.**


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	12992101	Screw
2	2188935	Blade, Fan
3	W10570074	Baseplate
4	12990511	Screw
5	W10776917	Extension, Drain
6	W10236396	Strap, Compressor
7	W10303521	Sleeve
8	W10660727	Tray, Evaporator
9	W10622701	Screw
10	12729128	Heater, Defrost
11	W10330834	Device, Start
12	W10248621	Clip, Condenser
13	12477102	Roller
14	12992101	Screw
15	10835903	Grommet
16	W10559262	Condenser

**Illus.**

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
17	W10350564	Capacitor
18	W10512220	Tray, Drip
19	W10463542	Tube, Suction
20	W10608485	Assembly, Evaporator and Heater
21	W10296661	Clip, Bottom Cover
22	W10527155	Motor, Condenser Fan
23	10428101	Clip, Heater
24	W10491355	Gasket, Airdam
25	W10177049	Drier
26	W10171785	Compressor (Also Order 482801 Installation Kit & 876765 Tube Kit)
27	W10142294	Screw
28	12477202	Axle, Roller
29	W10406719	Shroud
30	W10367947	Cord, Power

**Illus.**

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
31	W10278140	Cover, Condenser (Bottom)
32	W10650382	Strap, Bale
33	W10747515	Assembly, Unit Wire
Following Parts Not Illustrated		
	978025	Valve, Access
	978026	Valve, Access
	978027	Valve, Access
	978028	Valve, Access
	978029	Valve, Access
	978030	Valve, Access
	876764	Valve, Access
		REFRIGERANT CHARGE
		5.25 oz. (R-134A)



**Illus.**


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10510417	Front, Pantry
2	W10248789	Roller, Center
3	W10515051	Support, Pantry
4	W10248516	Ladder, Center
5	W10628815	Glass, Pantry
6	W10408747	Holder, Filter
7	W10257246	Axle, Roller
8	W10709179	Assembly, Tuck Shelf
9	W10688114	Assembly, Crisper Front
10	W10498901	Pan, Pantry
11	W10709149	Assembly, Shelf
12	W10512596	Knob, Pantry Temperature Control
13	W10372170	Ladder, Side
14	W10628814	Glass, Crisper

**Illus.**

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
15	W10717573	Cover, Crisper
16	W10248544	Roller, Guide
17	W10387757	Pan, Crisper
18		Sideplate, Pantry
	W10248798	Left Hand
	W10248796	Right Hand
19		Slide, Pantry
	W10508327	Left Hand
	W10508326	Right Hand
20	W10346771	Filter, Produce Preserver Plate, Crisper
21		
	W10530311	Left Hand
	W10530310	Right Hand
22	W10554279	Housing, Pantry Temperature Control

**Illus.**

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
23	W10554285	Cover, Pantry Top
24	W10662015	Assembly, Center Crisper Support
25	W10554293	Assembly, Pantry Front Cover
26	W10185612	Screw
27	W10236512	Support, Front
28	W10423560	Screw
29		Front, Sideplate (Pantry)
	W10248852	Left Hand
	W10248851	Right Hand
30	W10387778	Pan, Crisper
31	W10423520	Crisper, Front
32	W10530314	Housing, Roller





Illus.


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)
2		Assembly, User Interface
	W10590573	White

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
3		Wall, Dispenser False
	W10712262	Grey
4		Ring, Trim
	W10402180	Chrome

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
5		Assembly, Separator
	W10616134	Grey
6		Tray, Drip
	W10709233	Grey
7	W10470750	Assembly, LED





# REFRIGERADOR 7WF736SDAM13

**Illus.**

**No. Part No. Description**

- 1 W10272364 Screw
- 2 W10347051 Plate, Ice Chute
- 3 2198628 Seal

**Illus.**


**No. Part No. Description**

- 4 W10347120 Clip, Retainer
- 5 W10347114 Shaft, Motor
- 6 W10215646 Motor, Dispenser

**Illus.**

**No. Part No. Description**

- 7 8281163 Screw (Stainless)
- 8 W10347093 Assembly, Ice Container





**REFRIGERADOR 7WF736SDAM13**

Illus.

No.   Part No.   Description

1   W10764668   Assembly, Icemaker

# OPTIONAL PARTS (NOT INCLUDED)

## PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

## PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

## PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

## MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	20000008	Cleaner, Stainless Steel
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet

## TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key