




FRENCH DOOR BOTTOM MOUNT REFRIGERATOR

MODELS:

7WF736SDAM14 (Monochromatic Stainless)



REFRIGERADOR 7WF736SDAM14





REFRIGERADOR 7WF736SDAM14

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	Literature Parts W10666412 Use and Care W10811276 Tech Sheet (English) W10811278 Tech Sheet (French)	
2	W10453401	Supply, Power
3	W10344432	Block, Pivot
4	W10505487	Gasket
5	W10811363	Control, Electronic
6	W10415341	Gasket, HV Box
7	Plug, Button A3076901 Black	
8	W10141622	Brake, Roller
9	12992602	Screw
10	Hinge, Top W10248410 Left Hand W10248409 Right Hand	
11	W10673840	Screw (Stainless)
12	Cover, Right Hinge W10407158 Grey	

Illus.



<u>No.</u>	<u>Part No.</u>	<u>Description</u>
13	W10471618 Grey	Cover, Left Hinge
14	W10308751	Screw (Black)
15	W10248703 Grey	Hinge, Center (Right)
16	W10336736	Cover, Roller
17	W10394076 Valve, Water	Cover, Corner 12587703AP Grey
18	Assembly, Roller W10515763 Left Hand W10515762 Right Hand	
20	W10709365	Screw
21	12990701	Screw
22	W10637671 Grey	Grille, Toe
23	12992601	Screw
24	W10248706 Grey	Hinge, Center (Left)
25	W10141645	Screw

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
26	12990511	Screw
27	12990302	Screw
28	W10485658	Cover, Control Box
29	12466105	Switch, Light
30	W10577369	Cover, Unit
31	M0108107	Clamp, Tube
32	W10141645	Screw
33	W10277839	Lid, HV
34	W10505294	Coupler, Door
35	W10212137	Retainer, Door
36	489348	Cabinet (Not a Servicable Part) Clamp, Tube
37	W10678712	Tube, Water



REFRIGERADOR 7WF736SDAM14





REFRIGERADOR 7WF736SDAM14


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Seviceable Part)
2	A3189392	Gasket, Foam
3	W10809579	Module, LED
4	W10513428	Cover, Evaporator
5	12990511	Screw
6	12956601	Clip, Fan Motor
7	C3680310V	Switch, Light
8	12990504	Screw
9	W10496613	Grille, Air (Freezer)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
10	W10363507	Shroud, Evaporator Fan
11	12986101	Blade, Fan
12	12951101	Grommet, Fan Motor
13	W10728111	Motor, Evaporator (Includes Harness, Thermistor, & Defrost Thermostat)
14	W10503218	Assembly, Drain Funnel
15	M0500703	Seal
16	B8381501	Gasket, Drain

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
17	W10405166	Cover, Thermistor
18	W10531268	Gasket, Dual Evaporator
19	W10280385	Thermistor



REFRIGERADOR 7WF736SDAM14





REFRIGERADOR 7WF736SDAM14


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)
2	W10826118	Housing, Water System
3	W10736144	Tube, Fill
4	W10711460	Reservoir, Water (Also Order Wire Tie Part 8567668)
5	W10341329	Valve, DualWater
6	W10238156	Housing, Water Filter
7	W10811115	Enclosure, Water Valve
8	W10575423	Cover, Water Box
9	2223877	Latch, Push
10	W10277949	Door, Filter Access
11	W10680605	Filter, Water

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
12	W10315189	Filter, Air
13	W10674102	Waterline, Valve To Hinge
14	W10706850	Heater, Fill Tube
15	12990518	Screw
16	W10598013	Cover, Icebox
17	W10811677	Assembly, Icebox
18	W10831335	Assembly, LED
19	W10682878	Assembly, Air Tower
20	W10515072	Trim, Icebox
21	W10460280	Fan, Icebox
22	W10392172	Gasket, Fan
23	W10809579	Module, LED
24	W10320706	Gasket, Rear Return

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
25	W10553630	Assembly, Fascia
26	C3680310V	Switch, Light
27	W10280988	Gasket, Rear Supply
28	W10280983	Insulation
29	W10530312	Cover, Damper
30	W10635023	Assembly, Ice Box Adapter
31	W10479155	Damper, Control
32	W10438957	Cover, Thermistor
33	W10445802	Cup, LED Bracket
		Following Parts Not Illustrated
	W10813530	Harness, LED Light
	W10570599	Harness, Dual Valve



REFRIGERADOR 7WF736SDAM14





REFRIGERADOR 7WF736SDAM14


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer
	W10422791	Stainless
2		Handle, Door
	W10719666N	Stainless
3	W10460893	Screw
4	W10503521	Shaft, Rack
5		Assembly, Bracket
	W10625067	Left Hand
	W10625068	Right Hand

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	W10590553	Assembly, Lower Pan
7	12990518	Screw
8	W10704089	Assembly, Upper Pan
9	W10709748	Clip, Shaft
10	W10507444	Divider, Lower
11		Stop, Pan
	W10485096	Left Hand
	W10485089	Right Hand
12	W10485654	Divider, Upper

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
13	W10469177	Support, Pan
14	489443	Screw (Stainless)
15		Gasket, Door W10248749
		Grey



REFRIGERADOR 7WF736SDAM14





REFRIGERADOR 7WF736SDAM14


<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Left
	W10630233	Stainless
2		Door, Right
	W10422771	Stainless
3	W10464016	Screw
4	W10549592	Assembly, Ice Door
5		Latch, Door
	W10712952	Left Hand
	W10712953	Right Hand
6		Mullion, Door
	W10698199	Grey
7	12990204	Screw
8		Handle, Door
	W10713676	Stainless

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
9	12990504	Screw
10	W10407188	Bumper, Door
		Grey
11		Nameplate
	W10393265	Grey
12	W10460893	Screw
13	W10493524	Bucket, Gallon
14	W10555822	Assembly, Trivet
15	15 489214	Screw
16	W10347085	Gasket, Ice Compartment Door
17	W10245516	Clip, Tube
18	W10518658	Board, Receiver Circuit
19	W10258510	Cover, Receiver
20	3400065	Screw (Stainless)
	W10493524	Bucket, Gallon

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
21	W10258502	Cover, Emitter
22	W10258540	Slide, Icemaker ShutOff
23	W10832970	Board, Emitter Circuit
24	W10400825	Retainer, Ice Chute
25	W10347087	Gasket, Ice Chute
26	W10646855	Vent, Thermistor
27	W10258520	Door, Emitter
28	2198635	Spring, Door
29	2198634	Pin, Door
30		Gasket, Door W10873938
		Grey
31	W10499015	Tube, Water



REFRIGERADOR 7WF736SDAM14





REFRIGERADOR 7WF736SDAM14


<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	12992101	Screw
2	2188935	Blade, Fan
3	W10570074	Baseplate
4	12990511	Screw
5	W10776917	Extension, Drain
6	W10236396	Strap, Compressor
7	W10303521	Sleeve
8	W10660727	Tray, Evaporator
9	W10622701	Screw
10	12729128	Heater, Defrost
11	W10796752	Device, Start
12	W10248621	Clip, Condenser
13	12477102	Roller
14	12992101	Screw
15	10835903	Grommet
16	W10559262	Condenser
17	W10350564	Capacitor
18	W10512220	Tray, Drip

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
19	W10463542	Tube, Suction
20	W10248589	Assembly, Evaporator
21	W10815861	Clip, Bottom Cover
22	W10527155	Motor, Condenser Fan
23	10428101	Clip, Heater
24	W10491355	Gasket, Airdam
25	W10177049	Drier
26	W10171785	Compressor (Also Order 482801 Installation Kit & 876765 Tube Kit)
27	W10142294	Screw
28	12477202	Axle, Roller
29	W10406719	Shroud
30	W10367947	Cord, Power
31	W10278140	Cover, Condenser (Bottom)
32	W10650382	Strap, Bale
33	W10747515	Assembly, UnitWire

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
34	W10281329	Clip, Drier
35	12990702	Screw
36	2169104	Sealer, Insulation
Following Parts Not Illustrated		
	978025	Valve, Access
	978026	Valve, Access
	978027	Valve, Access
	978028	Valve, Access
	978029	Valve, Access
	978030	Valve, Access
	876764	Valve, Access
		REFRIGERANT CHARGE 5.25 oz. (R-134A)



REFRIGERADOR 7WF736SDAM14





REFRIGERADOR 7WF736SDAM14

Illus.
No. Part No. Description

- 1 W10510417 Front, Pantry
- 2 W10248789 Roller, Center
- 3 W10515051 Support, Pantry
- 4 W10248516 Ladder, Center
- 5 W10628815 Glass, Pantry
- 6 W10408747 Holder, Filter
- 7 W10257246 Axle, Roller
- 8 W10709179 Assembly, Tuck Shelf
- 9 W10688114 Assembly, Crisper Front
- 10 W10498901 Pan, Pantry
- 11 W10709149 Assembly, Shelf
- 12 W10512596 Knob, Pantry Temperature Control
- 13 W10372170 Ladder, Side
- 14 W10628814 Glass, Crisper
- 15 W10717573 Cover, Crisper
- 16 W10248544 Roller, Guide
- 17 W10387757 Pan, Crisper

Illus.
No. Part No. Description


- 18 Sideplate, Pantry
- W10248798 Left Hand
- W10248796 Right Hand
- 19 Slide, Pantry W10508327 Left Hand W10508326 Right Hand
- 20 W10346771 Filter, Produce Preserver Plate, Crisper
- 21 W10530311 Left Hand W10530310 Right Hand
- 22 W10554279 Housing, Pantry Temperature Control
- 23 W10554285 Cover, Pantry Top
- 24 W10662015 Assembly, Center Crisper Support
- 25 W10554293 Assembly, Pantry Front Cover
- 26 W10185612 Screw
- 27 W10236512 Support, Front

Illus.
No. Part No. Description

- 28 W10423560 Screw
- 29 Front, Sideplate(Pantry) W10248852 Left Hand W10248851 Right Hand
- 30 W10387778 Pan, Crisper
- 31 W10423520 Crisper, Front
- 32 W10530314 Housing, Roller
- 33 W10398002 Handle, Pantry
- 34 Roller Runner, Pantry W10508330 Left Hand W10508328 Right Hand



REFRIGERADOR 7WF736SDAM14





REFRIGERADOR 7WF736SDAM14




<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)
2		Assembly, User Interface
	W10808730	White

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3		Wall, Dispenser False
	W10712262	Grey
4		Ring, Trim
	W10402180	Chrome

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5		Assembly, Separator
	W10616134	Grey
6		Tray, Drip
	W10709233	Grey
7	W10470750	Assembly, LED



REFRIGERADOR 7WF736SDAM14





REFRIGERADOR 7WF736SDAM14

Illus.
No. Part No. Description

- 1 W10272364 Screw
- 2 W10347051 Plate, Ice Chute
- 3 2198628 Seal
- 4 W10347120 Clip, Retainer

Illus.
No. Part No. Description

- 5 W10347114 Shaft, Motor
- 6 W10215646 Motor, Dispenser
- 7 8281163 Screw (Stainless)
- 8 W10347093 Assembly, Ice Container

Illus.
No. Part No. Description

- 9 W10291905 Gasket
- 10 W10746960 Assembly, Icemaker

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	20000008	Cleaner, Stainless Steel
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key