




Guía	Descripción	# de parte
1	COVER-BACK	12575101WD
2	USE WPL 12751511	67004098
3	Screw	67006425
4	SCREW	681390
5	GASKET- MC	B5759649
6	Replacement Ice Maker	D7824706Q
6	Ice Maker Front Cover	WPW10289690
6	Ice Maker Shut-Off Arm	WP67004028
6	Ice Maker Wire Harness	WPD7813010
7	Screw	WP98165
8	Plastic Tube Insert	WPA3223101
8	Plastic Tubing	WPB5705307
9	Cord Clip	M0104102
10	Dual Water Valve	WP67005154
11	Clip	WPM0104106
12	Speed Clamp Clip	WPM0114003
12	Refrigerator Ice Maker Fill Tube	W11176463
13	Water Tubing Clamp	W10833902
15	Ice Bucket	WP67001255
16	COVER- WAT	12726003
17	Insulation	67003796
18	Water Line Clip	67004701
19	CLAMP-TUBE	12831101
20	TRACK- WAT	67004102
21	Power Cord - Black	WP67006506







<b>Guía</b>	<b>Descripción</b>	<b># de parte</b>
1	PAN- BASE	12457108
2	SHROUD- CO	67001090
3	Condenser Fan Motor Kit	12002738
4	Condenser Fan Motor Kit	12002738
5	Speed Nut	WP486692
6	BLADE- CON	WP12587601
7	Compressor Grommet	67003493
8	Compressor Kit	W10309989
9	SCREW	M0221523
10	Compressor Start Device and Capacitor	W10613606
11	Run Capacitor	WP65889-4
12	CLIP	12576801
13	PAN- DRAIN	WP12579803
14	GROMMET- C	67005680
15	TUBE- DISC	WP12866903
16	Screw	67006425
17	USE WPL 67006433	12992301
18	SEAL-STRIP	WP854334
19	Condenser	WP67006131
20	HARNS-WIRE	67004097




<b>Guía</b>	<b>Descripción</b>	<b># de parte</b>
1	Refrigerator Door Switch	W11384469
2	LENS-LIGHT	67004078
3	Refrigerator Light Cover	W11284721
4	CNTRL-ELEC	67004005
5	Electronic Control Board	WPW10503278
6	COVER-BOX	WP12806701
7	Damper Cover Insert	67003900
8	Screw	WP400021-1
9	HOUSING- L	12806601
10	SOCKET	W11447232
11	Light Bulb - 40W	8009
12	OVERLAY	W10317181
13	Damper Control	WP67003903
14	Insulation	WP67003904
15	COVER	67003905
16	MODULE- FZ	67003906
17	HOUSING- L	67001035
18	SOCKET	W11447232
19	Light Bulb - 40W	8009
20	Door Switch	W11396033
21	Screw, 8-18 X 5/16	WPW10139210
22	Thermistor	12002355
24	Wiring Harness	WP12868601
24	HARNS-WIRE	67003908






<b>Guía</b>	<b>Descripción</b>	<b># de parte</b>
1	Grille, Shroud	WPW10175909
2	TRAY-DRIP	W11547653
3	CLIP- EVAP	10623002
4	COVER-EVAP	W10308416
5	GASKET	W11451451
6	Adjustment Screw	71003131
7	Single Wheel Assembly	12580304
8	Screw	67006425
9	SCREW	M0260242
10	Thermistor	12002355
11	Drier	WPB2150504
12	EVAPORATOR	12002041
13	AIR DAM	12225601
14	DAM- RIGHT	67001084
15	Defrost Heater	WP67002493
16	CLIP	W11673433
17	SHROUD- EV	67002777
18	Evaporator Motor Kit - 60Hz 115V	12002744
19	CLIP- EVAP	67002779
20	Fan Grommet	WP67002780
21	Evaporator Fan Blade	WP2169142
22	GASKET	W10856123
23	BRACKET- R	12456801V
24	Speed Nut	M0286708
25	Single Roller	WP10450603
26	Roller Pin	M1205302
27	CLIP- DRIE	10547002
28	Screw	WP98165
29	SCREW	67006612
30	Defrost Thermostat	WP67003426
31	HARNS-WIRE	67004080







Guía	Descripción	# de parte
1	DOR-FIP Stainless Steel	12658925SQ
2	SCREW	12991101
3	Freezer Door Gasket - Black	W10436252
4	PLUG-HOLE	A3080001
5	PLUG- VENT	67004838





<b>Guía</b>	<b>Descripción</b>	<b># de parte</b>
1	Screw	WP98165
2	Drawer Gear Kit	12002500
2	Drawer Gear Kit	12002500
3	Screw 8-18 x 1	WP489474
4	BRACKET- D	WP12812501WD
5	BRACKET- D	WP12812502WD
6	Drawer Slide Kit	12002683
7	SHAFT	W11028221
8	Bracket - Right Side	WPW10280613
9	Drawer Gear Kit	12002497
10	Drawer Gear Kit	12002497
11	HANDLE	10508506
12	DIVIDER- B	67004127
13	SCREW	W10856125
14	DIVIDER- B	67006644
15	Wire Freezer Basket	67004987
16	BIN-FREEZR	WPW10503184



Guía	Descripción	# de parte
1	Door Handle - Stainless	67004959
2	Screw	WP67006197
2	Frame Screw	WP7101P126-60
3	Clip	WP13067101
3	Butterfly Handle Mount	WP67006852
4	CARD- HAND	67007028




Guía	Descripción	# de parte
1	Ejector Arm	WP627843
2	Water Fill Cup and Bearing	WP628356
3	Ice Stripper	WP2182124
4	Retainer, Thermostat	WP2315522
5	Bracket	WP2256087
6	Motor Housing	WP2195914
7	Screw	WP681249
8	Water Line Installation Kit	8003RP
9	Replacement Ice Maker	D7824706Q








<b>Guía</b>	<b>Descripción</b>	<b># de parte</b>
1	Drain Tube Gasket	WPB8381501
1	SEAL- O RI	WPM0500703
2	FUNNEL	W10815413
3	RIVET, POP (Qty 5) (Series 10)	A4539607
4	Corner Cover - Black	67003485
5	TUBE- DRAI	67001066
6	CLIP- DRAI	67001067
7	PLUG	A3076901
8	Screw	67006491
9	Door Hinge	W10215663
10	Levelling Foot	W11177593
11	Kickplate Grille	WP67002224
12	LADDER- CE	67001073
13	LADDER- L	67002489
14	SCREW	W10709795
15	Screw	67006425
16	Lower Hinge Cover	12561901B
17	COVER- FZ	WP67003924



<b>Guía</b>	<b>Descripción</b>	<b># de parte</b>
1	DOR-FIP Stainless Steel	12732411SQ
2	Screw	WPW10348409
3	Refrigerator Door Gasket	W11368721
4	SHIM- TOP	12695601
4	Door Hinge	WP12566607ED
5	Hinge Cover - Black - Left Side	W10177767
6	Screw Kit	R9800670
7	Door Stop	WP67003780
8	Screw	WP8281196
9	PLUG- VENT	67004838
10	Refrigerator Vertical Mullion Rail - Black	WP12722803B
11	PLUG-HOLE	A3080001
12	Door Bushing - Black	WP67002721
13	Screw	W11233072
13	Pivot Block	WP67003405




<b>Guía</b>	<b>Descripción</b>	<b># de parte</b>
1	DOOR Complete	WP12744905
2	Dairy Door	WP67003637
3	Door Shelf Bin	WPW10371193
3	MAT	W10450022
4	Refrigerator Door Bin	WPW10289497
5	Utility Bin	10423131
6	COVER-EGG	10436404
7	TRAY- EGG	10436506
8	Black Door Hinge	WP12607104ED
9	Center Hinge Pin	WP67006642
10	Refrigerator Door Hinge Screw	WP67006380
11	BUCKET- TA	WP67004003
11	BRACKET- T	67004107
12	BUCKET- SH	67004004
13	TRIVET	67001656
14	USE WPL 10448903V	10448903






Guía	Descripción	# de parte
1	SHELF- GLI	67004637
2	Pantry Drawer Divider.	WP67002759
3	Pantry Drawer	WP67003531
4	Crisper Brace	WP12642303WD
5	Crisper Glass Shelf Insert	WP67006704
6	Shelf Trim	WPW10231344
7	Humidity Control Slide	WP67005864
8	Front Crisper Seal	WP67003417
9	Crsiper Drawer Seal - Rear	WP67002513
10	Pantry Drawer Glide - Left or Right Side	WP67007026
11	KNOB	W11498983
12	Temperature Control Bar	WP67003795
13	Temperature Control Slide	WP67003793
14	Refrigerator Crisper Frame	WP67003854
14	Crisper Frame Support	WP12603701
15	HOUSING	12656202
16	Crisper Pan - Clear/White	WP67005915
17	GASKET- PA	67002329
18	Pantry End Cap Kit, LH and RH	W10874836
19	Pantry End Cap Kit, LH and RH	W10874836
20	Screw	67006425
21	Small Screw	M0238636
22	Screw	WPW10348409
23	Deli Track	WP67001719
24	EXTR- GLAS	WP67006010
25	Pantry Bin Glass Cover/Shelf	WP67002761
26	Crisper Brace	WP12227305WD
27	Refrigerator Pantry Drawer Door Cover	W10827015
28	Center Rail	WPW10326469



<b>Guía</b>	<b>Descripción</b>	<b># de parte</b>
1	FIP Door - Stainless Steel	12732410SQ
2	Screw	WPW10348409
3	Refrigerator Door Gasket	W11368721
4	PLUG-HOLE	A3080001
5	SHIM- TOP	12695601
5	Door Hinge	WP12566606ED
6	COVER- TOP	12684202B
7	Screw Kit	R9800670
8	Door Stop	WP67003780
9	Screw	WP8281196
10	PLUG- VENT	10712401
10	PLUG- VENT	67004838
11	Door Closure	WP67003639
12	Door Hinge Bushing	WP67002731
13	NAMEPLATE	Y12528501



<b>Guía</b>	<b>Descripción</b>	<b># de parte</b>
1	Water Filter Backing Plate	WP67001668
2	Water Filter Head	WP67004106
3	Water Filter	EDR4RXD1
4	Water Filter Cover	WP12568001
5	Screw	67006425
6	COVER	W10168903
7	Limit Switch	WP12575501
8	COVER	W11519867
9	Water Tank Assembly	12002023
10	Water Tube Connector/Union	WP2300868
11	Screw	WP98165
12	BLOCK- FIL	WP12777701
13	Refrigerator Water Filter Bypass	W11395888

