




SECADORA DBVH520EJ0WW

CONTROLS & BACKSPLASH

DBVH520EJ0WW




BENITO JUÁREZ #1500 GPE ZITON, CD. GUADALUPE NUEVO LEÓN TEL: 8183377999 Y 49
 HORARIOS: LUNES A VIERNES 8:30 A 6:00 PM Y SÁBADOS DE 8:30 A 2:00 PM
 WEB: www.denek.com



SECADORA DBVH520EJ0WW

FRONT PANEL

DBVH520EJ0WW




BENITO JUÁREZ #1500 GPE ZITON, CD. GUADALUPE NUEVO LEÓN TEL: 8183377999 Y 49
 HORARIOS: LUNES A VIERNES 8:30 A 6:00 PM Y SÁBADOS DE 8:30 A 2:00 PM
 WEB: www.denek.com



SECADORA DBVH520EJ0WW

DOOR

DBVH520EJ0WW




BENITO JUÁREZ #1500 GPE ZITON, CD. GUADALUPE NUEVO LEÓN TEL: 8183377999 Y 49
 HORARIOS: LUNES A VIERNES 8:30 A 6:00 PM Y SÁBADOS DE 8:30 A 2:00 PM
 WEB: www.denek.com



SECADORA DBVH520EJ0WW

CABINET

DBVH520EJ0WW




BENITO JUÁREZ #1500 GPE ZITON, CD. GUADALUPE NUEVO LEÓN TEL: 8183377999 Y 49
HORARIOS: LUNES A VIERNES 8:30 A 6:00 PM Y SÁBADOS DE 8:30 A 2:00 PM
WEB: www.denek.com



SECADORA DBVH520EJ0WW

BLOWER & MOTOR

DBVH520EJ0WW




BENITO JUÁREZ #1500 GPE ZITON, CD. GUADALUPE NUEVO LEÓN TEL: 8183377999 Y 49
 HORARIOS: LUNES A VIERNES 8:30 A 6:00 PM Y SÁBADOS DE 8:30 A 2:00 PM
 WEB: www.denek.com



SECADORA DBVH520EJ0WW

DRUM

DBVH520EJ0WW



BENITO JUÁREZ #1500 GPE ZITON, CD. GUADALUPE NUEVO LEÓN TEL: 8183377999 Y 49
HORARIOS: LUNES A VIERNES 8:30 A 6:00 PM Y SÁBADOS DE 8:30 A 2:00 PM
WEB: www.denek.com

Guía	Refacción	Descripción
2	WG04L04064	DRYER SMALL WINDOW
4	WG04L04010	POWER BUTTON
6	WG04L04072	START PAUSE BUTTON
6	WG04L04088	START PAUSE BUTTON
7	WG04F03487	DRYER KNOB
10	WG04F04339	BAR GRAPH BUTTONS
11	WG04L04073	OPTION BUTTONS
12	WG04F04256	LOCK BUTTON
13	WG04F01878	CNTRL PNL ASM WH
14	WG04L03998	PLUS MINUS BUTTONS
72	WG04L03997	DRYER FRONT SHIELD GASKET
75	WE2M210	SCREW BACK HOUSING
100	WG04F01233	USER INTERFACE BOARD ASM
100	WG04A00205	SHOE RACK
112	WG03L00760	PLUG BUTTON - WHITE COLOR
198	WW02A00070	SCREW GROUND
201	WW02A00011	BLOWER WHEEL W/NUT INSER
203	WG04F01829	STRAP MOTOR
204	WG04F01582	MOTOR STRAP
205	WG04A00990	SOPORTE
213	WG04F01569	BANDA TRANSMISION
215	WW02A00060	IDLER ARM SPRING
218	WW02F00240	GASKET SEAL, HSNG EXH.
222	WG04L07218	DRYER REAR PLATE
228	WE14M107	CONDUCTO DE ESCAPE
230	WG04F01199	T-STAT OUTLET BKUP ORG
232	WW02A00032	SCREW
236	WG04L00345	LEVELING LEG
238	WW02A00099	DRYER SCREW #10-16 3/4 - WHITE
240	WG04F01117	THERMISTOR OUTLET CNTR
240	WG04F12391	THERMISTOR OUTLET CNTR
300	WG04A00744	DRYER LINT FILTER
301	WE20M325	DRYER FRONT PANEL - WHITE
307	WG04L00158	DOOR OUTER RING
310	WE1M573	CLEANING FELT

Guía	Refacción	Descripción
310	WG04F01571	TRAP DUCT COMPLETE ASM
311	WG04F01580	SENSOR ROD
313	WG04F03471	SOPORTE TAMBOR SUPERIOR
314	WW02A00067	DRYER LIGHT BULB, 120 VOLT, 10 WATTS
316	WG04L00683	CORREDERA
316	WG01F01524	CORREDERA
317	WE9M29	FELT TOP BEARING
325	WE1M574	CONDUCTO TRAMPA / SELLO DELANTERO
327	WG04F00606	LATCH
333	WG04L00133	ENS. PUERTA
375	WE5M49	SOCKET ASM.
380	WE4M349	DOOR SWITCH
401	WE20M327	DRYER COVER - WHITE
403	WW03A00204	SCREW FLAT HEAD/AB
403	NLA	SCREW FLAT HEAD/AB
404	WE20M329	SIDE PANEL WH
410	WG04F07906	SOPORTE TRASERO DE TORNILLO DE NIVELACION
419	WW02F00172	CLOTHES DRYER POWER TERMINAL BLOCK
461	WW01A00001	SCREW
506	WG04F04880	INLET CONTROL THERMISTOR
515	WG04F00475	GROUND STRAP ASM
515	WW01A00443	GROUND STRAP ASM
515	WW02F00833	GROUND STRAP ASSEMBLY
603	WG04L00148	DOOR HANDLE COVER
610	WG04L00144	DRYER DOOR GASKET
630	WW03A00218	MOTOR THREADED AND PULLE
631	WG04F02264	CONNECTOR MOTOR
803	WW02F00232	SWITCH INTER.
3046	WW02A00097	DRYER SCREW
3049	WG04F03491	TOPE PUERTA
3051	WG04L01612	DOOR HINGE ASM. PLATED
3340	WG04L01698	DRYER TOP FRONT SHIELD GASKET
3341	WG04L01699	DRYER SIDE FRONT SHIELD GASKET
3342	WW02A00098	SCREW HINGE TO FRONT
3344	WG04F04464	DRYER HOUSING BACK

Guía	Refacción	Descripción
3345	WG04L00725	DOOR OUTER WINDOWS
3345	NLA	DOOR OUTER WINDOWS
3346	WW03L00337	CUBIERTA JALADERA PUERTA
3347	WG04L04076	INNER WINDOW RETAINER
3351	WW03A00201	SCREW #8 X 5/8 SS DOOR H
3352	WW02A00101	DRYER SCREW 8-32 1/2
3354	WE2M212	SCREW TO ATTACH HINGE TO FRONT PANEL
3356	WG04L07073	PLACA DE PARO
3357	WG04A00631	TUERCA GUIA PUERTA
3358	WD21M131	SCREW
3360	WG04A00629	GUIA
3361	WE1M571	DRYER DOOR GUIDE
3364	WG04F01593	HARNESS SENSORS
3365	WE4M388	MAIN ELECTRIC POWER BOARD ASM
3366	WE1M586	MAIN POWER BOARD SUPPORT
3367	WE1M587	DRYER EXHAUST PROTECTOR