

Distribuidor Autorizado


SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# SECADORA DBVH520EJ3WW

## CONTROLS & BACKSPLASH

DBVH520EJ3WW



Distribuidor Autorizado


SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# SECADORA DBVH520EJ3WW

## FRONT PANEL

## DBVH520EJ3WW



Distribuidor Autorizado


SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# SECADORA DBVH520EJ3WW

## FRONT PANEL

## DBVH520EJ3WW



Distribuidor Autorizado


SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# SECADORA DBVH520EJ3WW

**DOOR**

**DBVH520EJ3WW**



Distribuidor Autorizado


SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# SECADORA DBVH520EJ3WW

## CABINET

## DBVH520EJ3WW



Distribuidor Autorizado


SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# SECADORA DBVH520EJ3WW

## BLOWER & MOTOR

DBVH520EJ3WW



Distribuidor Autorizado


SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# SECADORA DBVH520EJ3WW

**DRUM**

**DBVH520EJ3WW**



Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas

# SECADORA DBVH520EJ3WW

Guía	Refacción	Descripción
2	WG04L04064	DRYER SMALL WINDOW
4	WG04L04010	POWER BUTTON
6	WG04L04072	START PAUSE BUTTON
6	WG04L04088	START PAUSE BUTTON
7	WG04F03487	DRYER KNOB
10	WG04F04339	BAR GRAPH BUTTONS
11	WG04L04073	OPTION BUTTONS
12	WG04F04256	LOCK BUTTON
13	WE19M1635	CNTRL PNL ASM WH
14	WG04L03998	PLUS MINUS BUTTONS
72	WG04L03997	DRYER FRONT SHIELD GASKET
100	WG04F02274	USER INTERFACE BOARD ASM
112	WG03L06938	BEAUTY BUTTON-WHT
112	WG03F04737	BEAUTY BUTTON-WHT
201	WW02A00011	BLOWER WHEEL W/NUT INSER
203	WW02F00003	STRAP MOTOR
204	WE01X0921	MOTOR DE CORREA
205	WG04A00990	SOPORTE
213	WG04F01569	BANDA TRANSMISION
215	WW02A00060	IDLER ARM SPRING
216	WE12M8	PULLEY IDLER
218	WE14M94	HOUSING BLOWER
218	WW02F00240	GASKET SEAL, HSNQ EXH.
222	WG04L07218	DRYER REAR PLATE
228	WE14M107	CONDUCTO DE ESCAPE
230	WG04F01199	T-STAT OUTLET BKUP ORG
233	WE13M41	MOTOR PLATE
234	WG04A00124	NUT CAP
234	WG04A00124	NUT CAP
236	WE1M771	LEVELLING LEG-1PC Plasti
240	WG04F01117	THERMISTOR OUTLET CNTR
240	WG04F12391	THERMISTOR OUTLET CNTR
300	WG04A00744	DRYER LINT FILTER
301	WE20M325	DRYER FRONT PANEL - WHITE
307	WG04L00158	DOOR OUTER RING



Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas

# SECADORA DBVH520EJ3WW

Guía	Refacción	Descripción
310	WE1M573	CLEANING FELT
311	WG04F01571	TRAP DUCT COMPLETE ASM
312	WG04F03523	SELLO DE FIELTRO
312	WW02A00201	SELLO DE FIELTRO
313	WG04F03471	SOPORTE TAMBOR SUPERIOR
314	WW02A00067	DRYER LIGHT BULB, 120 VOLT, 10 WATTS
315	WG04A00023	BEARING-SLIDE WHITE
316	WE1M507	SLIDE, DRUM - GREEN
325	WE1M574	CONDUCTO TRAMPA / SELLO DELANTERO
327	WG04F00606	LATCH
333	WG04L00133	ENS. PUERTA
375	WE5M49	SOCKET ASM.
380	WG02L00217	INTERRUPTOR PUERTA
401	WE20M327	DRYER COVER - WHITE
404	WE20M382	SIDE PANEL WH
408	WG04F11509	BOTTOM CHASSIS BASE
410	WG04A01057	BRACKET LEVELLING LEG
411	WW01A00431	BRACKET & LEVEL LEG ASM
419	WW02F00172	CLOTHES DRYER POWER TERMINAL BLOCK
420	WG04F04436	PANEL REAR 6 CU FT
430	WE1M458	T-BLOCK COVER
431	WE1M457	SOPORTE ALIVIO TENSIÓN
503	WG04F04043	ENSAMBLE TAMBOR
503	WW03F00415	ENSAMBLE TAMBOR
504	WG04F00267	DEFLECTOR HEAT
504	WG04F00267	DEFLECTOR HEAT
504	WG04F12324	DIFUSOR
505	WW02F00173	THERM. L210
506	WG04F04880	INLET CONTROL THERMISTOR
507	WG04F02270	THERMOSTATO
508	WW02F00244	SOPORTE
508	WG02F02340	SOPORTE
508	WG02F02340	SHAFT & BRACKET ASM
508	WG02F02340	SHAFT & BRACKET ASM
508	WG02F02340	SHAFT & BRACKET ASM

Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas

## SECADORA DBVH520EJ3WW

Guía	Refacción	Descripción
509	WW01F01128	BAFFLE
510	WW01A00442	SOPORTE DE PROTECCION
512	WE11M30	MICA HEATER & HSNG ASM
513	WE11M31	HOUSING HEATER
514	WE11M32	MICA UNIT ASM
515	WG04F00475	GROUND STRAP ASM
515	WW01A00443	GROUND STRAP ASM
515	WW02F00833	GROUND STRAP ASSEMBLY
603	WG04L00148	DOOR HANDLE COVER
610	WG04L00144	DRYER DOOR GASKET
630	WW03A00218	MOTOR THREADED AND PULLE
631	WG04F02264	CONNECTOR MOTOR
803	WD21X0557	INTERRUPTOR DE BLOQUEO
1000	WG04A00205	SHOE RACK
3049	WG04L06355	STRIKE DOOR
3049	WG04F03491	STRIKE DOOR
3051	WG04L01612	DOOR HINGE ASM. PLATED
3102	WG04A00067	BUJE PARA SECADORA
3106	WG04L00501	SLEEVE BEARING
3127	WG04F00001	O RING
3340	WG04L01698	DRYER TOP FRONT SHIELD GASKET
3341	WG04L01699	DRYER SIDE FRONT SHIELD GASKET
3344	WG04F04464	DRYER HOUSING BACK
3345	WG04L00725	DOOR OUTER WINDOWS
3345	NLA	DOOR OUTER WINDOWS
3346	WW03L00337	CUBIERTA JALADERA PUERTA
3347	WG04L04076	INNER WINDOW RETAINER
3356	WG04L07073	PLACA DE PARO
3357	WG04A00631	TUERCA GUIA PUERTA
3360	WG04A00629	GUIA
3361	WE1M571	DRYER DOOR GUIDE
3363	WG04F01580	SENSOR ROD
3364	WG04F01593	HARNESS SENSORS
3365	WE4M388	MAIN ELECTRIC POWER BOARD ASM
3366	WG03A03550	SOPORTE TARJETA PRINCIPAL
3367	WE1M587	DRYER EXHAUST PROTECTOR