


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

DU6000 TABLERO





DU6000 TABLERO


1	R0903522	DESCONTINUADO
2	R0903509	PUSH BUTTON (S/P)
3	R0905582	DESCONTINUADO
4	R0903007	ESCUTCHEON (S/P)
5	R0905592	DESCONTINUADO
6	R0902508	SWITCH P/B (S/P)
7	R0905593	DESCONTINUADO
8	R0903511	PLUG (S/P)
8	R0903521	PLUG, TIMER (S/P)
9	R0903006	COVER (S/P)
10	R0902507	SWITCH, CYCLE (S/P)
11	R0904003	TIMER, CONTROL (S/P)
12	R0905581	CAM, TIMER (S/P)
13	R0905545	DESCONTINUADO
14	R0905541	DESCONTINUADO
15	R0902506	DESCONTINUADO
16	R0912002	LIGHT PILOT (S/P)
17	R0910015	DESCONTINUADO
18	R0905534	SHIELD, SWITCH (S/P)
19	R0905533	DESCONTINUADO
20	R0900009	SCREW (S/P)

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

DU6000 PUERTA





DU6000 PUERTA


1	R0903010	PANEL DOOR (S/P)
2	R0903525	DOOR PANEL INSERT (S/P)
2	R0905559	DESCONTINUADO
3	R0905585	TRIM, BOTTOM (S/P)
4	R0905549	TRIM SIDE (S/P)
5	R0900010	SCREW (S/P)
6	R0905579	ARM HINGE L H (S/P)
6	R0905580	ARM HINGE RH (S/P)
8	R0905537	HINGE ARM BEARING (S/P)
9	R0903011	PANEL ACCESS (S/P)
10	R0905587	TRIM, ACCESS PANEL (S/P)
11	R0905588	TRIM SIDE & BOTTOM (S/P)
13	R0903012	DESCONTINUADO
14	R0900005	SCREW 1PKG=12PCS (S/P)
15	R0905584	INSERT, SERVICE PANEL, GOLD/BL (S/P)
15	R0905561	INSERT, ACCESS (S/P)
16	R0903001	DOOR, INNER (S/P)
17	R0900019	SCREW (S/P)
18	R0905531	LATCH ASSY (S/P)
19	R0903513	KNOB (S/P)
20	R0900016	SCREW (S/P)
21	R0905532	DOOR BAR (S/P)
22	R0905536	DOOR VENT (S/P)
24	R0905540	CAP, FILL (S/P)
25	R0905538	SHAFT HAND D CUP (S/P)
26	R0910010	DETERGENT CUP COVER (S/P)
27	R0955523	DEFLECTOR (S/P)
28	R0904501	DOOR GASKET (S/P)
29	R0905542	TRIP SPRING (S/P)
30	R0905539	LATCH DETERGENT CUP (S/P)
31	R0905535	RINSE AID INJECTOR ASSY (S/P)
34	R0905543	CONDUIT HARNESS (S/P)
35	R0910011	DRIP SHIELD (S/P)

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

DU6000 GABINETE








DU6000 GABINETE

1	R0905502	BAFFLE, TUB (RT) (S/P)
1	R0905501	BAFFLE TUB CORNER LH (S/P)
2	R0900001	MOUNTING SCREW (S/P)
3	R0910034	FILL, TUNNEL (S/P)
4	R0904505	GASKET, FUNNEL (S/P)
5	R0901510	DESCONTINUADO
6	R0903523	FILL HOSE (S/P)
7	R0905527	DESCONTINUADO
8	R0900008	DESCONTINUADO
9	R0903519	HOSE, POWER SHOWER (S/P)
10	R0901003	NUT (S/P)
11	R0905554	ASSY, PWR SHOWER (S/P)
12	R0900013	SCREW (S/P)
13	R0904506	INSULATION TUB (S/P)
14	R0910023	FILTER FRAME ASSY (S/P)
15	R0906001	DESCONTINUADO
16	R0905633	SUPPORT HEATER REAR (S/P)
17	R0905509	SUPPORT FRONT HEATER (S/P)
18	R0905511	FLOAT (S/P)
19	R0903501	DESCONTINUADO
20	R0905512	FLOAT STEM (S/P)
21	R0905513	BRKT, FLOOD SWITCH (S/P)
22	R0902501	DESCONTINUADO
23	R0905514	COVER SWITCH BRKT (S/P)
24	R0910024	DESCONTINUADO
25	R0911002	THERMOSTAT, WATER (S/P)
26	R0910021	RECEPTACLE (S/P)
27	R0900501	WASHER (S/P)
28	R0906502	GROMMET (S/P)
29	R0906501	INSULATION (S/P)
30	R0905507	BARRIER BRKT (S/P)
31	R0901001	NUT (S/P)
32	R0905508	DESCONTINUADO

33	R0905569	GUIDE SPRING (S/P)
34	R0910035	VALVE, WATER INLET (S/P)
35	R0903507	INSULATOR (S/P)
36	R0909002	SOLENOID ASSEMBLY, WATER VALVE (S/P)
37	R0905553	COVER, JCT. BOX (S/P)
38	R0905568	DOOR SPRING (S/P)
39	R0910026	COLL. CHAMBER (S/P)
40	R0904503	GASKET (S/P)
41	R0910025	DESCONTINUADO
42	R0906505	HOSE, CHAMBER (S/P)
43	R0906506	HOSE, CHAMBER (S/P)
44	R0900020	KIT, SCREW (S/P)
45	R0905528	CAP, SUMP (S/P)
46	R0900011	SCREW (S/P)
47	R0905586	HANGER ACCESS PANEL (S/P)

DU6000 CANASTA





DU6000 CANASTA


1	R0910027	DESCONTINUADO
2	R0910005	ROLLER STUD ASSY. (1= 4 PACK) (S/P)
3	R0906507	BUMPER RACK (S/P)
4	R0910006	DESCONTINUADO
5	R0910008	ROLLER ASSY (S/P)
5	R0910007	LOWER ROLLER ASSY (S/P)
6	R0910030	DESCONTINUADO
7	R0905567	RACK SLIDE (S/P)
8	R0903517	END CAP (S/P)
9	R0905577	STUD, TUB ROLLER (S/P)
10	R0910028	TUB ROLLER & BUSHING (S/P)
11	R0904504	GASKET, TUB (S/P)
12	R0900505	WASHER (S/P)
13	R0901007	NUT (S/P)
14	R0901508	FASTNER (S/P)
15	R0905570	LATCH KEEPER (S/P)
17	R0905571	LEVELING LEG (S/P)

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

DU6000 BOMBA





DU6000 BOMBA

1	R0910017	CENTER SPRAY ASSY (S/P)
2	R0905558	ADAPTER PWR TWR (S/P)
3	R0905557	SEAL, SPLIT RING (S/P)
4	R0905525	SPRAY ARM (S/P)
5	R0900014	DESCONTINUADO
6	R0900502	WASHER (S/P)
7	R0905556	DESCONTINUADO
8	R0905555	HUB/PINION ASSY (S/P)
9	R0910016	PINION GEAR (S/P)
10	R0900504	WASHER (S/P)
11	R0900015	SCREW (S/P)
12	R0901004	NUT (S/P)
14	R0910037	CHECK VALVE (S/P)
15	R0901009	SUPT & NUT ARM (S/P)
17	R0901512	CLAMP (S/P)
18	R0901008	NUT SUPPORT (S/P)
19	R0905591	DESCONTINUADO
20	R0901506	CLAMP, SUMP (S/P)
21	R0905521	SPRING, CUTTER (S/P)
22	R0903518	PLUG, TRAP (S/P)
23	R0901510	CLAMP (S/P)
24	R0905563	NUT (S/P)
25	R0905518	WEAR RING BASE (S/P)
26	R0905520	WEAR RING (S/P)
27	R0913111	PUMP IMPELLER (S/P)
28	R0913111	SHAFT SEAL (S/P)
29	R0903502	SEAL (S/P)
30	R0903505	HOSE DRAIN (S/P)
31	R0906504	SEAL, SHAFT (S/P)
32	R0905502	BAFFLE, TUB (RT) (S/P)
33	R0906503	DESCONTINUADO
34	R0913111	SHAFT GUARD/SLINGER (S/P)
35	R0900007	SCREW (S/P)

36	R0905524	BRKT, SOLENOID (S/P)
37	R0909001	DESCONTINUADO
38	R0903506	DESCONTINUADO
39	R0905529	SPRING, GATE ARM (S/P)
40	R0901503	DESCONTINUADO
41	R0905515	GATE VALVE ARM (S/P)
42	R0905530	GATE VALVE ARM KIT (S/P)
43	R0905517	ARMATURE & LINK ASSY (S/P)
44	R0900003	SCREW {J} (S/P)
45	R0910022	HANGER TUBE (S/P)
46	R0901509	FASTENER (S/P)
47	R0905575	HANGER MECH. (S/P)
48	R0900021	SCREW, MECHANISM (S/P)
49	R0907001	MOTOR/PUMP ASSY DISHWA (S/P)
50	R0910001	MOTOR/PUMP ASSY DISHWA (S/P)