


AIR FLOW PARTS

For Models: ED27DQXBW01, ED27DQXBN01, ED27DQXBB01
(White) (Almond) (Black)



4379584

17


Guía	Descripción	# de parte
1	Scroll, Fan	WP2182120
2	Fan Motor Retainer/Bracket	WP2155590
3	SCOOP-AIR	WP2161231
4	Screw	WP488729
5	COVER-EVAP	4388356
7	Evaporator Fan Motor - 120V 60Hz	4389144
8	Evaporator Fan Blade	WP2169142
10	GROMMET, FAN (2)	2155589
11	DUCT	2182146
12	HARNESS, FAN, EVAPORATOR, AND HEATER	2149197
13	Gasket, Fan Scroll	WP2155789
14	Zip Tie	WPW10339879
16	Evaporator Cover Gasket	WP2304241
17	COVER-EVAP	4388356
18	Screw	W11233072
21	Screw	WP489478
22	SUPPORT	4388358
23	SUPPORT	4388358



CABINET PARTS

For Models: ED27DQXBW01, ED27DQXBN01, ED27DQXBS01
(White) (Almond) (Black)

REFRIGERATOR



7-94 Lite In U.S.A. (ROQ)


1

Part No. 4378584,

Guía	Descripción	# de parte
2	Refrigerator Front Roller Kit	4386774
3	SCREW, 5/16-24 X 1-1/4	489393
4	Rear Roller	WPW10250570
5	SREW, 1/4-28 X 1/2 (6)	488454
6	Bottom Kickplate Clip	WP2155013
7	Screw	WP489478
9	SPACER, HINGE	2171882
12	Top Door Hinge	WP2196046
13	USE WPL 2196048	2171868
15	Upper Hinge Cover	WP1129262
15	Upper Hinge Cover	WP1129262
15	Upper Hinge Cover	WP1129262
16	Hinge Kit	4386946
16	Door Hinge Set	8201707
20	SPACER, HINGE	2171883
21	USE WPL 2196097	1127272
21	USE WPL 2196097	1110708
21	FILLTER, WRAPPER, ALMOND	2196095
22	Kickplate Grille - Only Black Available	2155485
23	Screw	WP999367
31	TOP-PLATE, BOTTOM HINGE RETAINER (2)	2147310
35	Screw - 8-18 x 1/2	WP489464
40	CORD-POWER	1113084
41	FITTING	W11566763
42	Extension Tube	WP1108438
43	Clip, Drain Tube	WP1108439
47	Rear Compressor Cover	WP2188755
48	Hood, Canopy Non-serviceable	N/A
49	Door Hinge Cover	1119787
49	Door Hinge Cover	1119787
49	Hinge Cover	2155938
52	USE WPL 3196256	549193
53	Screw	WPW10141645
54	Door Cam - Black	WPW10329686
55	Screw	WP489483

CONTROL PARTS


For Models: ED27DQXBW01, ED27DQXBN01, ED27DQXBB01
(White) (Almond) (Black)



Guía	Descripción	# de parte
1	DISCONTINUED	4389197
2	BRACKET	1110629
3	SCREW (2)	489397
4	Door Light Switch	WP2149705
6	Electronic Defrost Control Board with Wire Harness	4388932
7	Screw	489392
8	BUTTON-PLG	940014
9	Thermostat Assembly	WP2198202
10	Screw	WP965173
11	Cam Assembly	WP2182195
12	BEARING	1110560
13	Screw	WP489478
14	Cam Assembly	WP2182195
15	ARM-PIVOT	W11256541
16	SCREW	627068
17	Light Socket Kit	4387478
18	Refrigerator Thermostat Sensor Barrier	WP2196003
19	Light Bulb - 40W	8009
20	HARNS-WIRE	2195015
21	Clip, Wiring	WP1115374
22	Wiring Clip	1115375
23	ROD	1123960
24	FASTENER	489285
25	ESCUTCHEON	2161213
26	Thermostat Knob - White	2182111
27	Air Control Knob - White	2197871
28	RETAINER	837444
29	WASHER	489203

DISPENSER FRONT PARTS


For Models: ED27DQXBW01, ED27DQXBN01, ED27DQXBB01
(White) (Almond) (Black)



Guía	Descripción	# de parte
4	Hood, Canopy Non-serviceable	N/A
6	Hood, Canopy Non-serviceable	N/A
7	USE WPL 2152716	2152717
8	SLIDE, CUBE/CRUSH, BLACK	2152719
8	Slide for cube/crush switch - white	2152720
8	SLIDE - Almond	2152721
9	Ice Dispenser Door Chute	WP2180353
10	Ice Door Hinge Mechanism with Mounting Brack	WP2147167
12	Ice Door Mechanism	WP1120581
13	Dispenser Overflow Grille - Black Only	WP983900
14	RING-COMPR	987917
15	Lever Bearing	983697
16	Lever Spring	983696
17	SHIELD, WIRING	1119041
19	Spacer	625834
22	Nozzle and Tube Kit	WP4388152
23	Screw	WP965173
24	ARM-DISPSR	2177144
25	Ice Cube Guide	1124730
26	WHITE	488892
27	SLIDE, LIGHT, SWITCH, BLACK	2152724
27	Light Switch Slide	2152726
27	SLIDE	2152727
29	SOCKET	2166862
31	USED W/625846 MOTOR	488361
32	INSULATOR. CONTROL BRACKET	2147164
33	BRACKET, CONTROL	2147163
34	Light Bulb - 10W	WP22002263
35	Single Hex Head Screw	WP489069
36	SCREW, 4-40 X 9/16 (6)	489155
38	Water Dispenser Arm - White	WP2177149
39	OVERLAY	2162923
40	USE WPL 2198154N	2162928
41	SHIELD	1121404
42	BRACKET-WATER	987049
45	Screw	WP3400906
46	Micro Switch	WP2162361

FREEZER DOOR PARTS


For Models: ED27DQXBW01, ED27DQXBN01, ED27DQXBS01
(White) (Almond) (Black)



Guía	Descripción	# de parte
1	DISCONTINUED	4386801
2	USE WPL 1119757	1118417
2	HANDLE	1124713
3	ENDCAP-HDL	1119359
4	Screw	WP489128
5	SHIM	935075
6	DIVIDER	1123293
7	SHELF BIN (4)	2182752
8	Freezer Door Gasket - White	2159074
8	Freezer Door Gasket - Black	2159082
9	TRIM-DOOR	2170920
10	Screw	WP488234
11	ICE CHUTE	2156145
12	Door Closing Cam Kit	4318165
12	Door Closing Cam Kit	4318165
13	Screw	WP999367
14	BRACKET	2155331
15	End Cap Trim Piece	WP2156006
16	RETAINER	941262
17	INSERT-HDL	1119363
17	INSERT-HDL	1118435
17	INSERT-HDL	1119373
18	INSERT-HDL	1119361
18	INSERT-HDL	1119375
18	INSERT-HDL	1118437
19	RETAINER	2194770
20	ENDCAP-HDL	2156220
21	SCREW	489090
22	SCREW	4387279

FREEZER LINER PARTS


For Models: ED27DQXBW01, ED27DQXBN01, ED27DQXBB01
(White) (Almond) (Black)



Guía	Descripción	# de parte
1	Hood, Canopy Non-serviceable	N/A
2	Ice Door Slide	1115380
3	USE WPL 2163423	2162946
5	Screw	WP489478
6	CLIP	2215823
7	Shelf Stud - White	4388405
8	STUD-SHELF	W11581579
9	TRIM-BASKT	2179512
10	BASKET, TOLL	2152096
11	BASKET-FZR	2152090
12	BASKET-FZR	2181763
13	STUD-SHELF	W11581579
14	WIRING, COVER	2155572
15	Screw	WP488729
17	TRACK	1126354
17	TRACK	1126355
18	8-18 X .625 TR CR AB	W11693756
19	SWITCH	W11457217
20	Shelf Support Stud - White	4388538
21	USE WPL 4388537	1115386
22	DOOR-ICE	2174343
23	Shelf	WP2194297K
24	LIGHT LENS	1115389
25	Light Bulb - 40W	8009
26	Light Socket Kit	4387478
27	STUD-SHELF	W11581579
28	TRACK	W10845583
28	TRACK	W10845585
29	SCREW	718257
31	Wire Shelf	WP2174267
32	TRIM-SHELF	2162933

ICEMAKER PARTS

For Models: ED27DCXBN01, ED27DQXBN01, ED27DQXBN01
(White) (Almond) (Black)




4379584

19

Guía	Descripción	# de parte
1	Screw	WPW10141645
2	Ice Maker Water Fill Tube Kit	WP2196157
3	Water Hose Clamp	WP488878
4	Plastic Tubing Inserts - 4 Included	4387491
5	Clip, Fuse	WP628379
7	Water Tube Kit	W10823511
8	Ice Maker Fill Tube Gasket	WP1106508
9	Screw	WP489478
10	Dual Outlet Valve Kit	4318046
11	Compression Nut	WP627018
13	Icemaker Fill Tube Extension Kit	4378431
14	Tube Clamp	WP488366
18	COVER-FRNT	628355
19	Screw	WPW10141625
20	Ice Mold	WPW10190929
22	Water Fill Cup and Bearing	WP628356
23	Ejector Arm	WP627843
24	Ice Stripper	WP2182124
25	Motor Housing	WP2195914
26	Retainer, Thermostat	WP2315522
27	Adhesive Cement	WP4317852
27	Cycling thermostat	WP627985
28	SCREW	8533917
29	Icemaker Control Assembly	W10190935
30	Screw	WP681249
31	ARM-SHUT	W11342242
32	Ice Maker Wire Harness	WP2187464
33	Ice Maker Wire Harness	WP2187464
35	Icemaker Control Assembly	W10190935
36	Screw - 8-32 X 1-1/4	WP488163
37	Icemaker Control Assembly	W10190935
38	SCREW	489136
40	Nut Assembly	4318011
42	Transformer Screw	WP488787
43	Insert	WP1129177

MOTOR AND ICE CONTAINER PARTS

For Models: ED27DQXBW01, ED27DQXBN01, ED27DQXBB01
(White) (Almond) (Black)



4379584


7

Guía	Descripción	# de parte
1	Bracket	WPW10284485
2	Ice Dispenser Kit Motor - 120V 60Hz	WP2188242
3	Soleniod Assembly	WP2152713
4	GUIDE	W10850503
6	Clip, Wiring	WP1115374
7	HARNS-DISP	2169490
8	Screw	WP489399
9	Ice Dispenser Motor Coupling	WPW10169511
10	Screw	WP489478
11	Light Socket Kit	4387478
12	Ice Bucket	WPW10670845
14	Ice Bucket	WPW10670845
15	COUPLING	W10749708
16	STOP-CONE	1118480
17	FEEDER, CONE	1119074
18	Spacer, Step	WP1119005
19	Single Flat Spacer	WP1119007
20	Rotary Blade	W10278732
21	Rotary Blade	W10278732
22	BLADE	W10278733
23	Washer, Plain	WP489235
24	BLADE	1119009
25	Block Blade	2157405
26	PIN-ROLL	489229
27	Ice Auger Kit	W10422851
28	Ice Bin Auger Drum	4388736
29	Ice Bin Auger Drum	4388736
30	Floating Baffle	W10852691
31	Nut, Bearing	WP1119018
32	ARM-CONTRL	W11596045
33	SPRING	1119020
34	CLIP	1119021
35	Transformer Screw	WP488787
37	Refrigerator Ice Crusher Housing	WPW10185018
38	Deflector, Ice	WP1119017
39	WASHER	489234
40	Retainer Ring	WP489236
41	Sleeve Kit	4317870
42	DISCONTINUED	4317811

Guía	Descripción	# de parte
43	ICE DEFLECTOR	1119043
44	USE WPL 2147510	2162949
45	Light Bulb - 40W	8009
46	Light Bulb Lens Cover - White	983359

REFRIGERATOR DOOR PARTS

For Models: ED27DCXBW01, ED27DQXBW01, ED27DQXBB01
(White) (Almond) (Black)



#379504


9

Guía	Descripción	# de parte
2	Complete Dairy Compartment Door - Clear	WP2256101
3	Screw	WP489128
4	Refrigerator Door Shelf Bin	WP2182795
5	INSERT-HDL	1119363
5	INSERT-HDL	1118435
5	INSERT-HDL	1119373
6	Fresh Food Door Gasket	2159075
6	Fresh Food Door Gasket	2159075
6	Fresh Food Door Gasket - Black	2159083
7	HANDLE	1124713
7	HANDLE	943276
7	USE WPL 1119757	1118417
8	ENDCAP-HDL	1119359
9	SHIM	935075
10	INSERT-HDL	1119375
10	INSERT-HDL	1118437
10	INSERT-HDL	1119361
11	Door Closing Cam Kit	4318165
11	Door Closing Cam Kit	4318165
12	Screw	WP999367
13	USE WPL 2155331	2155329
13	USE WPL 2155331	2155329
14	RETAINER	2163566
15	RETAINER	941262
16	RETAINER	2194770
17	ENDCAP-HDL	2156220
18	SCREW	489090
19	SCREW	4387279
20	TRIM-DOOR	4318791
20	DIVIDER	2195498
20	Trimless Black Panel Kit	4318947
20	Woodgrain Handle	4210446

Guía	Descripción	# de parte
1	Hood, Canopy Non-serviceable	N/A
2	USE WPL 1116612	985468
3	Cold Control Slide	984102
4	Slide Pad	992358
8	Shelf Support Stud - White	4388538
11	Screw	WP488488
13	Drawer Rail - Left Side	WP1114633
14	Shelf Track - Left Side	WP1115265
14	Shelf Track - Right Side	W10853640
16	USE WPL 1115261	1124828
17	Shelf Support Stud	WP1114631
22	Bracket Retainer	WP2256085
24	Air Diffuser Assembly	WPW10151374
25	COVER	2152019
26	COVER-WIRE	2150331
27	SCREW	W10759522
29	Light Socket Kit	4387478
31	Water Dispenser Reservoir Tubing	WP2256126
33	Light Bulb - 40W	8009
34	LIGHT LENS	2169504
37	SCREW	798639

REFRIGERATOR SHELF PARTS


For Models: ED27DQXBW01, ED27DQXBN01, ED27DQXBB01
(White) (Almond) (Black)



Guía	Descripción	# de parte
1	SHELF-GLAS	2162991
2	PAN-SNACK	1115262
3	Crisper Cover Frame - NO Glass	WP1126289
4	Crisper Shelf Front Gasket	1115291
5	Rear Crisper Drawer Gasket	1121385
6	USE WPL 1110795	2162845
7	Crisper Drawer Glass Cover	WP1114687
8	Crisper Drawer Cover	WP2148298
10	USE WPL 2168851	2162860
11	USE WPL 2162712	2162854
12	SLIDE	2162849
13	SCREW, 6-19 X 3/8 (3)	489162
3	PAN-MEAT	2162932
15	Egg Container	W10136387A
16	Egg Carrier	WP2177817
17	USE WPL 2169935	2164374
18	TRIM-COVER	2162989
19	Shelf Support Stud - White	4388538
20	Shelf Support Stud	WP1115290
21	Shelf Support Stud	WP2149540
22	Shelf Support Stud - White	4388538

UNIT PARTS

For Models: ED27DQXBW01, ED27DQXBN01, ED27DQXBB01
(White) (Almond) (Black)



Guía	Descripción	# de parte
1	Speed Nut	WP486692
2	Condenser Fan Blade	WP1108179
3	CONDENSER	2198175
4	Screw - 8-18 x 1/2	WP489464
5	CLIP	2208280
6	SCREW	681390
7	CLIP	2200079
8	SLEEVE	W11661094
9	Compressor Dampener	WP2158826
11	RETAINER	943322
12	Terminal Cover	1105055
13	OVERLOAD	4388953
15	Hood, Canopy Non-serviceable	N/A
17	Capacitor	WPW10662129
19	USE WPL 937252	509812
21	Screw	WP489478
22	USE WPL 2155501	2164519
23	Clip, Heater	WP2161324
24	Condenser Fan Motor Kit	833697
25	Evaporator Tray	1110674
26	USE WPL 2256150	2149294
27	Filter Drier Tube	W10843121
28	Refrigerator Compressor	W10439638
28	TUBE-KIT	876765
29	8-18 X .625 TR CR AB	W11693756
30	Unit Mounting Frame	2304904
31	HARNS-WIRE	2176859
32	STRAP	548695
33	Defrost Heater	2161323
34	CLIP, HEATER (2)	2161330
35	Bi-Metal Defrost Thermostat	WPW10225581
37	SCREW	489387
38	Wire Assembly (Production)	WP2172890
39	PRODUCTION	2162067
40	SCREW	489340
41	BAFFLE-AIR	W10896764
42	CLIP, HEATING	2155547
43	COVER-UNIT	W10466698
44	CLIP	489396

Guía	Descripción	# de parte
48	Unit Mounting Rail	2305374
49	SCREW	4159456
50	GUARD-FAN	1110663
53	Screw	WP489427
54	WIRE, CONNECTOR	227991
55	Screw	WPW10141625
59	TUBE, SPRING FORMING	983659
63	Access Valve - 3/16 Inch	876764
63	Access Valve - 5/16 Inch	978026