

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas


# Lavadora Whirlpool ETW4400WQ1



## TOP AND CABINET PARTS

For Model: ETW4400WQ1  
(White)

AUTOMATIC  
WASHER



Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas

## Lavadora Whirlpool ETW4400WQ1

<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
1	Energy Guide	W10062895
1	Feature Sheet (English/French)	W10150642
1	Feature Sheet (Spanish)	W10150643
1	Wiring Diagram	W10199994
1	Installation Instructions (Spanish)	W10200662
1	Use & Care Guide (English/French)	W10200843
1	Use & Care Guide (Spanish)	W10200844
1	INSTALLATION INSTRUCTIONS	W10200890
2	Bumper, Lid (2)	9724509
3	Lid	8541774
4	Screw, Lid Hinge Mounting (4)	W10119828
5	Hinge, Lid (L.H.)	W10225135
6	Hinge, Lid (R.H.)	91770
7	Cabinet	63424
8	Screw, Ground	3351614
9	Switch, Lid	8318084
10	Clip, Top & Cabinet & Rear Panel (2)	62780
11	Dispenser, Bleach	3362952
12	TOP	8318064
13	Nut, Push-In (2)	357213
14	Bearing, Lid Hinge (2)	21258
15	Spacer, Cabinet To Top (4)	62750
16	Screw, 10-16 x 3/8 (4)	3390631

Distribuidor Autorizado


SurteRápido.com

Venta de Refacciones  
Electrodomesticas

Lavadora Whirlpool ETW4400WQ1

## CONTROLS AND REAR PANEL PARTS

For Model: ETW4400WQ1  
(White)



Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas

## Lavadora Whirlpool ETW4400WQ1

<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
1	HARNES WIRING	W10307145
2	Screw, 8-18 x 1/2	9740848
3	Cable Tie	3347868
4	U-Bend, Drain Hose	8577378
5	Strap, Console (2)	8568314
6	Panel, Rear	W10194450
7	Pad, Rear Panel	62747
8	Drain Hose Assembly (Includes Item 19)	W10189267
9	Timer, Control (60 Hz.)	W10199989
10	Screw, Ground	3351614
11	Screw, 8-18 x 3/8	90767
12	SWITCH, WATER LEVEL	W10231403
13	Bracket, Control	3948608
14	Cord, Power (Includes Item 15)	8578842
15	Strain Relief, Power Cord	3952821
16	Cap, End (L.H.)	8274437
17	Cap, End (R.H.)	8274434
18	Valve, Water Inlet W	W10144820
19	Clamp, Hose	8541668
20	Screw, 10-16 x 3/8	62863
21	Knob, Timer	8538949
22	Dial, Timer	8538955
23	Knob, Control	8538957
24	Clip, Knob	8536939
25	Clip, Capacitor	8318046
26	Support, Rear Panel	8519200
27	Clip, Push-In Retainer	W10000080

Distribuidor Autorizado

SurteRápido.com


Venta de Refacciones  
Electrodomesticas

Lavadora Whirlpool ETW4400WQ1

### AGITATOR, BASKET AND TUB PARTS

For Model: ETW4400WQ1

(White)



Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas

## Lavadora Whirlpool ETW4400WQ1

<b><u>No. Ilus.</u></b>	<b><u>DESCRIPCIÓN</u></b>	<b><u>No. de Parte</u></b>
<b>1</b>	Cap, Agitator	3355758
<b>2</b>	Screw & Washer	358237
<b>3</b>	Washer	3949550
<b>4</b>	Agitator	3347288
<b>5</b>	Tub Ring	8528150
<b>6</b>	Gasket, Tub Ring	3976308
<b>7</b>	Nut, Spanner	21366
<b>8</b>	Balance Ring	387240
<b>9</b>	Basket	8526017
<b>10</b>	Clip, Pressure Switch Hose	2219077
<b>11</b>	Hose, Pressure Switch	3347780
<b>12</b>	Block, Basket Drive	389140
<b>13</b>	Tub	63849
<b>14</b>	GASKET, CENTERPOST	383727
<b>15</b>	Agitator (Complete)	3348117
<b>16</b>	Clothes Mover	3348752
<b>17</b>	Dog, Agitator (4)	3366877
<b>18</b>	Bearing, Driven Cam	3363661
<b>19</b>	CAM, DRIVEN	3363663
<b>20</b>	Spacer, Thrust	3350389
<b>21</b>	Cap, Barrier	3354733
<b>22</b>	Seal, Inner Cap	W10072840

Distribuidor Autorizado


SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# Lavadora Whirlpool ETW4400WQ1

## BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS

For Model: ETW4400WQ1  
(White)



Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas

## Lavadora Whirlpool ETW4400WQ1

<b>No. Ilus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>1</b>	Brake & Drive Tube (Complete)	388952
<b>2</b>	Washer, Spin Tube Thrust	63292
<b>3</b>	Ring, Spin Tube Support	62697
<b>4</b>	Ring, Retainer	63283
<b>5</b>	Clutch (Complete)	3951311
<b>6</b>	Band & Lining, Clutch	3951308
<b>7</b>	Cap, Clutch Spring (2)	62646
<b>8</b>	Spring, Clutch	3946792
<b>9</b>	Gearcase (Complete)	3360630
<b>10</b>	Screw, Gearcase To Base (3)	3357334
<b>11</b>	Plate, Motor Mount To Gearcase	62611
<b>12</b>	Grommet, Motor (4)	62691
<b>13</b>	Coupling, Motor And Isolation	3364003
<b>14</b>	Seal	8577374
<b>15</b>	Clip, Anti-Rattle	3355454
<b>16</b>	Screw	3400516
<b>17</b>	Retainer, Motor (2)	W10086010
<b>18</b>	Shield, Tub To Motor	3362089
<b>19</b>	MOTOR, MAIN DRIVE	W10210608
<b>21</b>	Retainer, Pump (2)	8546127
<b>22</b>	PUMP (COMPLETE)	W10288040
<b>23</b>	Screw, 10-16 x 5/8	3387485
<b>24</b>	Shield, Motor	3946532



Distribuidor Autorizado

SurteRápido.com


Venta de Refacciones  
Electrodomesticas

Lavadora Whirlpool ETW4400WQ1

### MACHINE BASE PARTS

For Model: ETW4400WQ1

(White)



Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas

## Lavadora Whirlpool ETW4400WQ1

<b>No.Illus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
<b>1</b>	Screw, Bracket Mounting (10-32 x 5/8)	3400076
<b>2</b>	Bracket, Spring Outer (2)	64067
<b>3</b>	SPRING, SUSPENSION (3)	63907
<b>4</b>	Support & Brake, Tub	8575214
<b>5</b>	Bracket, Spring Outer (L.F.)	64065
<b>6</b>	Link, Leveling Mechanism (2)	63466
<b>7</b>	Spring, Leveling Mechanism	62597
<b>8</b>	Pin, Knurled	62837
<b>9</b>	Foot, Rear (2)	62596
<b>10</b>	Bearing, Centerpost (2)	8546455
<b>11</b>	Seal, Centerpost (3)	357409
<b>12</b>	Spring, Counterweight	8534035
<b>13</b>	Pad, Plate	62568
<b>14</b>	Plate, Suspension (Includes Item 13)	3946509
<b>15</b>	Pad, Base	3363660
<b>16</b>	Base Assembly (7, 8, 9, 13, 14, 15 & 22)	285771
<b>17</b>	Nut, Lock (2) (3/8-16)	3359452
<b>18</b>	Foot, Front (2)	W10001130
<b>19</b>	Seal, Centerpost	8577376
<b>20</b>	CENTERPOST BEARING KIT (10, 11 & 19)	285203
<b>21</b>	Ring, Sound Deadening	63134
<b>22</b>	Retainer, Suspension Spring	W10145155

Distribuidor Autorizado


SurteRápido.com

Venta de Refacciones  
Electrodomesticas

Lavadora Whirlpool ETW4400WQ1

## WIRING HARNESS PARTS

For Model: ETW4400WQ1  
(White)



Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas

## Lavadora Whirlpool ETW4400WQ1

<b><u>No. Ilus.</u></b>	<b><u>DESCRIPCIÓN</u></b>	<b><u>No. de Parte</u></b>
<b>1</b>	Retainer, Harness	3349557
<b>2</b>	Clip, Harness	388498
<b>3</b>	Clip, Harness	3347812
<b>4</b>	Clip, Harness (Push-In)	3352501
<b>5</b>	Clip, Harness (Half-Harness)	90016
<b>6</b>	Clip, Harness	3390496
<b>7</b>	Retainer, Harness	389379
<b>8</b>	Timer, Block Disconnect (Black)	352089
<b>8</b>	Timer, Block Disconnect (Natural)	3948614
<b>9</b>	Receptacle, Terminal (3-Way)	62889
<b>10</b>	Plug, Terminal (3-Way)	353424
<b>11</b>	Block, Disconnect (Motor 2 Speed)	62505
<b>12</b>	Block, Disconnect	3347243
<b>13</b>	Protector	63523
<b>14</b>	Connector, 2-Way	717252
<b>15</b>	Clip, Harness	3352944
<b>16</b>	Block, Disconnect (12-Way)	3390423
<b>17</b>	Receptacle, 6 Way	3347730
<b>18</b>	Connector (T.P.A.) (3-Circuit)	3948617
<b>19</b>	Plug (T.P.A) (3-Circuit) (Pressure Switch)	3360056
<b>20</b>	Block, Connector (Natural)	3354925
<b>20</b>	BLOCK, CONNECTOR (RED)	3354926

Distribuidor Autorizado


SurteRápido.com

Venta de Refacciones  
Electrodomesticas

Lavadora Whirlpool ETW4400WQ1

## BRAKE AND DRIVE TUBE PARTS

For Model: ETW4400WQ1  
(White)



Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas

## Lavadora Whirlpool ETW4400WQ1

<b><u>No. Ilus.</u></b>	<b><u>DESCRIPCIÓN</u></b>	<b><u>No. de Parte</u></b>
NI	LUBRICANT	285208
1	Brake And Drive Tube (Complete)	388952
2	Ring, Thrust	62658
3	Seal, Drive Tube	356427
4	TUBE, BASKET DRIVE ( 3, 4, 5 & 9)	64027
5	Ring, Retaining	64035
6	Shoe, Brake (2)	64232
7	``T`` Bearing, Spin Tube	62703
8	Cap, Brake Spring (2)	3353956
9	Spring, Brake	387806
10	Sleeve, Brake Spring	3355360
11	Cam, Brake Release	661516
12	Sleeve, Cam	63022
13	Driver, Brake Cam	64194
14	Ring, Retaining	90368

Distribuidor Autorizado

SurteRápido.com


Venta de Refacciones  
Electrodomesticas

# Lavadora Whirlpool ETW4400WQ1

## GEARCASE PARTS

For Model: ETW4400WQ1

(White)



Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas

## Lavadora Whirlpool ETW4400WQ1

<b>No.illus.</b>	<b>DESCRIPCIÓN</b>	<b>No. de Parte</b>
1	Gearcase (Complete)	3360630
2	Cover, Gearcase	285202
3	Seal, Gearcase Cover	3349985
4	SEALER, GASKET (.20 FL. OZ.) (6 ML)	285195
5	Pinion, Spin (Includes Illus. 25)	63320
6	Seal, Spin Pinion	356427
7	Shaft, Agitator (Complete)	389387
8	Ring, Retaining (2)	90369
9	Retainer, Spring	62677
10	Spring, Agitate	62676
11	Gear, Agitate (Includes 15 and 29)	63273
12	Washer, Agitate Gear	62619
13	Cam Follower (Includes 14)	62580
14	Cam, Agitate (Includes 13)	62581
15	Shaft, Agitator (Includes 11 and 29)	285509
16	Washer, Cam Thrust	62618
17	Bearing, Thrust	16018
18	Ball, Bearing	85529
19	Bottom and Pinion, Gearcase	389230
21	Seal, Thrust Plug	285352
22	SCREW, GEARCASE COVER MOUNTING	3351614
23	Ring, Retaining	3362552
24	Washer Kit, Thrust	285735
25	Gear, Spin	3360629
26	Neutral Assembly	388253
27	Rack, Connecting	3360629
28	Actuator, Shift	3360629
29	Washer, Intermediate	388815