


Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# SECADORA FRIGIDAIRE EWMGD70JRR0



Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas



## SECADORA FRIGIDAIRE EWMGD70JRR0

Guía	Número de parte	Descripción
2	131168200	Laundry appliance screw, #8-18 x 31/100-in
3	134766500	Dryer control kn
3A	137063600	Dryer knob r
4	134871900	Pipe
5	134767800	Pipe
7	137007800	Trim
8	134767600	Lens
9	134768400	Pipe
10	137007900	Laundry appliance control button cap
11	137043100	Button
12	137010900	Button
13	137021200	Button
14	137009900	Button
15	137008100	Button
16	134994610	Dryer user interf
19	134402900	Laundry applian
22	134790700	Dryer user interface wire harness
23	137016100	Dryer harness
24	134638510	Washer top panel
24	134638515	Panel
24	134638520	Panel
24	134638525	Laundry appliance top panel (silver)
24	134638530	Panel
26	131205100	Washer screw
27	137317411	Control panel
27	137317415	Panel
27	137317420	Panel
27	137317412	Washer control panel

Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas



## SECADORA FRIGIDAIRE EWMGD70JRR0






Guía	Número de parte	Descripción
27	137317430	Panel
27A	134710900	Dryer control
27B	134711000	Bracket

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# SECADORA FRIGIDAIRE EWMGD70JRR0



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas



## SECADORA FRIGIDAIRE EWMGD70JRR0

Guía	Número de parte	Descripción
2	131168200	Laundry applian
4	134792100	Bracket
7	5303161296	Laundry appliance fill hose washer
8	134694400	Cover
15	137031800	Cushion
16	5304509715	Dryer heat duct
17	134792900	Insulator
18	131168200	Laundry appliance screw, #8-18 x 31/100-in
19	134711200	Dryer thermistor
20	134705900	Dryer drum seal
21	137610800	Dryer drum
23	134786100	Dryer moisture sensor
25	137297500	Bracket
26	137032530	Washer control
27B	134690203	Dryer cabinet
27L	134712610	Dryer side panel
27L	134712615	Panel
27L	134712620	Panel
27L	134712625	Panel
27R	134712630	Panel
27R	134712710	Panel
27R	134712715	Panel
27R	134712720	Panel
27R	134712725	Panel
27R	134712730	Panel
28	137560425	Panel
28A	137029801	Bracket
29	131205100	Washer screw

Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas



## SECADORA FRIGIDAIRE EWMGD70JRR0


Guía	Número de parte	Descripción
30	137610900	Vane
30A	137611100	Vane
31	134501000	Washer power cord
34	215822000	Refrigeration appliance screw
35	134713100	Bracket
40	134715900	Dryer drum supp
40A	134716700	Dryer washer
41	134716800	Dryer nut, 3/8
44	216396900	Appliance leveling leg
45	134712823	Bulkhead
51	5304500709	Dryer water
52	131202300	Laundry applian
53	137471800	Hose
54	137471700	Dryer water
61	218470300	Refrigerator water inlet valve assembly
62	137474500	Dryer mist hose adapter
63	137016500	Ring
64	137016300	Tube
65	137017200	Grommet
66	5304521480	Nozzle assem
67	137017400	Clip
68	5304521480	Nozzle assem

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones Electrodomesticas

# SECADORA FRIGIDAIRE EWMGD70JRR0



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas



## SECADORA FRIGIDAIRE EWMGD70JRR0

Guía	Número de parte	Descripción
1	134784700	Seal
2	131168200	Laundry applian
5	134912700	Dryer drying
6	134708300	Dryer lint duct
7	137046800	Laundry applian
7A	137046700	Laundry appliance door trim ring clip
8	134700900	Dryer lint screen cover
10	134933900	Dryer door latch kit
12	134696901	Washer door inner frame
15	134704600	Dryer door hinge
16	134788000	Dryer screw, #8 x 1.18-in
17	134792900	Insulator
18	131168200	Laundry appliance screw, #8-18 x 31/100-in
19	134790400	Washer screw
20	137553000	Dryer door seal
22	137553710	Panel
22	134696315	Panel
22	134696320	Panel
22	137553755	Panel
22	134696330	Panel
25	137538802	Dryer door latch
26	134813600	Dryer door switch
26	134813660	Dryer door switch
27	134793600	Dryer lint screen
27A	134790600	Laundry appliance screw
28	137034500	Dryer front panel clip
40	134715900	Dryer drum support roller
40A	134716700	Dryer washer



Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas



## SECADORA FRIGIDAIRE EWMGD70JRR0


Guía	Número de parte	Descripción
41	134716800	Dryer nut, 3/8-16
42	137556105	Dryer bulkhead
46	134934900	Dryer door glass seal
47	5304505715	Washer door trim ring
48	134618900	Cover
49	134651200	Laundry center washer door trim ring clip
50	131302800	Washer baffle screw
51	137459300	Dryer door strik
56	137576000	Dryer door glass
57	137067900	Laundry appliance door outer lens
58	137067900	Laundry appliance door outer lens
59	134931500	Cover
60	134430300	Dryer screw, #10
68	134742000	Plug
68	134742002	Washer door hinge hole cover (gray)
70	137526000	Dryer drum led lamp

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# SECADORA FRIGIDAIRE EWMGD70JRR0



Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas



## SECADORA FRIGIDAIRE EWMGD70JRR0


Guía	Número de parte	Descripción
2	131168200	Laundry appliance
4	134707900	Dryer motor clamp
7	134693900	Dryer exhaust duct
8	134711401	Dryer exhaust thermal limiter
8A	134935200	Dryer screw, 8 x 32-1/4-in
10	134690800	Dryer blower wheel and housing assembly
15	134711300	Dryer thermistor
20	131017900	Screw
23	134784400	Dryer idler assembly
25	134719300	Dryer drum belt
27	134242400	Dryer motor clamp
28	137116000	Dryer drive motor
34	215822000	Refrigeration appliance screw
46	134707400	Dryer motor bracket
47	131633300	Dryer exhaust duct seal
52	131168200	Laundry appliance screw, #8-18 x 31/100-in

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones  
Electrodomesticas

# SECADORA FRIGIDAIRE EWMGD70JRR0



Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas



## SECADORA FRIGIDAIRE EWMGD70JRR0

Guía	Número de parte	Descripción
2	131168200	Laundry appliance
4	134713901	Dryer burner bracket
8	137539200	Dryer safety thermostat
8A	134935200	Dryer screw, 8 x 32-1/4-in
33	137116700	Dryer high-limit thermostat
34	215822000	Refrigeration appliance screw
55	137029500	Dryer wire harness
61	134715801	Dryer burner bracket
64	137019000	Pipe
65	08015112	Pipe
70	5303207409	Dryer gas valve assembly
71	5303931775	Dryer valve coil kit
72	5303931775	Dryer valve coil kit
73	5303207410	Dryer burner orifice
74	5304517325	Dryer burner igniter
76	134714401	Collar
77	134197700	Dryer burner
79	5303281135	Dryer radiant sensor