


LAVADORA GHW9300PW4

CONTROL PANEL PARTS

For Model: GHW9300PW4

(White/Platinum)



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas


LAVADORA GHW9300PW4

Guía	Descripción	Refacción
1	PANEL CONTROL	8182716
2	USER INTERFASE	8182785
3	POWE PUSH BUTTON	WP8181860
4	HOLD TO START BUTTON	WP8181861
5	SOIL LEVEL PUSH BUTTON	8181863
6	PUSHBUTTON	8182275
7	PUSHBUTTON	8181889
8	SPIN/TEMPERATURE PUSH BUTTON	8181865
13	BRACKET	8182224
15	CONTROL BOARD	8182789
16	SCREW	WP488729
17	HARNS-WIRE	8182212
19	DISPENSER DRAWER HANDLE	WP8181887
20	BEZEL CLEAR	8181855
21	OVERLAY	8181857
23	CONTROL KNOB	WP8181859
24	ENDCAP	8181852
25	ENDCAP	8181853

LAVADORA GHW9300PW4

DISPENSER PARTS

For Model: GHW9300PW4
(White/Platinum)



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas


LAVADORA GHW9300PW4

Guía	Descripción	Refacción
1	WATER INLET VALVE	WP8182862
2	JOSE, INLET VALVE TO DISPENSER	8182683
3	CLAMP	WP489503
7	NOZZLE	280194
9	RING-O	280196
11	CAM	8181726
12	LEVER, WATER DISTRIBUTION	WP8181725
13	WASHER DISPENSER ACTUATOR MOT	WPW10665207
15	SPRING	8181727
16	LEVER, WATER DISTRIBUTION	8181724
17	WASHER DISPENSER	280198
18	NOZZLE, DISTRIBUTION	WP8181712
19	SEAL	WP8181747
20	DISPENSER DRAWER HANDLE	WP8181887
21	DETERGENT DISPENSER DRAWER	WP8181720
22	CONTAINER, DETERGENT	WP8181722
23	SIPHON. BLEACH/SOFTENER	8182665
24	DIVIDER	8182131
25	DRAWER HOOK	WP8181721
26	CAP	8182123
27	HARNS-WIRE	8182863
28	COVER	8181898

LAVADORA GHW9300PW4

DOOR AND LATCH PARTS

For Model: GHW9300PW4
(White/Platinum)



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

LAVADORA GHW9300PW4


Guía	Descripción	Refacción
5	WASHER DOOR BELLOW	WP8182119
6	BELLOW TO OUTER TUB CLAMP	WP8182210
7	DOOR LOCK LATCH	WP8182634
8	SCREW	WP8540725
9	DOOR HOOK/STRIKE	WP8181651
10	SCREW	W11230114
14	BELLOW CLAMP	W10902779
15	CLAMP	8181659
16	CLAMP	8181650
17	SCREW	8181785
21	INNER DOOR GLASS	8181655
22	DOOR, BACK SUPPORT	8182628
23	DOOR HINGE	8181843
24	SCREW	WP8181660
25	SCREW	WP8540282
26	DISPENSER TO BELLOW TUBE	WPW10005300
27	TRIM	8181842
28	COVER	8181841
29	HINGE COVER	8181844
30	TRIM-WHITE	8181840
31	DOOR HANDLE	WP8181846
32	CLIP. TRIM	WP8182779
33	TRIM	8181839
34	SCREW	WP3400805

LAVADORA GHW9300PW4

PUMP AND MOTOR PARTS

For Model: GHW9300PW4

(White/Platinum)



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

LAVADORA GHW9300PW4

Guía	Descripción	Refacción
1	ELECTRONIC CONTROL BOARD	W10756692
4	CHECK DRAIN BALL	W10121657
5	CLAMP	WP696392
6	PUMP HOSE	WPW10467168
7	HOSE CLAMP	WP285655
8	GROMMET, DAMPER REAR	8182820
9	HOSE CLAMP	WP3367052
10	DRAIN PUMP KIT	280187
11	GROMMET, DAMPER FRONT	WPW10526202
13	FILTER CAP SEAL	WP8181736
14	FILTER CAP	8183027
16	DRIVE MOTOR WITH PULLEY	WP8182793
17	WIRING HARNESS	WPW10137867
18	SCREW	W10128585
19	CLIP	8182209
20	DRAIN HOSE	WPW10003250


LAVADORA GHW9300PW4



TOP AND CABINET PARTS

For Model: GHW9300PW4
(White/Platinum)

AUTOMATIC
WASHER



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

LAVADORA GHW9300PW4


Guía	Descripción	Refacción
1	TECH SHEET	8182677
2	USE WPL 8181641	8181799
3	USE WPL 8182609	8181630
4	PANEL	8181838
5	PANEL	8181643
6	LEVELLING LEG	8181636
7	BRACKET. SPRING	WP8181763
8	BRACE, SIDE PANEL	8183008
9	PANEL	8181635
10	PANEL, REAR	8182698
11	BRACE	WPW10003040
12	SHIPPING BOLT KIT	W10289554A
13	INLET HOSE	WP89503
14	CORD,, POWER	WP8183009
15	RELIEF-STR	8182635
16	BRACE, REAR	8182607
17	CLIP, DRAIN HOSE	8182701
18	HOSE, DRAIN	WP8181737
19	CONNECTOR, DRAIN HOSE	WP8181738
20	HOSE CLAMP	WP3367052
22	NOISE FILTER	WPW10367632
23	WATER LEVEL/PRESSURE SWITCH	WPW10514214
24	WATER LEVEL/PRESSURE SWITCH HOSE	WPW10004260
25	SCREW	8181691
26	COVER, TRANSPORT	WP8540268
27	RETAINER	WPW10280024
28	SCREW	WP488729
29	MICROSWITCH	WPW10085220
30	GROMMET	W11116978
31	SCREW	8182201
32	CLIP, OUTER HOSE HOLDER	8182702

LAVADORA GHW9300PW4

TUB AND BASKET PARTS

For Model: GHW9300PW4

(White/Platinum)



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

LAVADORA GHW9300PW4

Guía	Descripción	Refacción
1	NUT	WPW10283361
2	DRUM DRIVE PULLEY	WP8182650
3	DRIVE BELT	WPW10388414
4	COVER	8181745
5	VENT-PIPE	8181744
6	CLAMP, VENT HOSE	8540010
7	HOSE, EXHAUST	WP8181743
8	TUB-OUTER	W10772617
9	USE WPL W10008870	8181913
10	GASKET, TUB	WP8181673
11	USE WPL W10250573	8182232
12	WASHER BAFFLE	WP8182233
13	RING-O	WPW10250553
14	AIR TRAP	8181731
15	COUNTERWEIGHT-FRONT	WPW10008880
16	SPRING	W10135004
17	SCREW-KIT	W10182109
18	HOSE CLAMP	WP3367052
19	HOSE, TUB TO DISPENSER	WP8181794
20	CLAMP, TUB	WP8540092
21	OUTER TUB	W10772607
22	NUT, PUSH-IN	WP8182512
23	SHOCK ABSORBER	W10822553
24	TEMPERATURE SENSOR	WPW10467289
25	WATER HEATER ASSEMBLY	WPW10426377
26	BRACKET	W10250558
27	SCREW	WPY706189