

Distribuidor Autorizado


SurteRápido.com

Venta de Refacciones
Electrodomesticas

MICROONDAS HMM700WK

HORNO DE MICROONDAS
MICROWAVE OVEN

HMM700WK



Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

MICROONDAS HMM700WK

Guía	Refacción	Descripción
1	WG02L00301	GLASS TRAY
1	WG02L00654	GLASS TRAY
2	WG02L00492	ROLLER RING
2	WG02L00650	ROLLER RING
3	WG02F01504	SPLASH SHIELD
3	WG02L00816	SPLASH SHIELD
9	WG02F00620	H.V. CAPACITOR
9	WG02F12430	H.V. CAPACITOR
10	WG02F00648	H.V. DIODE
10	WG02F12429	H.V. DIODE
13	WG03F00784	CAPACITOR HOLDER
15	WG02F01230	P.C BOARD
16	WG02F01679	THIN FILM SWITH
16	WG02F02218	THIN FILM SWITH
17	WG02F05096	PROTECCION DE GOMA
18	WG02F00890	LEVER
18	WG02L00663	LEVER
19	WG02F00930	LOWER HINGE
19	WG02L00661	LOWER HINGE
20	WG02F01807	TURNTABLE MOTOR
20	WG02F01809	TURNTABLE MOTOR
21	WG02F01723	TRANSFORMER
21	WG02F12439	TRANSFORMER
22	WG02F05095	CABLE DE ALIMENTACIÓN
23	WG02A00131	WIRING HARNESS
23	WG02F12440	WIRING HARNESS
24	WG02F01046	MICROSWITCH
24	WG02F10585	MICROSWITCH
25	WG02F04895	MICRO SWITCH
25	WG02F02211	MICRO SWITCH
26	WG02F01047	MICROSWITCH
26	WG02F10168	MICROSWITCH
27	WG02F00948	MAGNETRON
27	WG02F12435	MAGNETRON
28	WG02F01618	THERMOSTAT

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



MICROONDAS HMM700WK

Guía	Refacción	Descripción
29	WG02F04894	LÁMPARA
29	WG02F10163	LÁMPARA
30	WG02F01204	OUTER ENCLOSURE
32	WG02F01639	THERMOSTAT 1
32	WG02F10164	THERMOSTAT 1
33	WG02A00620	LABEL
34	WG02F01090	MICROSWITCH MOUNTING
34	WG02F02224	MICROSWITCH MOUNTING
35	WG02L00242	FOOT
37	WG02L00031	BASE PLATE
37	WG02L00660	BASE PLATE
41	WG02F00150	BUTTON
44	WG02L00086	CAVITY
46	WG02F01876	WAVE FILTER
49	WG02F00505	FAN SHROUD
49	WG02F13679	FAN SHROUD
50	WG03F00798	FAN BLADE
50	WG02F13680	FAN BLADE
51	WG02F00494	FAN MOTOR
51	WG02F12432	FAN MOTOR
53	WG02L00197	DOOR HOOK
53	WG02L00652	DOOR HOOK
54	WG02L00201	DOOR HOOK SPRING
54	WG02L00653	DOOR HOOK SPRING
57	WG02F00546	FLAKE(IN DOOR FRAME)
57	WG02A02377	FLAKE(IN DOOR FRAME)
60	WG02L00049	BOARD SEAL
60	WG02F02227	BOARD SEAL
67	WG02F00471	FACE BOARD
71	WG02L00186	DOOR FRAME
71	WG02L07357	DOOR FRAME
73	WG02F00245	CHOKE COVER
73	WG02L00649	CHOKE COVER
74	WG02L00143	DOOR (WITH INLAIDS)
75	WG02L00541	UPPER HINGE

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas



MICROONDAS HMM700WK

Guía	Refacción	Descripción
84	WG02F00021	AIR DUCT
85	WG02F00168	BUTTON SPRING
85	WG02F02225	BUTTON SPRING
110	WG02L00220	DOOR WINDOW
116	WG02F01033	MICA FLAKE
117	WG02F02202	LAMP SOCKET
117	WG02F10178	LAMP SOCKET