

Distribuidor Autorizado

SurteRápido.com

Venta de Refacciones
Electrodomesticas

Secadora Whirlpool IED4400VQ1


Inglis

CABINET PARTS

For Model: IED4400VQ1
(Designer White)

29" ELECTRIC DRYER

by Whirlpool Corporation





Secadora Whirlpool IED4400VQ1

Guía	N.P.	Descripción
1	3393008	Screw, 10-16 X 1/2
2	343641	Screw, 10-16 x 1/2
3	693995	Screw, Hex Washer Head
4	8541400	Bracket, Cabinet
5	3396795	Cover, Block
6	3403630	Plug, Strike
7	3396805	Panel, Rear
8	697776	Screw, 10-32 x 5/8 (External Ground)
9	3405246	Seal, Door
10	3406109	Door Switch Assembly
11	697773	Screw, 6-20 x 7/8
12	3397659	Block, Terminal
13	3404413	Plug, Hinge
14	8066217	Hinge, Top (2)
15	3394083	Clip, Front Panel (2)
16	279810	FOOT, OPTIONAL
16	3392100	Foot, Dryer
17	279318	Terminal, Tinned & Brass (3)
18	8530603	Cabinet (Includes Illus. 4)
19	98234	Clip, Ground
20	690363	Lock, Front Top (2)
21	W10224853	Panel, Front
22	691366	Idler & Pulley Assembly
23	685203	Clip, Felt Pad (2)
24	3389441	Catch, Door Assembly
25	W10131364	Belt, Drive
26	348780	Base, Motor
27	342055	Screw, 8-18 x 1/2




Secadora Whirlpool IED4400VQ1

Guía	N.P.	Descripción
28	3405514	Hinge, Door (2)
29	3400500	Bolt, 5/16-18 x 3/4
30	8066184	PULLEY 60 HZ.
31	W10194250	Motor Assembly
32	W10121316	Clamp, Motor Mount
33	3403431	Strike, Door
34	3404162	Clamp, Motor (W/Shield)
35	3402341	Door, Rear
36	3402335	Door, Front
37	3405184	Handle, Door
38	3406129	Seal & Bearing Assembly
39	279393	Terminal Block Kit (For Terminal Block)

TOP AND CONSOLE PARTS

For Model: IED4400VQ1
 (Designer White)






Secadora Whirlpool IED4400VQ1

Guía	N.P.	Descripción
1	8274261	Panel, Rear Console
2	8533951	Screw, Grounding
3	8533971	Screw, 8-18 x 5/16
4	8274437	Cap, End (L.H.)
5	W10207807	Panel, Control
6	388326	Screw, Console
7	693995	Screw, Hex Head
8	8274434	Cap, End (R.H.)
9	3395683	Housing, Connector (Motor)
10	8558463	Screen, Lint
11	8271418	Bracket, Control
12	8538959	Knob, Push-To-Start
13	688983	Screw, 8-18 x 5/8
14	8536939	Clip, Spring
15	3347243	Connector 6-Circuit
16	8557930	Top
17	357213	Nut, Push-In (2)
18	W10186068	Harness, Wiring
19	688805	Spring Clip, Knob
20	94614	Terminal
21	W10185972	TIMER
22	3936144	Connector
23	3394427	CLIP-HARNESS
24	3391249	Tie, Cable
25	8538953	Timer Knob
26	3397269	Connector, Timer
27	3401144	Connector, (PTS Relay)
28	3977456	Switch, Push-To-Start

BULKHEAD PARTS

For Model: IED4400VQ1
 (Designer White)





Secadora Whirlpool IED4400VQ1

Guía	N.P.	Descripción
	279948	Kit, Dryer Repair
	3406839	Dry Rack
	8522199	Kit, Dryer Vent Testing
1	348368	Lint Chute Assembly
2	489463	Screw, 8-18 x 5/8
3	3388703	WASHER, SUPPORT
4	347139	Seal, Lint Chute
5	90767	Screw, 8-18 x 3/8
6	696302	Shield, Exhaust
7	3392519	Thermal Fuse
8	3387134	THERMOSTAT, INTERNAL-BIAS
9	3977393	THERMAL, CUT-OFF
10	694089	Wheel, Blower
11	8577230	Housing, Blower
12	8066155	CLIP
13	343641	Screw, 10-16 x 1/2
14	8541818	Box, Heater
15	3977767	THERMOSTAT, 221 F (105 C)
16	339956	Seal
17	3403585	Element, Heater
18	3403636	Baffle, Drum (1)
19	279457	Wire Kit, Terminal
20	8066086	DRUM HOLE PLUG
21	3390647	Screw, 8-18 x 1/2
22	690997	Ring, Tri
23	3399506	Shaft, L.H.
24	3399507	Shaft, R.H.
25	3397590	Roller, Support



Secadora Whirlpool IED4400VQ1

Guía	N.P.	Descripción
26	348197	Washer, Support
27	3359452	Nut, 3/8-16
28	3403491	Bulkhead
29	692526	Ring, Bearing
30	W10219342	Screw, 8-16 x 1/2
31	3406130	Seal, Rear Drum
32	695587	Drum Assembly
33	692490	Baffle, Drum (2)
34	3976434	Bracket, Support
35	90296	Clip