


KitchenAid®

48" BUILT IN REFRIGERATOR


MODELS:

KBSD608ESS00 (Stainless Steel)

KBSD608EBS00 (Black Stainless Steel)



<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	15	3400230	Screw	34		Bracket, Support Base (Front)
	W10763009	Use and Care Guide	16	2257644	Hinge, Top		2006616	Left Hand
	W10763005	Energy Guide	17	W10674648	Bracket, Filter		2006556	Right Hand
	W10762990	English	18	W10001250	Screw	35	1157158	Screw
	W10762992	French	19	2004994	Lock, Bushing	36	2006617	Bracket, Base Support (Rear)
	W10763010	Installation Instructions	20	W10484913	Bushing, Top Hinge	37	2006346	Washer, Extension Arm
2		Cabinet (Not A Serviceable Part)	21	W10663352	Clip	38	2316859	Bushing, Extension Arm
3		Button, Water Filter	22	2221242	Spring, Door Closure (Green)	39	2314064	Tube, Drain
	2260503B	Black	23	486194	Screw	40	W10271541	Connector, Union
4	W10138054	Assembly, Roller	24	2005008	Ring, Bushing Retaining	41	8281163	Screw (Stainless)
5		Assembly, Support Base	25	W10129069	Clip, Wire	42	1118894	Switch, Rocker Arm
	W10279275	Left Hand	26	W10482554	Cover, Bottom Gap		1115373	Switch, Rocker Arm Combination (Freezer)
	W10138423	Right Hand	27		Hinge (Bottom)	43	2215938	Cover, Switch
6		Cap, Water Filter		2006779	Left Hand	44	487415	Screw
	2260518B	Black	28	2302876	Bushing, Adjustable	45		Bracket, Switch
7	2307640	Bracket, Grill Mounting	29	8533913	Screw		W10741112	Left Hand
8	2307584	Grommet, Crossover Tube	30	W10188551	Skirt, Bottom Grille		W10741111	Right Hand
9	2320509	Stop, Door	31		Extension Arm, Door Closer	46	2215612	Cover, Air Duct
10	W10121140	Housing, Water Filter		W10709785	Left Hand	47	2005032	Leveler, Adjustable
11	2318189	Tray, Filter Drip		W10728112	Right Hand	48	2006841	Ring, Retainer
12	3400525	Screw	32		Grille Bottom, Front	49		Cam Assembly
13	W10754687	Filter, Water		W10182718	Black		2307857	Right Hand
14	489399	Screw	33	W10485630	Screw	50	W10780213	Assembly, Switch Wire



Illus.


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Cabinet Side (Right)
	W10568005	Aluminum
2	486194	Screw
3		Trim, Bottom Cabinet
	2316688	Aluminum

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10001250	Screw
5		Trim, Top Cabinet
	2314018	Aluminum
6		Trim, Cabinet Side (Left)
	W10568007	Aluminum

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10121451	Insert, Blind Threaded
8	2005925	Seal, Side Trim






REFRIGERADOR KBSD608EBS00

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)
2	2306010	Thermistor
3	2208970	Duct, Air
4	2259077	Ladder, Shelf
5	520965	Support, Ladder
6	2006475	Screw (White)
7	487539	Screw (Stainless)
8	2302937	Thermistor
9	2302986	Lid, Baffle
10	W10169528	Assembly, Control Baffle

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
11	2317844	Assembly, Thermistor
12	2310205	Assembly, Meat Pan Wire
13	8533929	Screw (Stainless)
14	486194	Screw
15	2221296	Assembly, Air Baffle
16	W10645131	Reservoir, Water
17	W10141518	Screw
18	2309222	Assembly, Air Diffuser
19	2317105	Cover, Thermistor

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
20	2188820	Thermistor
21	W10475010	Assembly, Spacer
22	2309087	Cover, Air Diffuser
23	W10159488	Diverter, Crisper Cover
24	2259398	Seal, Air Duct
25	2003577	Guard, Air Return
26	W10607479	Assembly, LED Module



Illus.


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10436861	Motor, Fan
2	2198665	Tube, Circuit Board
3	2169142	Blade, Fan
4	W10260421	Retainer, Fan Motor
5	2302817	Gasket, Scroll Assembly
6	W10321090	Grommet, Motor
7	486194	Screw
8	2259464	Wedge, Right Air Duct
9	2317844	Assembly, Thermistor
10	W10607479	Assembly, LED Module
11	2221070	Clamp, Tube
12	W10581989	Gasket, Evaporator Cover
13	489214	Screw
14	2182120	Scroll, Fan
15	2259465	Wedge, Left Air Duct
16	2307775	Duct, Air
17	2198643	Lens, Receiver
18		Block, Fan Scroll
	2209066	Left Hand
	2209482	Right Hand

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
19	2215650	Cover, Emitter
20		Liner (Not A Serviceable Part)
21	2259025	Cover, Air Outlet
22	W10581993	Assembly, Evaporator Cover
23	W10428001	Cover, Evaporator
24	2302851	Support, Air Duct
25	487539	Screw (Stainless)
26	2198635	Spring, Door
27	2309284	Deflector, Air Duct
28	1112260	Support, Evaporator
29	2196205	Stud, Shelf
30	W10191952	Screw
31		Rail, Evaporator Cover
	2221107	Left Hand
	2259355	Right Hand
32	2220904	Gasket, Evaporator Cover
33	2259493	Cover, Receiver
34	W10482187	Harness, Bi-Metal Wire
35	2306010	Thermistor

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
36	2317105	Cover, Thermistor
37	2006475	Screw (White)
38	2259032	Ladder, Shelf
39	2259445	Support, Ladder
40	2198634	Pin, Door
41	W10193840	Board, Emitter Circuit
42	2198633	Flipper, Shut Off
43	2255563	Slide, Icemaker Shut Off
44	W10290817	Board, Receiver Circuit
45	W10160570	Bi-Metal, Defrost
46	W10142283	Screw (White)



Illus.**No. Part No. Description**




1	2222970	Bin, Ice
2	W10769145	Ice Container Assembly
3	W10749207	Button, Bin
4	W10134785	Latch, Bin
5	2198608	Spring, Latch

Illus.**No. Part No. Description**

6	2198671	Screw (Stainless)
7	8281163	Screw (Stainless)
8	2188919	Clip, Shaft
9	2198628	Seal
10	2318082	Shaft, Drive

Illus.**No. Part No. Description**

11	2318011	Enclosure, Motor
12	2315547	Motor, Dispenser
13	2318028	Cover
14	2315559	Sleeve, Bearing
15	W10254073	Washer



Illus.No. Part No. Description


1 W10798005 Control Box
2 2317000 Clip, Control Box
3 W10458299 Wire, Jumper

Illus.No. Part No. Description

4 2324973 Bracket, Control Box
5 W10142283 Screw (White)

Illus.No. Part No. Description

6 487539 Screw (Stainless)
7 W10760791 Assembly, User
Interface



Illus.


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10568585	Assembly, Fixed Shelf
2	W10701859	Rack, Wine
3	W10556313	Assembly, Meat Pan Cover
4	W10556776	Assembly, Crisper Cover
5	W10407625	Assembly, Crisper Pan
6		Slide, Meat Pan
	2302954	Left Hand
	2302955	Right Hand
7	2256249	Front, Crisper Pan

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
8		Spacer, Crisper
	2256223	Left Hand
	2256222	Right Hand
9		Slide, Crisper
	2302956	Left Hand
	2302957	Right Hand
10		Spacer, Meat Pan
	2256243	Left Hand
	2256244	Right Hand

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
11	8533928	Screw (Stainless)
		(Left Hand)
	8533929	Screw (Stainless)
		(Right Hand)
12	W10407628	Assembly, Meat Pan
13	2256367	Assembly, Meat Pan Front
14	W10593207	Assembly, Produce Preserver




Illus.No. Part No. Description

1	W10759087	Shelf, Wire
2	W10759067	Shelf, Fixed
3	2259083	Basket, Freezer
4	2256271	Assembly, Basket Front

Illus.No. Part No. Description

5		Slide, Basket
	2259318	Left Hand
	2259317	Right Hand
6	8533928	Screw (Stainless)



Illus.


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10761879	Door, Refrigerator
2	W10127710	Plate, Handle Door
3	W10485980	Assembly, Hinge (Top)
4	2316804	Spacer, Door Hinge Bottom
5	W10162602	Screw
6	2302878	Assembly, Bottom Hinge
7	2222797	Rail, Lid
8	2222983	Gasket, Utility Bin
9	W10760886	Gasket, Door
10		Skin, Door
	W10756464	Stainless
	W10756465	Black

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
11		Door, Handle
	W10541592	Stainless
12	W10758113	Spacer, Handle Side Door
13	488568	Screw (Stainless)
14	8281252	Screw (Black)
15	W10761897	Spacer, Door Skin (Top)
16	308544	Screw
17	W10756209	Spacer, Hinge Side Door
18	W10761937	Spacer, Door Skin (Bottom)
19	W10323748	Bin, Gallon Door

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
20		End Cap
	W10323173	Left Hand
	W10323172	Right Hand
21	W10323037	Bin, Utility Center
22	2257617	Door, Utility Bin
23	W10323600	Bin, Shallow Door
24	W10127980	Filler, Foam Board



Illus.


No.	Part No.	Description
1		Door, Freezer
	W10769144	Universal Silver
	W10777532	Black
2	2302879	Assembly, Bottom Hinge
3	W10162602	Screw
4	W10485980	Assembly, Hinge (Top)
5	2316804	Spacer, Door Hinge Bottom
6	W10760884	Grey
7		Door, Handle
	W10541592	Stainless

Illus.

No.	Part No.	Description
8	W10758113	Spacer, Handle Side Door
9		Skin, Door
	W10756222	Stainless
	W10756223	Black
10	8281252	Screw (Black)
11	W10758121	Spacer, Door Skin (Top)
12	488568	Screw (Stainless)
13	W10758123	Spacer, Door Skin Bottom
14	W10756209	Spacer, Hinge Side Door

Illus.

No.	Part No.	Description
15	308544	Screw
16		Filler, Door
	W10159586	Filler, Top Foam Board
	W10159583	Filler, Bottom Foam Board
17	W10127710	Plate, Handle Door
18	W10323603	Bin, Shallow



<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	11		Housing, Middle (Not Available Order Item 12)	17	W10151236	Assembly, User Interface
2	486194	Screw	12	W10260622	Assembly, Housing	18		Tray, Housing
3	W10542660	Bracket, Motor		W10260620	Housing Assembly		2318062B	Black
4	W10546285	Assembly, Motor and Bracket	13		Assembly, Water Paddle	19	2305342	Assembly, LED
5	W10205979	Motor, Ice Door		2305307GN	Universal Silver	20	2305447	Clip, Wiring
6	W10504458	Door, Ice	14		Ice, Paddle Assembly			
7	W10542663	Support, Ice Door		2305306GN	Universal Silver			
8	4449745	Screw	15	2305219	Cover, Control			
9	2305235	Assembly, Spigot	16	2321746	Assembly, User Interface Control Cover			
10	2318017	Assembly, Separator						

Illus.


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Top Grille
	W10761969	Stainless
	W10761970	Black Stainless
2	W10545068	Cover, Unit
3	486194	Screw

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	2256466	Panel, Unit Back
5	W10694109	Cover, Unit Front
6		Nameplate
	W10518672	Grey

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10645086	Divider, Unit Air
8	2215910	Grommet, Flexible



Illus.


<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10645666	Assembly, Inverter Box
2	489373	Screw
3	W10653005	Compressor
4	W10550831	Housing, Control Board Mounting
5	2318054	Control, Electronic
6	1100826	Grommet
7		Support, Condenser
	W10525177	Left Hand
	W10525179	Right Hand
8	W10648264	Tube, Heat Loop Transition
9	2215676	Cover, Terminal
10	W10587113	Grommet
11	W10200659	Control, Electronic
12	2203075	Spacer
13	2256328	Bracket, Inverter Mounting
14	487539	Screw (Stainless)
15	1157158	Screw
16	W10591457	Condenser

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
17	W10624574	Supply, Power
18	W10770059	Plate, Circuit Board (Top)
19	2310195	Assembly, Jumper Wire (Power Switch to Power Cord)
20	2155774	Tie, Wire
21	W10175593	Drier
22	W10414681	Bracket, Fan Motor
23	2188875	Motor, Condenser
24	W10139483	Blade, Fan
25	W10415670	Orifice, Fan
26	W10146359	Screw
27	W10635302	LED Control
28	2259350	Board, Power Supply
29	W10624944	Tube, Drier Transition
30	W10528578	Tube, Process
31	486194	Screw
32	W10525175	Cover, Condenser Support
33	2310196	Cord, Power
34	W10321055	Bracket, Control Assembly

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
35	549193	Clamp, Power Cord
36	2266802	Switch, Power Disconnect
37	2319835	Grommet, Condenser
38	W10775849	Assembly, Unit Wire
39	W10761479	Plate, Circuit Board
		Following Parts Not Illustrated
	978025	Valve, Access
	978026	Valve, Access
	978027	Valve, Access
	978028	Valve, Access
	978029	Valve, Access
	978030	Valve, Access
	876764	Valve, Access
		REFRIGERANT CHARGE
		7.25 oz. (R-134A)



Illus.

No. Part No. Description

	1	W10139908	Cover, Evaporator Seal
	2	486194	Screw
	3	W10157752	Bracket, Heater
	4	W10648568	Tube, Oil Trap Suction
5		W10388653	Tube, Transition (Drier/Restrictor)
	6	W10281063	Assembly, Drain Pan
	7	W10309012	Cover, Wiring

Illus.


No. Part No. Description

	8	W10321048	Cover, Wire Box
	9	W10499597	Tube, Discharge
	10	2188820	Thermistor
	11	W10427993	Evaporator
	12	W10140162	Heater, Defrost
	13	1113048	Clamp, Heater
	14	W10321050	Shelf, Wiring Cover
	15	W10432308	Gasket, Evaporator

Illus.

No. Part No. Description

	16	4389107	Tie, Wire
	17	W10169509	Clip, Heat Exchanger
	18	2320554	Support, Drain Pan
	19	W10413009	Grommet, Air Return
	20	2215648	Dampener
	21	W10160981	Assembly, Air Return Bracket



Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	2320601	Shield, Water Valve
2	W10508659	Assembly, Icemaker Wire
3	628379	Clip, Thermal Fuse
4	W10296807	Tube, Filter Inlet
5	486194	Screw
6	2252228	Bracket, Icemaker Mounting
7	W10683737	Tube, Filter Outlet
8	W10159842	Valve, Inlet
9	2221070	Clamp, Tube
10	2320559	Support, Valve
11	2198641	Bracket, Icemaker Cover
12	2208136	Clip, Water Tube

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
13	W10357286	Fitting, Water
14	W10289690	Cover, Icemaker
15	W10141604	Screw
16	628228	Assembly, Mold and Heater (Also Order 542638)
17		Motor, (Not Serviceable Order Item 28)
18	W10377998	Cup, Fill
19	627843	Ejector
20	W10272161	Stripper, Ice
21	2194712	Support, Housing
22	2315522	Retainer, Thermostat
23	627985	Thermostat
24	W10001280	Screw
25	W10279391	Assembly, Smart Valve Wire

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
26	489276	Screw
27	W10504754	Cover, Icemaker
28	W10223929	Assembly, Module and Motor
29	W10001250	Screw
100	W10774430	Complete Icemaker Assembly
		Following Parts Not Illustrated
	W10355016	Cleaner, Stainless Steel
	W10355010	Cleaner, Kitchen & Appliance
	W10355049	Wipes, Stainless Steel Cleaning
	REFDEODOR...	Deodorizer Pack