

**KitchenAid®**

**48" BUILT IN REFRIGERATOR**


**MODELS:**

KBSD608ESS01 (Stainless Steel)

KBSD608EBS01 (Black Stainless Steel)



# REFRIGERADOR KBSD608EBS01




# REFRIGERADOR KBSD608EBS01

<u>Ilus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts W10763009 Use and Care Guide W10763005 Energy Guide W10910733 English W10910734 French W10763010 Installation Instructions
2		Cabinet (Not A Serviceable Part)
3		Button, Water Filter 2260503B Black
4	W10138054	Assembly, Roller
5		Assembly, SupportBase W10279275 Left Hand W10138423 Right Hand
6		Cap, Water Filter W10797527 Black
7	2307640	Bracket, Grill Mounting
8	2307584	Grommet, Crossover Tube
9	2320509	Stop, Door
10	W10121140	Housing, Water Filter
11	2318189	Tray, Filter Drip
12	3400525	Screw
13	W10754687	Filter, Water
14	489399	Screw

<u>Ilus. No.</u>	<u>Part No.</u>	<u>Description</u>
15	3400230	Screw
16	2257644	Hinge, Top
17	W10674648	Bracket, Filter
18	W10001250	Screw
19	2004994	Lock, Bushing
20	W10484913	Bushing, Top Hinge
21	W10663352	Clip
22	2221242	Spring, Door Closure (Green)
23	486194	Screw
24	2005008	Ring, Bushing Retaining
25	W10129069	Clip, Wire
26	W10482554	Cover, Bottom Gap
27		Hinge (Bottom) 2006779 Left Hand 2006780 Right Hand
28	2302876	Bushing, Adjustable
29	8533913	Screw
30	W10188551	Skirt, Bottom Grille
31		Extension Arm, Door Closer W10709785 Left Hand W10728112 Right Hand
32		Grille Bottom, Front W10182718 Black
33	W10485630	Screw

<u>Ilus. No.</u>	<u>Part No.</u>	<u>Description</u>
34		Bracket, Support Base (Front) 2006616 Left Hand 2006556 Right Hand
35	1157158	Screw
36	2006617	Bracket, Base Support (Rear)
37	2006346	Washer, Extension Arm
38	2316859	Bushing, Extension Arm
39	W10548640	Tube, Drain
40	W10271541	Connector, Union
41	8281163	Screw(Stainless)
42	1118894	Switch, Rocker Arm 1115373 Switch, Rocker Arm Combination (Freezer)
43	2215938	Cover, Switch
44	487415	Screw
45		Bracket, Switch W10741112 Left Hand W10741111 Right Hand
46	2215612	Cover, Air Duct
47	2005032	Leveler, Adjustable
48	2006841	Ring, Retainer
49		Cam Assembly 2307857 Right Hand
50	W10780213	Assembly, SwitchWire

# REFRIGERADOR KBSD608EBS01



Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas


# REFRIGERADOR KBSD608EBS01

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Trim, Cabinet Side (Right)
	W10568005	Aluminum
2	486194	Screw
3		Trim, Bottom Cabinet
	2316688	Aluminum

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10001250	Screw
5		Trim, Top Cabinet
	2314018	Aluminum
6		Trim, Cabinet Side (Left)
	W10568007	Aluminum

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10121451	Insert, Blind Threaded
8	2005925	Seal, Side Trim


# REFRIGERADOR KBSD608EBS01



# REFRIGERADOR KBSD608EBS01

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	11	2317844	Assembly, Thermistor	20	2188820	Thermistor
2	2306010	Thermistor	12	2310205	Assembly, Meat Pan Wire	21	W10475010	Assembly, Spacer
3	2208970	Duct, Air	13	8533929	Screw (Stainless)	22	2309087	Cover, Air Diffuser
4	2259077	Ladder, Shelf	14	486194	Screw	23	W10159488	Diverter, Crisper Cover
5	520965	Support, Ladder	15	2221296	Assembly, Air Baffle	24	2259398	Seal, Air Duct
6	W10808292	Screw (White)	16	W10645131	Reservoir, Water	25	2003577	Guard, Air Return
7	487539	Screw (Stainless)	17	W10141518	Screw	26	W10843339	Assembly, LED Module
8	2302937	Thermistor	18	2309222	Assembly, Air Diffuser			
9	2302986	Lid, Baffle	19	2317105	Cover, Thermistor			
10	W10169528	Assembly, Control Baffle						

# REFRIGERADOR KBSD608EBS01






# REFRIGERADOR KBSD608EBS01

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10436861	Motor, Fan	19	2215650	Cover, Emitter	36	2317105	Cover, Thermistor
2	2198665	Tube, Circuit Board	20		Liner (Not A Serviceable Part)	37	W10808292	Screw (White)
3	2169142	Blade, Fan	21	2259025	Cover, Air Outlet	38	2259032	Ladder, Shelf
4	W10260421	Retainer, Fan Motor	22	W10813095	Assembly, Evaporator	39	2259445	Support, Ladder
5	2302817	Gasket, Scroll Assembly			Cover	40	2198634	Pin, Door
6	W10321090	Grommet, Motor	23	W10428001	Cover, Evaporator	41	W10193840	Board, Emitter Circuit
7	486194	Screw	24	2302851	Support, Air Duct	42	2198633	Flipper, Shut Off
8	2259464	Wedge, Right Air Duct	25	487539	Screw (Stainless)	43	2255563	Slide, Icemaker Shut Off
9	2317844	Assembly, Thermistor	26	2198635	Spring, Door	44	W10290817	Board, Receiver Circuit
10	W10843339	Assembly, LED Module	27	2309284	Deflector, Air Duct	45	W10482187	Bi-Metal, Defrost
11	2221070	Clamp, Tube	28	1112260	Support, Evaporator	46	W10142283	Screw (White)
12	W10581989	Gasket, Evaporator Cover	29	2196205	Stud, Shelf			
13	489214	Screw	30	W10191952	Screw			
14	2182120	Scroll, Fan	31		Rail, Evaporator Cover			
15	2259465	Wedge, Left Air Duct		2221107	Left Hand			
16	2307775	Duct, Air		2259355	Right Hand			
17	2198643	Lens, Receiver	32	2220904	Gasket, Evaporator Cover			
18		Block, Fan Scroll	33	2259493	Cover, Receiver			
	2209066	Left Hand	34	W10482187	Harness, Bi-Metal Wire			
	2209482	Right Hand	35	2306010	Thermistor			

# REFRIGERADOR KBSD608EBS01





# REFRIGERADOR KBSD608EBS01

**Illus.**  
**No.**    **Part No.**    **Description**

- 1    2222970    Bin, Ice
- 2    W10769145    Ice Container Assembly
- 3    W10749207    Button, Bin
- 4    W10134785    Latch, Bin
- 5    2198608    Spring, Latch




**Illus.**  
**No.**    **Part No.**    **Description**

- 6    2198671    Screw (Stainless)
- 7    8281163    Screw(Stainless)
- 8    2188919    Clip, Shaft
- 9    2198628    Seal
- 10    2318082    Shaft, Drive

**Illus.**  
**No.**    **Part No.**    **Description**

- 11    2318011    Enclosure, Motor
- 12    2315547    Motor, Dispenser
- 13    2318028    Cover
- 14    2315559    Sleeve, Bearing
- 15    W10254073    Washer

# REFRIGERADOR KBSD608EBS01



Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas


# REFRIGERADOR KBSD608EBS01

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10798005	Control Box
2	2317000	Clip, Control Box
3	W10458299	Wire, Jumper

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10160981	Bracket, Control Box
5	W10142283	Screw (White)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	487539	Screw (Stainless)
7	W10760791	Assembly, User Interface

# REFRIGERADOR KBSD608EBS01




# REFRIGERADOR KBSD608EBS01

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10568585	Assembly, Fixed Shelf
2	W10701859	Rack, Wine
3	W10556313	Assembly, Meat Pan Cover
4	W10556776	Assembly, Crisper Cover
5	W10407625	Assembly, CrisperPan
6	Slide, Meat Pan 2302954 Left Hand 2302955 Right Hand	
7	2256249	Front, Crisper Pan

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
8	Spacer, Crisper 2256223 Left Hand 2256222 Right Hand	
9	Slide, Crisper 2302956 Left Hand 2302957 Right Hand	
10	Spacer, Meat Pan 2256243 Left Hand 2256244 Right Hand	

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
11	8533928	Screw (Stainless) (Left Hand)
	8533929	Screw (Stainless) (Right Hand)
12	W10407628	Assembly, Meat Pan
13	2256367	Assembly, Meat Pan Front
14	W10593207	Assembly, Produce Preserver

# REFRIGERADOR KBSD608EBS01





Distribuidor Autorizado


**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas

# REFRIGERADOR KBSD608EBS01

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10759087	Shelf, Wire	5		Slide, Basket
2	W10759067	Shelf, Fixed		2259318	Left Hand
3	2259083	Basket, Freezer		2259317	Right Hand
4	2256271	Assembly, Basket Front	6	8533928	Screw (Stainless)

# REFRIGERADOR KBSD608EBS01




# REFRIGERADOR KBSD608EBS01

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10761879	Door, Refrigerator
2	W10127710	Plate, Handle Door
3	W10485980	Assembly, Hinge (Top)
4	2316804	Spacer, Door Hinge Bottom
5	W10162602	Screw
6	2302878	Assembly, Bottom Hinge
7	*****	Rail, Lid
8	W10798552	Gasket, Utility Bin
9	W10760886	Gasket, Door Skin, Door
10	W10756465	Stainless
	W10756465	Black

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
11	Door, Handle W10541592	Stainless
12	W10758113	Spacer, Handle Side Door
13	488568	Screw (Stainless)
14	8281252	Screw (Black)
15	W10761897	Spacer, Door Skin (Top)
16	308544	Screw
17	W10756209	Spacer, Hinge Side Door
18	W10761937	Spacer, Door Skin (Bottom)
19	W10323748	Bin, Gallon Door

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
20	End Cap	2222762 Left Hand 2222761 Right Hand
21	W10798552	Bin, Utility Center
22	2257617	Door, Utility Bin
23	W10323600	Bin, Shallow Door
24	W10127980	Filler, Foam Board

# REFRIGERADOR KBSD608EBS01




# REFRIGERADOR KBSD608EBS01

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer
	W10769144	Universal Silver
	W10777532	Black
2	2302879	Assembly, Bottom Hinge
3	W10162602	Screw
4	W10485980	Assembly, Hinge(Top)
5	2316804	Spacer, Door Hinge Bottom
6	W10760884	Grey
7		Door, Handle
	W10541592	Stainless

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10758113	Spacer, Handle Side Door
9		Skin, Door
	W10756223	Stainless
	W10756223	Black
10	8281252	Screw (Black)
11	W10758121	Spacer, Door Skin (Top)
12	488568	Screw (Stainless)
13	W10758123	Spacer, Door Skin Bottom
14	W10756209	Spacer, Hinge Side Door

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
15	308544	Screw
16		Filler, Door
	W10159586	Filler, Top Foam Board
	W10159583	Filler, Bottom Foam Board
17	W10127710	Plate, Handle Door
18	W10323603	Bin, Shallow


# REFRIGERADOR KBSD608EBS01



# REFRIGERADOR KBSD608EBS01

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	11		Housing, Middle (Not Available Order Item 12)	17	W10151236	Assembly, User Interface
2	486194	Screw	12	W10260620	Assembly, Housing	18		Tray, Housing
3	W10542660	Bracket, Motor		W10260620	Housing Assembly		2318062B	Black
4	W10546285	Assembly, Motor and Bracket	13		Assembly, WaterPaddle	19	2305342	Assembly, LED
5	W10205979	Motor, Ice Door		2305307GN	Universal Silver	20	2305447	Clip, Wiring
6	W10504458	Door, Ice	14		Ice, Paddle Assembly			
7	W10542663	Support, Ice Door		2305306GN	Universal Silver			
8	4449745	Screw	15	2305219	Cover, Control			
9	2305235	Assembly, Spigot	16	2321746	Assembly, User Interface Control Cover			
10	2318017	Assembly, Separator						

# REFRIGERADOR KBSD608EBS01





Distribuidor Autorizado

**SurteRápido.com**

Venta de Refacciones  
Electrodomesticas


# REFRIGERADOR KBSD608EBS01

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Top Grille
	W10761970	Stainless
	W10761970	Black Stainless
2	W10545068	Cover, Unit
3	486194	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	2256466	Panel, Unit Back
5	W10694109	Cover, Unit Front
6		Nameplate
	W10518672	Grey

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10645086	Divider, Unit Air
8	2215910	Grommet, Flexible

# REFRIGERADOR KBSD608EBS01



# REFRIGERADOR KBSD608EBS01

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10645666	Assembly, Inverter Box
2	489373	Screw
3	W10913755	Compressor
4	W10550831	Housing, Control Board Mounting
5	2318054	Control, Electronic
6	1100826	Grommet
7		Support, Condenser
	W10525177	Left Hand
	W10525179	Right Hand
8	W10625009	Tube, Heat Loop Transition
9	2215676	Cover, Terminal
10	W10587113	Grommet
11	W10200659	Control, Electronic
12	2203075	Spacer
13	2256328	Bracket, Inverter Mounting
14	487539	Screw (Stainless)
15	1157158	Screw
16	W10591457	Condenser

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
17	W10624574	Supply, Power
18	W10770059	Plate, Circuit Board (Top)
19	2310195	Assembly, Jumper Wire (Power Switch to Power Cord)
20	2155774	Tie, Wire
21	W10175593	Drier
22	W10414681	Bracket, Fan Motor
23	W10527155	Motor, Condenser
24	W10139483	Blade, Fan
25	W10415670	Orifice, Fan
26	W10146359	Screw
27	W10790783	LED Control
28	2259355	Board, Power Supply
29	W10624944	Tube, Drier Transition
30	W10528578	Tube, Process
31	486194	Screw
32	W10525175	Cover, Condenser Support
33	2310196	Cord, Power
34	W10321055	Bracket, Control Assembly


<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
35	549193	Clamp, Power Cord
36	2266802	Switch, Power Disconnect
37	2319835	Grommet, Condenser
38	W10775849	Assembly, UnitWire
39	W10761479	Plate, Circuit Board

Following Parts Not Illustrated

978025	Valve, Access
978026	Valve, Access
978027	Valve, Access
978028	Valve, Access
978029	Valve, Access
978030	Valve, Access
876764	Valve, Access

REFRIGERANT CHARGE  
7.25 oz. (R-134A)

# REFRIGERADOR KBSD608EBS01




# REFRIGERADOR KBSD608EBS01

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10139908	Cover, Evaporator Seal
2	486194	Screw
3	W10157752	Bracket, Heater
4	W10648568	Tube, Oil Trap Suction
5	W10388653	Tube, Transition (Drier/Restrictor)
6	W10281063	Assembly, Drain Pan
7	W10309012	Cover, Wiring

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10321048	Cover, Wire Box
9	W10499597	Tube, Discharge
10	2188820	Thermistor
11	W10427993	Evaporator
12	W10140162	Heater, Defrost
13	1113048	Clamp, Heater
14	W10321050	Shelf, Wiring Cover
15	W10432308	Gasket, Evaporator

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
16	4389107	Tie, Wire
17	W10169509	Clip, Heat Exchanger
18	2320554	Support, Drain Pan
19	W10413009	Grommet, Air Return
20	2215648	Dampener
21	W10160981	Assembly, Air Return Bracket

# REFRIGERADOR KBSD608EBS01



# REFRIGERADOR KBSD608EBS01

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	2320601	Shield, Water Valve
2	W10508659	Assembly, Icemaker Wire
3	628379	Clip, Thermal Fuse
4	W10296807	Tube, Filter Inlet
5	486194	Screw
6	2252228	Bracket, Icemaker Mounting
7	W10683737	Tube, Filter Outlet
8	W10820321	Valve, Inlet
9	2221070	Clamp, Tube
10	2320559	Support, Valve
11	2198641	Bracket, Icemaker Cover
12	2208136	Clip, Water Tube

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
13	W10357286	Fitting, Water
14	W10289690	Cover, Icemaker
15	W10141604	Screw
16	628228	Assembly, Mold and Heater (Also Order 542638)
17		Motor, (Not Serviceable Order Item 28)
18	W10377998	Cup, Fill
19	627843	Ejector
20	W10272161	Stripper, Ice
21	2194712	Support, Housing
22	2315522	Retainer, Thermostat
23	627985	Thermostat
24	W10001280	Screw
25	W10279391	Assembly, Smart Valve Wire

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
26	489276	Screw
27	W10504754	Cover, Icemaker
28	W10223929	Assembly, Module and Motor
29	W10001250	Screw
100	W10774430	Complete Icemaker Assembly
		Following Parts Not Illustrated
	W10355016	Cleaner, Stainless Steel
	W10355010	Cleaner, Kitchen & Appliance
	W10355049	Wipes, Stainless Steel Cleaning
	REFDEODOR...	Deodorizer Pack