



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts W10114100 Guide, U & C W10314563 Tech Sheet
2	W10160564	Front Screen
3	W10160543	Door Frame Asm
4	8205777	Choke Cover
5	W10160562	Tape, Seal
6	8184263	Latch
7	8183882	Spring, Latch
8	W10160561	Panel, Door
9	W10160557	Door Assembly




Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------


1	W10160560	Button, Release
2	8184272	Spring, Button
3	W10160556	Membrane/Panel
4	W10160555	Microcomputer
5	8205451	Lever, Release
6	4358883	Screw




Illus. No.	Part No.	DESCRIPTION
1	8184278	Canopy
2	W10160554	Outer Case
3	W10160544	Tray, Glass
4	W10160542	Turntable Support
5	8184375	Motor, Synchronous
6	4358188	Screw
7	4358829	Screw
8	8171862	Screw
9	W10160547	Sensor, Humidity
10	8205457	Guide, Sensor
11	4358376	Screw
12	4358489	Screw



Illus. No.	Part No.	DESCRIPTION
1		Latch Board Assembly (Non-Serviceable)
2	8185271	Latch Board
3	8183561	Switch Micro Primary/Secondary
4	8183562	Switch, Micro Monitor
5	4358271	Screw



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8205458	Propeller	8	W10329754	Power Cord	16	W10329753	Filter, Noise
2	8205456	Guide, Suction	9	W10160550	Thermostat	17	8205509	Insulator
3	8205462	Motor, Fan	10	8171810	Lamp, Baseless	18	4358190	Screw
4	8185272	H.V. Capacitor	11	W10160545	Duct, Air	19	4358489	Screw
5	8184288	H.V.C Bracket	12	8205460	Magnetron	20	4358381	Screw
6	W10329902	Leadwire Assembly	13	4359794	Holder	21	4358271	Screw
7	W10160548	H.V. Diode Cable	14	4359781	Damper	22	W10160553	Screw
			15	W10170368	Fuse			



Illus. No.	Part No.	DESCRIPTION
1	W10160551	Base Plate (L)
2	W10160552	Base Plate (R)
3	8184385	Leg
4	W10170369	Transformer
5	4358192	Screw
6	4358489	Screw